

Controllers, Indicators, and Recorders

Controllers

Page 1 of 2

Product	Date	Doc. Num	Title or Description
37	0108	PL 003-320	Parts List - Diaphragm Meter With Intermediate Linkage
37	0403	PSS 3-4A2 A	Product Specification Sheet - Diaphragm Measuring Element
40	0702	PL 001-105	Parts List - Box Pens, Pen-Arms, Indexes for Instruments
40	0702	PL 001-345	Parts List - Indicating Scale and Light Assemblies for Instruments
40M	0702	PL 001-105	Parts List - Box Pens, Pen-Arms, Indexes for Instruments
40M	0702	PL 001-345	Parts List - Indicating Scale and Light Assemblies for Instruments
40M	0410	PL 004-111	Parts List - On-Off or Narrow Band Proportional Types
40M	0410	PL 004-116	Parts List - On-Off or Narrow Band Proportional Types
40M	0410	PL 004-121	Parts List - Dual or Duplex, On-Off or Narrow Band Types
40M	0410	PL 004-126	Parts List - Dual or Duplex Proportional Types
40M	0402	PSS 3-1A1 A	Product Specification Sheet
40P	0702	PL 001-105	Parts List - Box Pens, Pen-Arms, Indexes for Instruments
40P	0702	PL 001-345	Parts List - Indicating Scale and Light Assemblies for Instruments
40P	0410	PL 004-111	Parts List - On-Off or Narrow Band Proportional Types
40P	0410	PL 004-116	Parts List - On-Off or Narrow Band Proportional Types
40P	0410	PL 004-121	Parts List - Dual or Duplex, On-Off or Narrow Band Types
40P	0410	PL 004-126	Parts List - Dual or Duplex Proportional Types
40P	0403	PSS 3-1A2 A	Product Specification Sheet - Pressure Recorders, Indicators, and Recording or Indicating Controllers
40P	0201	PSS 3-1A2 B	Product Specification Sheet - Temperature Recorders, Indicators, and Recording or Indicating Controllers
40P	0403	PSS 3-1A2 C	Product Specification Sheet - Flow Recorders, Indicators, and Controllers
43AP	0306	DP 011-476	Dimensional Print
43AP	0180	MI 011-476	Installation and Operation
43AP	0486	MI 011-477	Servicing
43AP	0486	MI 011-481	Maintenance and Alignment
43AP	0209	PL 004-484	Parts List
43AP	0403	PSS 3-1B3 A	Product Specification Sheet- Pneumatic Indicating Controllers
43AP	0101	PSS 3-1B3 B	Product Specification Sheet - Controllers for Electronic Inputs
43APG	0609	PL 004-494	Parts List
130	0603	PL 004-560	Parts List - Automatic Control Section for Controllers
130M	0806	DP 017-450	Dimensional Print
130M	0578	MI 017-450	Installation and Maintenance
130M	0179	PL 004-550	Parts List
130M	0495	PSS 2B-4H1 A	Product Specification Sheet
138	0101	PSS 2B-4H1 M	Product Specification Sheet
716C	1196	DP 018-575	Dimensional Print
716C	0297	MI 018-575	1/6 DIN Temperature
716C	0597	MI 018-579	1/16 DIN and 1/8 DIN Temperature Serial Communications Guide
716C	1196	PSS 2C-1B5 A	Product Specification Sheet

Controllers, Indicators, and Recorders

Controllers

Page 2 of 2

Product	Date	Doc. Num	Title or Description
718P	1196	DP 018-574	Dimensional Print
718P	0297	MI 018-574	1/8 DIN Temperature with Series Interface
718P	0597	MI 018-578	1/8 DIN Process Serial Communications Guide
718P	1196	PSS 2C-1B4 A	Product Specification Sheet
718TC	1196	DP 018-572	Dimensional Print
718TC	0297	MI 018-573	1/8 DIN Temperature with mA Output
718TC	0597	MI 018-579	1/16 DIN and 1/8 DIN Temperature Serial Communications Guide
718TC	1196	PSS 2C-1B3 A	Product Specification Sheet
740C	0905	MI 018-871	Digital Circular Chart Recorder and Recording Controller - Installation, Operation, Configuration, and Maintenance
740C	1005	PL 009-166	Parts List
740C	1005	PSS 2C-1A7 A	Product Specification Sheet
762	0398	MI 018-888	Serial Communications Guide
762	0895	TI 039-200	Technical Information
762C	0696	PSS 2C-1A1 D	Product Specification Sheet
762CNA	0906	DP 018-836	Dimensional Print
762CNA	0298	MI 018-885	SINGLE STATION MICRO
762CNA	0499	PL 009-136	Parts List
762CSA	0298	MI 018-889	Shelf Mounted
762CSA	0605	PL 009-139	Parts List

May 2010

Controllers, Indicators, and Recorders Indicators

Product	Date	Doc. Num	Title or Description
45P	0501	PSS 2B-1H1 E	Product Specification Sheet
65FS	1006	MI 018-272	Field Mounted
65FS	0210	PL 008-559	Parts List
65FS	0210	PSS 2A-3B1 C	Product Specification Sheet
65P	0101	PSS 2A-3B1 A	Product Specification Sheet
710D	1196	DP 018-571	Dimensional Print
710D	0297	MI 018-571	1/8 DIN Digital
710D	0597	MI 018-576	Digital Serial Communications Guide
710D	1196	PSS 2C-1B2 A	Product Specification Sheet

Controllers, Indicators, and Recorders

Recorders

Product	Date	Doc. Num	Title or Description
40	0705	MI 001-130	Instrument Mounting and Connections Model 40 Recorders - Installation
40M	0705	MI 001-145	Mullins Chart Changers for Recorder - Installation and Operation (AS Reference MCC)
40M	0410	PL 001-301	Parts List - Circular Chart Recorder
40P	0705	MI 001-145	Mullins Chart Changers for Recorder - Installation and Operation (AS Reference MCC)
40P	0410	PL 001-301	Parts List - Circular Chart Recorder
120	0603	PL 006-413	Parts List - Style D
120	0509	PL 006-414	Parts List - Style E
120	1004	PL 006-416	Parts List - Chart Drives for 120 Series
120	0101	PSS 2B-3E1 A	Product Specification Sheet
740R	0905	MI 018-871	Digital Circular Chart Recorder and Recording Controller - Installation, Operation, Configuration, and Maintenance
740R	1005	PL 009-166	Parts List
740R	1005	PSS 2C-1A8 A	Product Specification Sheet
752RNA	0402	PSS 2C-1A16 A	Product Specification Sheet
763MNA	0901	PL 009-178	Parts List
763MNA	0402	PSS 2C-1A15 A	Product Specification Sheet
763RNA	0901	PL 009-178	Parts List
763RNA	0402	PSS 2C-1A14 A	Product Specification Sheet
6100AF	1208	DP 018-910	Dimensional Print
6100AF	0809	MI 018-910	Paperless Graphic Recorders
6100AF	0110	PL 009-190	Parts List
6100AF	0110	PSS 2C-1C1 A	Product Specification Sheet - Paperless Graphic Recorder
6180AF	1208	DP 018-910	Dimensional Print
6180AF	0809	MI 018-910	Paperless Graphic Recorders
6180AF	0809	PL 009-190	Parts List
6180AF	0809	PSS 2C-1C1 A	Product Specification Sheet - Paperless Graphic Recorder
E20S	0701	PSS 2A-3A1 C	Product Specification Sheet

Electrochemical Analyzers

Page 1 of 2

Product	Date	Doc. Num	Title or Description
BS810NX	1104	MI 611-226	Remote Communications Program for 875 Analyzers
BS811BV	0509	MI 611-207	Conversion Kit to Add HART Capability to 875 Series Analyzers
BS811FN	0206	MI 611-228	General Purpose Firmware Upgrade Kit for 875 Analyzers
BS811GC	1002	MI 611-189	Static Charge Control Upgrade for 875PH Analyzers
BS811GD	1002	MI 611-189	Static Charge Control Upgrade for 873PH-..P Analyzers
BS811GE	1002	MI 611-189	Static Charge Control Upgrade for 873PH-..W, X, Y, or Z Analyzers
873	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
873A	1003	PSS 6-1C1 F	Product Specification Sheet
873ACC	0604	MI 611-192	Ace Series Analyzers for Contacting Conductivity Measurement
873AEC	0604	MI 611-193	Ace Series Analyzers for Electrodeless Conductivity Measurement
873APH	0604	MI 611-191	Ace Series Analyzers for pH Measurements
873ARS	0604	MI 611-194	Ace Series Analyzers for Resistivity Measurements
873CC	0608	DP 611-162	Dimensional Print
873CC	0604	MI 611-166	Contact/Conductivity Measurement
873CC	1295	PL 611-016	Parts List
873CC	1003	PSS 6-1C1 E	Product Specification Sheet
873DO	0608	DP 611-149	Dimensional Print
873DO	0608	DP 611-162	Dimensional Print
873DO	0705	MI 611-169	Dissolved Oxygen Measurement
873DO	1295	PL 611-016	Parts List
873DO	1003	PSS 6-1C1 E	Product Specification Sheet
873DPX	0608	DP 611-162	Dimensional Print
873DPX	0604	MI 611-190	pH/ORP/ISE Measurement
873DPX	1295	PL 611-016	Parts List
873DPX	0594	PSS 6-1C1 B	Product Specification Sheet
873DPX	1003	PSS 6-1C1 E	Product Specification Sheet
873EC	0608	DP 611-162	Dimensional Print
873EC	0409	MI 611-167	Electrodeless Conductivity Measurement
873EC	0409	MI 611-220	System Calibration Examples
873EC	1295	PL 611-016	Parts List
873EC	1003	PSS 6-1C1 E	Product Specification Sheet
873PH	0608	DP 611-162	Dimensional Print
873PH	0604	MI 611-165	pH and ORP Measurement
873PH	1295	PL 611-016	Parts List
873PH	0594	PSS 6-1C1 B	Product Specification Sheet
873PH	1003	PSS 6-1C1 E	Product Specification Sheet
873RS	0608	DP 611-162	Dimensional Print
873RS	1005	MI 611-168	Resistivity Measurement
873RS	1295	PL 611-016	Parts List
873RS	1003	PSS 6-1C1 E	Product Specification Sheet

Electrochemical Analyzers

Page 2 of 2

Product	Date	Doc. Num	Title or Description
875	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
875	0509	MI 611-207	Conversion Kit BS811BV to Add HART Communication Capability
875	0408	MI 611-208	Safety Information
875	1104	MI 611-226	Remote Communications Program BS810NX
875	1004	MI 611-227	Operation, Configuration and Calibration Using a HART Communicator
875	0206	MI 611-228	General Purpose Firmware Upgrade Kit BS811FN
875	0508	MI 611-246	Remote Communications
875CR	0500	DP 611-164	Dimensional Print
875CR	0809	MI 611-222	Contacting Conductivity and Resistivity Measurements
875CR	0206	PL 611-158	Parts List - Style A
875CR	1006	PL 611-163	Parts List - Styles C-D
875CR	1206	PSS 6-3A1 B	Product Specification Sheet
875EC	0500	DP 611-164	Dimensional Print
875EC	0809	MI 611-224	Electrodeless Conductivity Measurement
875EC	0409	MI 611-220	System Calibration Examples
875EC	0206	PL 611-158	Parts List - Style A
875EC	1006	PL 611-163	Parts List - Styles C-D
875EC	0209	PSS 6-3N1 C	Product Specification Sheet
875PH	0500	DP 611-164	Dimensional Print
875PH	0809	MI 611-225	pH, ORP, or Ion Selective Electrode (ISE) Measurement - Style C
875PH	0206	PL 611-158	Parts List - Style A
875PH	1006	PL 611-163	Parts List - Styles B-C
875PH	1206	PSS 6-1A1 E	Product Specification Sheet

May 2010

Electrochemical Transmitters

Product	Date	Doc. Num	Title or Description
870IT	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
870IT	0595	MI 611-213	Conversion Kit Kit-C-BS806ZP to Add Rain Door Assembly
870IT	0408	MI 611-208	Safety Information
870ITCR	0398	DP 611-163	Dimensional Print
870ITCR	0310	MI 611-216	Contact Conductivity/Resistivity
870ITCR	1002	PL 611-153	Parts List - Style B
870ITCR	1002	PL 611-156	Parts List - Style A
870ITCR	0609	PSS 6-3C1 B	Product Specification Sheet
870ITEC	0398	DP 611-163	Dimensional Print
870ITEC	0409	MI 611-212	Electrodeless Conductivity Measurements
870ITEC	0409	MI 611-220	System Calibration Examples
870ITEC	1002	PL 611-153	Parts List - Style B
870ITEC	1002	PL 611-156	Parts List - Style A
870ITEC	0509	PSS 6-3N2 A	Product Specification Sheet
870ITPH	0398	DP 611-163	Dimensional Print
870ITPH	1005	MI 611-211	pH, ORP, and ION Selective Electrode Measurements
870ITPH	1002	PL 611-153	Parts List - Style B
870ITPH	1002	PL 611-156	Parts List - Style A
870ITPH	0509	PSS 6-1B1 B	Product Specification Sheet

Electrochemical Sensors

pH and ORP Sensors Page 1 of 2

Product	Date	Doc. Num	Title or Description
BS810FA	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871PH Titanium
BS810FB	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871PH 316 ss
BS811HZ	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871A 316 ss
BS811JC	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871A Titanium
ORP10	1103	DP 611-171	Dimensional Print
ORP10	1103	DP 611-172	Dimensional Print - Insertion Assemblies for DolpHin
ORP10	1103	DP 611-173	Dimensional Print - Mounting Accessories for DolpHin
ORP10	0902	MI 611-204	Use of Universal Bushing with DolpHin Sensors (BS810XB and BS810XC)
ORP10	0809	MI 611-205	DolpHin - Installation, Troubleshooting, Maintenance, and Parts List
ORP10	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
ORP10	0408	MI 611-208	Safety Information
ORP10	0802	PSS 6-1C3 A	Product Specification Sheet
PH10	1103	DP 611-171	Dimensional Print
PH10	1103	DP 611-172	Dimensional Print - Insertion Assemblies for DolpHin
PH10	1103	DP 611-173	Dimensional Print - Mounting Accessories for DolpHin
PH10	0902	MI 611-204	Use of Universal Bushing with DolpHin Sensors (BS810XB and BS810XC)
PH10	0809	MI 611-205	DolpHin - Installation, Troubleshooting, Maintenance, and Parts List
PH10	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
PH10	0408	MI 611-208	Safety Information
PH10	0802	PSS 6-1C3 A	Product Specification Sheet
PH12	0909	DP 611-214	Dimensional Print
PH12	1009	MI 611-214	pH Sensors and Accessories - Installation, Troubleshooting, and Maintenance
PH12	0909	MI 611-215	pH Sensors- Quick Start
PH12	0410	PL 611-214	Parts List
PH12	0410	PSS 6-1C5 A	Product Specification Sheet
871	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
871A	0608	DP 611-141	Dimensional Print ECS Flow Through Submersible
871A	0608	DP 611-144	Dimensional Print
871A	0608	DP 611-145	Dimensional Print
871A	0608	DP 611-157	Dimensional Print Ball Valve Assembly
871A	1108	MI 611-164	Installation
871A	0408	MI 611-208	Safety Information
871A	0410	PSS 6-1C2 B	Product Specification Sheet

May 2010

Electrochemical Sensors

pH and ORP Sensors Page 2 of 2

Product	Date	Doc. Num	Title or Description
871PH	0508	DP 611-113	Dimensional Print pH and ORP
871PH	0307	DP 611-121	Dimensional Print Mounting Assembly
871PH	0804	DP 611-122	Dimensional Print Ball Valve Assembly
871PH	0307	DP 611-123	Dimensional Print Optional Containment
871PH	0608	DP 611-140	Dimensional Print ECS Flow Through Spool
871PH	0608	DP 611-141	Dimensional Print ECS Flow Through Submersible
871PH	0493	MI 611-125	Electrode Cleaning System
871PH	0804	MI 611-136	Reference Junction Refill Kit for Sensors
871PH	0808	MI 611-148	Installation and Maintenance
871PH	0408	MI 611-208	Safety Information
871PH	0804	MI 611-188	Electrode Kit for Sensors
871PH	0110	PL 611-014	Parts List
871PH	0410	PSS 6-1C2 A	Product Specification Sheet

Electrochemical Sensors

Conductivity Page 1 of 2

Product	Date	Doc. Num	Title or Description
871CC	0207	DP 611-091	Dimensional Print Flow Chambers
871CC	0605	DP 611-092	Dimensional Print Flanges 316 ss
871CC	0605	DP 611-093	Dimensional Print Twist-Lock Bushing 316 ss
871CC	0605	DP 611-094	Dimensional Print Twist-Lock Bushing PVC
871CC	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
871CC	0605	DP 611-131	Dimensional Print 3/4 NPT Threaded Bushing (-A and -K)
871CC	0605	DP 611-132	Dimensional Print Universal Mounting (-B)
871CC	0605	DP 611-133	Dimensional Print Sanitary Flange Mounted (-C and -L)
871CC	0605	DP 611-134	Dimensional Print Insertion Type (-D and -M)
871CC	0605	DP 611-135	Dimensional Print Twist-Lock Mounted (-E)
871CC	0605	DP 611-136	Dimensional Print 3/4 NPT Threaded Bushing and 1/2 NPT Conduit (-F)
871CC	0605	DP 611-139	Dimensional Print DIP Type (-G)
871CC	0606	MI 611-151	Installation and Maintenance
871CC	0408	MI 611-208	Safety Information
871CC	0105	PSS 6-3C2 A	Product Specification Sheet
871CR	0998	DP 611-165	Dimensional Print Universal Bore Piece
871CR	0998	DP 611-166	Dimensional Print Bushing Mounted
871CR	0998	DP 611-167	Dimensional Print Universal Bore Piece w/Cable Connector or Conduit Fitting
871CR	0998	DP 611-168	Dimensional Print Tri-Clamp Fittings
871CR	0998	DP 611-169	Dimensional Print Insertion Sensors for use with Ball Valve Accessories
871CR	0506	DP 611-170	Dimensional Print Accessories
871CR	0408	MI 611-208	Safety Information
871CR	0606	MI 611-221	Sensors and Accessories
871CR	0708	PL 611-019	Parts List Sensors
871CR	0310	PSS 6-3C2 B	Product Specification Sheet
871EC	0306	DP 611-011	Dimensional Print
871EC	0605	DP 611-092	Dimensional Print Flanges 316 ss
871EC	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
871EC	0608	DP 611-142	Dimensional Print Ball Valve Assembly
871EC	0305	DP 611-155	Dimensional Print Ball Valve Assembly (871EC-SP, -HP, -PP, -PT, -NL, -TF)
871EC	0305	DP 611-180	Dimensional Print Ball Valve Assembly (871EC-RE, -LB, -BW, -UT)
871EC	0306	MI 611-150	Installation and Maintenance
871EC	0408	MI 611-208	Safety Information
871EC	0409	MI 611-220	System Calibration Examples
871EC	0410	PSS 6-3C4 A	Product Specification Sheet
871FT	0408	DP 611-150	Dimensional Print with ANSI Class
871FT	0105	DP 611-151	Dimensional Print with NPT
871FT	0210	DP 611-152	Dimensional Print with Sanitary
871FT	0301	DP 611-153	Dimensional Print with ANSI Class 300
871FT	0797	DP 611-158	Dimensional Print with Metric PN10
871FT	0608	DP 611-159	Dimensional Print with Metric PN16

Electrochemical Sensors

Conductivity Page 2 of 2

Product	Date	Doc. Num	Title or Description
871FT	0209	MI 611-202	Installation, Calibration, and Troubleshooting
871FT	0408	MI 611-208	Safety Information
871FT	0409	MI 611-220	System Calibration Examples
871FT	0310	PL 611-017	Parts List Inch Line Sizes
871FT	0301	PL 611-018	Parts List Millimetre Line Sizes
871FT	0410	PSS 6-3Q1 A	Product Specification Sheet
910	0605	DP 611-092	Dimensional Print Flanges 316 ss
910	0605	DP 611-093	Dimensional Print Twist-Lock Bushing 316 ss
910	0605	DP 611-094	Dimensional Print Twist-Lock Bushing PVC
910	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
910	0605	DP 611-124	Dimensional Print 3/4 NPT Threaded Bushing
910	0605	DP 611-125	Dimensional Print 3/4 NPT Threaded Bushing
910	0605	DP 611-126	Dimensional Print Sanitary Flange Mounted
910	0605	DP 611-127	Dimensional Print Insertion Type
910	0605	DP 611-128	Dimensional Print Twist Lock Mounting
910	0605	DP 611-129	Dimensional Print 3/4 NPT Threaded Bushing and 1/2 NPT Conduit
910	0605	DP 611-130	Dimensional Print DIP Type
920	0605	DP 611-092	Dimensional Print Flanges 316 ss
920	0605	DP 611-093	Dimensional Print Twist-Lock Bushing 316 ss
920	0605	DP 611-094	Dimensional Print Twist-Lock Bushing PVC
920	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
920	0605	DP 611-124	Dimensional Print 3/4 NPT Threaded Bushing
920	0605	DP 611-125	Dimensional Print 3/4 NPT Threaded Bushing
920	0605	DP 611-126	Dimensional Print Sanitary Flange Mounted
920	0605	DP 611-127	Dimensional Print Insertion Type
920	0605	DP 611-128	Dimensional Print Twist Lock Mounting
920	0605	DP 611-129	Dimensional Print 3/4 NPT Threaded Bushing and 1/2 NPT Conduit
920	0605	DP 611-130	Dimensional Print DIP Type
921	0605	DP 611-093	Dimensional Print Twist-Lock Bushing 316 ss
921	0605	DP 611-094	Dimensional Print Twist-Lock Bushing PVC
1210	0605	DP 611-092	Dimensional Print Flanges 316 ss
1210	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
FT10	0207	DP 611-217	Dimensional Print
FT10	0408	MI 611-208	Safety Information
FT10	1007	MI 611-217	Flow-Through Conductivity Sensors - Installation, Calibration, Troubleshooting, and Maintenance
FT10	0409	MI 611-220	System Calibration Examples
FT10	0107	PL 611-141	Parts List
FT10	0209	PSS 6-3Q1 B	Product Specification Sheet

May 2010

Electrochemical Sensors

Other

Product	Date	Doc. Num	Title or Description
	0408	MI 000-004	Master Book 123 Table of Contents
	0408	MI 000-005	Master Book 123 Index by Model
	0105	PSS 6-0A0 A	Analytical Products Manual 012 Table of Contents
	0207	TI 612-005	Electrodeless Conductivity, Toroidal Magnets, and the Procedure of Degaussing
222	0804	DP 611-122	Dimensional Print Ball Valve Assembly
222	0804	DP 611-137	Dimensional Print pH and ORP
871DO	0608	DP 611-149	Dimensional Print
871DO	0705	MI 611-200	Sensors and Accessories
871DO-C	0705	PL 611-121	Parts Lists - Dissolved Oxygen Sensors
871DO-C	0209	PSS 6-9B1 A	Product Specification Sheet
0051052	0904	DP 611-160	Dimensional Print - Junction Box (7 Terminals)
BS807BZ	0904	DP 611-160	Dimensional Print - Junction Box (8 Terminals)
BS811MR	0410	DP 611-174	Dimensional Print - Remote Preamplifier Junction Box
BS811MR	0410	MI 611-229	Remote Preamplifier Junction Box
BS813XN	0410	DP 611-174	Dimensional Print - Junction Box
BS813XN	0410	MI 611-229	Junction Box
EP402	0205	MI 611-177	Small-Bore Flow-Through Assembly
EP459A	0807	DP 611-210	Dimensional Print - Fluoride Measuring System
EP459A	0210	MI 611-210	Fluoride Measuring System
EP459A	0707	PL 611-210	Parts List - Fluoride Measuring System

May 2010

Electrochemical Product Application Data

Product	Date	Doc. Num	Title or Description
875PH	0904	PAD D3620-008	Analyzers for Control and Monitoring in Chromate Waste Treatment
	0998	PAD D3620-012	Point of Use Water Purity Measurements in Semiconductor Industry Using Intelligent Transmitters and Sensors
	0198	PAD G2600-006	Black Liquor Spill Reclamation
	0198	PAD G2600-015	Alkali Concentration Measurement System
	0198	PAD G2600-017	Bleaching
	0198	PAD G2600-018	Brownstock Washing
	0198	PAD G2600-019	Causticizing Control
	0198	PAD G2600-020	Steam Condensate Reclamation
	0198	PAD G2600-021	Dissolving Tank Density Control
	0198	PAD G2600-022	Paper Machine - Wet End pH Control
	0198	PAD G2600-023	Waste Water Treatment
	0198	PAD G2600-024	White Liquor Strength
	0298	PAD P4100-020	Intelligent Analytical Transmitters in Power Plant Applications
	0499	PAD P4100-021	Steam Condensate Leak Detection
	0499	PAD P4100-022	Reverse Osmosis Measurements
	0499	PAD P4100-023	pH Measurement in Wet Scrubbers
	0499	PAD P4100-024	pH Measurement in High Purity Boiler Water
	0499	PAD P4100-025	Demineralizer Regeneration Concentration Control
	0499	PAD P4100-026	Demineralization Bed Monitoring
	0499	PAD P4100-027	Cooling Tower Control
	0499	PAD P4100-028	Condensate Return
	0499	PAD P4100-029	Condensate Analysis
	0499	PAD P4100-030	Waste Water Treatment

May 2010

Foxboro Eckardt Electronic Transmitters

Product	Date	Doc. Num	Title or Description
104..	0696	PSS EML0900A-(en)	Product Specification Sheet Accessories for Buoyancy Transmitter
144LD	0503	MI EML0610A-(en)	Buoyancy Transmitter with Torque Tube
144LD	1008	MI EML0610E-(en)	Buoyancy Transmitter with Torque Tube and Displacer for Level, Interface and Density - All Versions
144LD	1107	MI EML0610F-(en)	Buoyancy Transmitter with Torque Tube and Displacer for Level, Interface and Density with Communication FOUNDATION Fieldbus
144LD	0708	PSS EML0610A-(en)	Product Specification Sheet
144LVD	0605	MI EML1610E-(en)	Buoyancy Transmitter for Liquid Level, Interface and Density
144LVD	0908	PSS EML1610A-(en)	Product Specification Sheet
167LP	1108	PSS EML0110A-(en)	Product Specification Sheet
204..	0109	PSS EML0901A-(en)	Product Specification Sheet Accessories for Buoyancy Transmitter
244LD	0210	MI EML0710E-(en)	Buoyancy Transmitter with Torque Tube and Displacer for Level, Interface and Density - All Versions
244LD	0908	PSS EML0710A-(en)	Product Specification Sheet
244LVP	0210	MI EML1710A-(en)	Buoyancy Transmitter for Liquid Level, Interface and Density
244LVP	0309	PSS EML1710A-(en)	Product Specification Sheet

May 2010

Foxboro Eckardt Positioners

Product	Date	Doc. Num	Title or Description
SRD960	0707	MI EVE0105B-(en)	Universal Positioner with HART Hand-Held Terminal
SRD960	0109	MI EVE0109A-(en)	Universal Positioner
SRD960	0210	PSS EVE0109A-(en)	Product Specification Sheet
SRD991	0707	MI EVE0105B-(en)	Intelligent Positioner with HART Hand-Held Terminal
SRD991	0409	MI EVE0105E(en)	Intelligent Positioner - All Versions
SRD991	1209	PSS EVE0105E-(en)	Product Specification Sheet
SRD992	0899	MI EVE0106A-(en)	Digital Positioner
SRD992	0101	PSS EVE0106A-(en)	Product Specification Sheet
SRI990	1007	MI EVE0107A-(en)	Analog Positioner
SRI990	0210	PSS EVE0107A-(en)	Product Specification Sheet

Magnetic Flow Transmitters

Page 1 of 2

Product	Date	Doc. Num	Title or Description
47	0908	MI 021-322	Magnetic Flow Transmitters - Installation, Commissioning, and Service
47	0908	MI 021-326	Flowmeter Remote Mounting Kit, Installation Kit A5E01268346
47	0507	PSS 1-6G1 A	Product Specification Sheet
48	0908	MI 021-322	Magnetic Flow Transmitters - Installation, Commissioning, and Service
48	0908	MI 021-326	Flowmeter Remote Mounting Kit, Installation Kit A5E01268346
48	0604	MI 021-329	Supplemental Installation Instructions for Transmitter used in PMO, HTST Flowmeter Applications
48	0507	PSS 1-6G1 A	Product Specification Sheet
IMT25	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters
IMT25	0501	DP 021-365	Dimensional Print
IMT25	1208	MI 021-387	Installation with 8000A, 2800, 8300, 9100A, 9200A, and 9300A
IMT25	0409	MI 021-390	Operation, Configuration, and Calibration
IMT25	0405	MI 021-391	System Maintenance with 8000A, 2800, 8300, 9100A, 9200A, and 9300A
IMT25	0698	MI 021-397	Operation, Configuration, and Calibration With HART Communicator
IMT25	0705	PL 008-745	Parts List
IMT25	0309	PSS 1-6F5 A	Product Specification Sheet - FoxCom and HART
IMT25-...F	0605	MI 014-900	Fieldbus Overview
IMT25-...F	0405	MI 021-399	Operation, Configuration, and Calibration from a Fieldbus Host
IMT25-...F	0309	PSS 1-6F5 B	Product Specification Sheet - FOUNDATION Fieldbus
IMT25L	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters
IMT25L	0398	DP 021-366	Dimensional Print
IMT25L	1197	PL 008-746	Parts List
IMT25L	0309	PSS 1-6F6 A	Product Specification Sheet
IMT96	0299	DP 021-367	Dimensional Print
IMT96	0209	MI 021-402	With 2800 Series Flanged Flowtubes Installation
IMT96	0809	MI 021-403	Integral Keypad and Display, Local Operation, Configuration, and Calibration
IMT96	0309	MI 021-404	With 2800 Series Flanged Flowtubes System Maintenance
IMT96	0599	MI 021-412	Retrofitting 2800 Series with Flanged Flowtubes when Previously Connected to an E96
IMT96	0309	MI 021-415	With HART Communications - Operation, Configuration, and Calibration
IMT96	0109	PL 008-747	Parts List
IMT96	0109	PSS 1-6F8 A	Product Specification Sheet
MAG2	1208	TI 027-077	Technical Information Magnetic Flowmeter Application Guideline
MAG2IC	1208	DP 021-500	Dimensional Print
MAG2IC	0410	MI 021-500	Flowmeter with Integrally Mounted Transmitter - Operation, Configuration, and Calibration
MAG2IC	0210	PL 008-750	Parts List
MAG2IC	0410	PSS 1-6G3 A	Product Specification Sheet

May 2010

Magnetic Flow Transmitters

Page 2 of 2

Product	Date	Doc. Num	Title or Description
MAG2RS	1208	DP 021-501	Dimensional Print
MAG2RS	0410	MI 021-500	Remote Mounted Flowtube - Operation, Configuration, and Calibration
MAG2RS	0210	PL 008-750	Parts List
MAG2RS	0410	PSS 1-6G3 A	Product Specification Sheet
MAG2RT	1208	DP 021-500	Dimensional Print
MAG2RT	0410	MI 021-500	Remote Mounted Transmitter - Operation, Configuration, and Calibration
MAG2RT	0210	PL 008-750	Parts List
MAG2RT	0410	PSS 1-6G3 A	Product Specification Sheet

Magnetic Flow Flowtubes

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters - 8000A, 8300, and 9300A
2800	0708	DP 021-120	Dimensional Print
2800	0193	DP 021-137	Dimensional Print
2800	0909	MI 021-120	Flowtubes, Installation
2800	0309	MI 021-137	Installation
2800	1195	MI 021-138	Fault Location Guide
2800	0309	MI 021-141	Sanitary pftc Line
2800	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
2800	0608	PL 008-541	Parts List 15 to 300 mm (12/ to 12 in) Sizes
2800	0608	PL 008-544	Parts List 350 to 900 mm (14 to 36 in) Sizes
2800	1209	PSS 1-6B5 A	Product Specification Sheet
2800	0608	PSS 1-6B5 C	Product Specification Sheet
2800	1208	PSS 1-6B5 E	Product Specification Sheet
2891	0608	PL 008-543	Parts List 2.5 mm (1/10 in) Size
2893	0608	PL 008-543	Parts List 6 mm (1/4 in) Size
4700S	0908	MI 021-323	Sanitary Flowtube - Installation
4700S	0604	MI 021-329	Supplemental Installation Instructions for Flowtube used in PMO, HTST Flowmeter Applications
4700S	1208	MI 021-414	Flowmeter Submersible Mounting Kit FDK-085U0220
4700S	0410	PSS 1-6G2 A	Product Specification Sheet
8000A	1107	DP 021-358	Dimensional Print
8000A	0109	MI 019-179	Flow Safety Information
8000A	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
8000A	0909	MI 021-380	Compact Magnetic Flowtubes - Installation
8000A	0808	PL 008-740	Parts List
8000A	0808	PSS 1-6F2 A	Product Specification Sheet
8000A	0608	PSS 1-6F2 C	Product Specification Sheet
8300	0708	DP 021-360	Dimensional Print Flanged
8300	0708	DP 021-361	Dimensional Print pftc-Lined Sanitary
8300	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
8300	0908	MI 021-381	Installation
8300	0808	PL 008-741	Parts List
8300	0608	PSS 1-6F2 B	Product Specification Sheet
8300	0608	PSS 1-6F2 C	Product Specification Sheet

May 2010

Magnetic Flow Flowtubes

Page 2 of 2

Product	Date	Doc. Num	Title or Description
9100A	0808	DP 021-368	Dimensional Print Flanged
9100A	0109	MI 019-179	Flow Safety Information
9100A	1008	MI 021-413	Flowtubes, Installation
9100A	0601	PL 008-748	Parts List
9100A	0609	PSS 1-6F9 A	Product Specification Sheet
9200A	0808	DP 021-368	Dimensional Print Flanged
9200A	0109	MI 019-179	Flow Safety Information
9200A	1008	MI 021-413	Flowtubes, Installation
9200A	0601	PL 008-748	Parts List
9200A	1208	PSS 1-6F10A	Product Specification Sheet
9300A	0902	DP 021-364	Dimensional Print
9300A	0109	MI 019-179	Flow Safety Information
9300A	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
9300A	1208	MI 021-386	Flanged Magnetic Flowtubes, pfa-, pft-, or Polyurethane-Lined, Installation
9300A	0808	PL 008-742	Parts List
9300A	0808	PSS 1-6F4 A	Product Specification Sheet

May 2010

Magnetic Flow Other

Product	Date	Doc. Num	Title or Description
	0808	TI 27-71f	Technical Information Material Selection Guide
	0906	TI 027-072	Technical Information Electrical Conductivity of Process Liquids
IMTSIM	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters
IMTSIM	1009	MI 021-392	Magnetic Flowtube Simulator
IMTSIM	1109	PSS 1-6F7 A	Product Specification Sheet

May 2010

Mass Flow Transmitter

Product	Date	Doc. Num	Title or Description
	0300	TI 001-053	Tutorial Percent Solids Calculation
CFT50	0709	B0800AH-C	Digital Coriolis Mass Flowmeters Installation Guidelines and Quick Start - HART
CFT50	0210	B0800AL-B	Digital Coriolis Mass Flowmeters Installation Guidelines and Quick Start - Modbus
CFT50	1203	MI 019-100	Universal Instruction Manual I/A Series Mass Flow Products
CFT50	0609	DP 019-375	Dimensional Print
CFT50	0506	MI 019-132	Digital Coriolis Transmitter with HART - Installation, Startup, Configuration, and Maintenance
CFT50	0409	MI 019-133	Safety Connection Diagrams (FM, CSA)
CFT50	0609	MI 019-134	Digital Coriolis Transmitter with Modbus - Installation, Startup, Configuration, and Maintenance
CFT50	0109	MI 019-179	Flow Safety Information
CFT50	0509	PL 008-704	Parts List
CFT50	0410	PSS 1-2B7 A	Product Specification Sheet

May 2010

Mass Flow Flowtubes

Product	Date	Doc. Num	Title or Description
CFS10	0802	DP 019-182	Dimensional Print 6-50 mm (1/4 to 2 inch)
CFS10	0998	DP 019-366	Dimensional Print 3 mm (1/8 inch)
CFS10	1203	MI 019-100	Universal Instruction Manual I/A Series Mass Flow Products
CFS10	0506	MI 019-120	Installation, Startup, Troubleshooting and Maintenance
CFS10	0109	MI 019-179	Flow Safety Information
CFS10	0608	PL 008-702	Parts List - Style A
CFS10	0506	PL 008-733	Parts List - Style B
CFS10	0909	PSS 1-2B1 A	Product Specification Sheet
CFS20	0802	DP 019-183	Dimensional Print
CFS20	1203	MI 019-100	Universal Instruction Manual I/A Series Mass Flow Products
CFS20	0506	MI 019-120	Installation, Startup, Troubleshooting and Maintenance
CFS20	0109	MI 019-179	Flow Safety Information
CFS20	0608	PL 008-703	Parts List - Style A
CFS20	0506	PL 008-735	Parts List - Style B
CFS20	0909	PSS 1-2B1 A	Product Specification Sheet

Product	Date	Doc. Num	Title or Description
	0309	MSDS 010	Recorders - Type 1800 Aqueous Recorder Ink
	0407	MSDS 011	Recorders - Non-Bleed Aqueous Recorder Ink Fiber Tip Cartridges
	0808	MSDS 021	Controllers - Nitrogen - N2 Liquefied Nitrogen N2 (Cryogenic)
	0808	MSDS 022	Controllers - Argon - Ar Liquefied Argon - Ar (Cryogenic)
	0908	MSDS 023	Controllers - Helium - He Liquefied Helium - He (Cryogenic)
0003093	1209	MSDS 049	Echem Sensors - Reference Electrode Solution - 4M Potassium Chloride Solution Plus Glycol
0016776	0407	MSDS 046	Controllers - Mercury
0016777	0407	MSDS 046	Controllers - Mercury
0017033	0407	MSDS 046	Controllers - Mercury
0046719	0309	MSDS 019	Controllers - Toluene
0046721	0407	MSDS 018	Controllers - Dithyl Ether
0046722	0407	MSDS 014	Controllers - Ethyl Alcohol
0048130	0309	MSDS 092	Pressure Transmitters - DC111 Valve Lubricant and Sealant
0048192	1209	MSDS 076	Temperature - Dewcel Solution - 5% Lithium Chloride Solution - 1 Ounce Bottle
0048860	0407	MSDS 099	Controllers - 4205 Prism Instant Adhesive Thermal Reistant Gel
1355061	1209	MSDS 051	Echem Sensors - Antimony pH Electrode Disk
1600585	0309	MSDS 140	Echem Sensors - Nyogel 761
A072203	0407	MSDS 032	Pressure Transmitters - DC704 Diffusion Pump Fluid Silicone
AS600AM	1209	MSDS 050	Echem Sensors - Glass pH Electrode Buffer Solution
B0134LM	0309	MSDS 031	Pressure Transmitters - DC200 Fluid 2 CST and 5 CST
B0139SL	1008	MSDS 029	Pressure Transmitters - FC-770 Fluorinert Electronic Liquid
B0158LY	1209	MSDS 049	Echem Sensors - Reference Electrode Solution - 4M Potassium Chloride Solution Plus Glycol
B0200EB	1209	MSDS 119	Echem Sensors - Dissolved Oxygen Electrolyte Solution 0.5M KCL
BS810YB	0708	MSDS 136	Echem Sensors - Internal Filling Solution
BS811GH	1209	MSDS 139	Echem Sensors - Reference Electrode Solution - 1M Potassium Chloride Solution Plus Glycol
C1000VY	0309	MSDS 103	Pressure Transmitters - DC200 Fluid 10 CST
D0114YC	0808	MSDS 034	Pressure Transmitters - DC200 Fluid, 500 CST - Silicone
D0116MP	0309	MSDS 043	Controllers - Ethylene Glycol
D0123MX	0407	MSDS 044	Controllers - Triethanolamine
D0129ZT	0908	MSDS 108	Controllers - High Intensity Nylon Wick Aqueous Recorder Ink
D0129ZU	0309	MSDS 024	Controllers - Nylon Wick 63 Aqueous Recorder Ink
D0129ZV	0309	MSDS 024	Controllers - Nylon Wick 63 Aqueous Recorder Ink
D0129ZW	0309	MSDS 024	Controllers - Nylon Wick 63 Aqueous Recorder Ink
F0109EH	0407	MSDS 120	Controllers - Moebius Oil Syntalube

Product	Date	Doc. Num	Title or Description
H0103AY	1209	MSDS 076	Temperature - Dewcel Solution - 5% Lithium Chloride Solution - 1 Pint Bottle
Q0104KE	0309	MSDS 053	Echem Sensors - 4 Molar Potassium Chloride Saturated with Silver Chloride
L0121CN	0908	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
L0121CS	0908	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
L0121CX	0908	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
L0121DC	0908	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
N1205BR	0407	MSDS 143	Pressure Transmitters - DC200 FLuid, Foodgrade, 350 CST - Silicone
N1206TZ	0309	MSDS 142	Pressure Seals - Neobee M-20
T0103RK	0407	MSDS 013	Controllers - sec-BUTYLBENZENE
T0103KR	0808	MSDS 015	Controllers - Propane
T0103KT	0309	MSDS 017	Controllers - Methyl Chloride
T0103PX	0808	MSDS 020	Controllers - Acetone
X0114AF	0309	MSDS 127	Pressure Transmitters - Key Abso-Lute (Oxygen Sealing Compound)
X0118CC	0309	MSDS 088	Pressure Transmitters - Lubriplate Aero
X0180AM	0908	MSDS 125	Pressure Transmitters - FC-43 Fluorinert Brand Electronic Liquid
X0180DE	0309	MSDS 126	Pressure Transmitters - DC200 Fluid 5 CST
X0180GS	0908	MSDS 144	Pressure Transmitters - F-900 Torque Seal (Red) Sealing Compount
X0180HB	0309	MSDS 137	Echem Analyzers - DC838 Silicone Adhesive/Sealant (Kit-AG100WH)
X0180HC	0309	MSDS 138	Echem Analyzers - Multiplurpose Alcohol Wipes (Kit-AG100WH)
X0180HK	0808	MSDS 141	Magnetic Flow Flowtubes - DC3-4207 Dielectric Tough Gel Part A and B

Pressure Transmitters d/p Cell

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0998	B0800AE	Ensuring Premium Performance with Foxboro Intelligent Level Transmitters
	0210	B0800AG	Pressure Transmitters - Getting Started
11DM	0304	PL 006-265	Parts List Styles C and D
13A	0499	MI 022-310	d/p Cell Installation and Operation
13A	0789	MI 022-345	Maintenance
13A	1005	PL 006-175	Parts List
13A	0110	PSS 2B-1C1 A	Product Specification Sheet
13H	0306	PL 006-177	Parts List
13HA	0110	PSS 2B-1C1 A	Product Specification Sheet
15A	0304	PL 006-176	Parts List Styles B-E
15A	0110	PSS 2B-1C1 A	Product Specification Sheet
CO	1107	DP 022-335	Dimensional Print
CO	1003	MI 022-335	Compact Orifice with d/p Cell Transmitters
CO	1003	PL 006-172	Parts List - Compact Orifice with d/p Cell Transmitters
CO	1007	PSS 3-5A1 E	Product Specification Sheet - Compact Orifice with d/p Cell Transmitters
IDP.-F	0605	MI 014-900	Fieldbus Overview
IDP10	0605	DP 020-446	Dimensional Print
IDP10	0609	MI 020-357	Functional Safety Manual
IDP10	0509	MI 020-358	Safety Information
IDP10	0509	MI 020-359	Universal Instruction Manual
IDP10	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IDP10	1209	PL 009-005	Parts List
IDP10	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IDP10-A	1007	MI IDP10-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA Output Signal)
IDP10-A	0310	PSS 2A-1C14 C	Product Specification Sheet
IDP10-D	1007	MI IDP10-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IDP10-D	0310	PSS 2A-1C14 A	Product Specification Sheet
IDP10-F	0608	MI IDP10-F	Installation, Calibration, Configuration and Maintenance (FOUNDATION Fieldbus Communication)
IDP10-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IDP10-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IDP10-T	0708	MI IDP10-T	Installation, Calibration, Configuration, and Maintenance (HART Communications)
IDP10-T	0310	PSS 2A-1C14 B	Product Specification Sheet
IDP10-V	1007	MI IDP10-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IDP10-V	0310	PSS 2A-1C13 D	Product Specification Sheet

Pressure Transmitters d/p Cell

Page 2 of 2

Product	Date	Doc. Num	Title or Description
IDP25	0605	DP 020-446	Dimensional Print
IDP25	0509	MI 020-358	Safety Information
IDP25	0509	MI 020-359	Universal Instruction Manual
IDP25	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IDP25	0110	PL 009-013	Parts List
IDP25	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IDP25-D	0410	MI IDP25-D/ IDP50-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IDP25-D	1209	PSS 2A-1C14 K	Product Specification Sheet
IDP25-F	0410	MI IDP25-F/ IDP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IDP25-F	1209	PSS 2A-1C14 K	Product Specification Sheet
IDP25-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IDP25-T	0410	MI IDP25-T/ IDP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IDP25-T	1209	PSS 2A-1C14 K	Product Specification Sheet
IDP50	0605	DP 020-446	Dimensional Print
IDP50	0509	MI 020-358	Safety Information
IDP50	0509	MI 020-359	Universal Instruction Manual
IDP50	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IDP50	0110	PL 009-014	Parts List
IDP50	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IDP50-D	0410	MI IDP25-D/ IDP50-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communications)
IDP50-D	1209	PSS 2A-1C14 L	Product Specification Sheet
IDP50-F	0410	MI IDP25-F/ IDP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IDP50-F	1209	PSS 2A-1C14 L	Product Specification Sheet
IDP50-T	0806	MI 020-366	I/A Series Pressure Transmitters with HART M275 Configurator
IDP50-T	0410	MI IDP25-T/ IDP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IDP50-T	1209	PSS 2A-1C14 L	Product Specification Sheet

Pressure Transmitters

Absolute/Gauge

Page 1 of 5

Product	Date	Doc. Num	Title or Description
	0998	B0800AE	Ensuring Premium Performance with Foxboro Intelligent Level Transmitters
	0210	B0800AG	Pressure Transmitters - Getting Started
11A	0701	PSS 2B-1A1 A	Product Specification Sheet
11AH	0304	PL 006-273	Parts List Styles C and D
11AL	0304	PL 006-272	Parts List Styles C and D
11AM	0304	PL 006-271	Parts List Styles D and E
11GH	0304	PL 006-267	Parts List Styles D and E
11GH	0999	PSS 2B-1A3 A	Product Specification Sheet
11GM	0499	MI 004-311	Removable Sealed Pressure
11GM	0499	MI 022-415	Pressure Transmitter Style C-D
11GM	0304	PL 006-266	Parts List
11GM	0999	PSS 2B-1A3 A	Product Specification Sheet
15F	0103	PL 006-179	Parts List
IAP.-F	0605	MI 014-900	Fieldbus Overview
IAP10	0599	DP 020-212	Dimensional Print Sanitary Gauge or Absolute Level 2-inch Tri-Clamp
IAP10	0705	DP 020-217	Dimensional Print Sanitary with Pulp and Paper Process Connections
IAP10	0403	DP 020-218	Dimensional Print Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IAP10	0403	DP 020-219	Dimensional Print Sanitary with Mini Tank Spud Seal
IAP10	0209	DP 020-447	Dimensional Print
IAP10	0609	MI 020-357	Functional Safety Manual
IAP10	0509	MI 020-358	Safety Information
IAP10	0509	MI 020-359	Universal Instruction Manual
IAP10	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IAP10	1209	PL 009-006	Parts List
IAP10	1209	PSS 2A-1C13 K	Product Specification Sheet - Sanitary Process Connections
IAP10	1209	PSS 2A-1C13 L	Product Specification Sheet - Process Connections for Pulp and Paper
IAP10	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IAP10-A	0309	MI IAP10-A/ IGP10-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IAP10-A	0409	PSS 2A-1C13 C	Product Specification Sheet
IAP10-D	0309	MI IAP10-D/ IGP10-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IAP10-D	0209	PSS 2A-1C13 A	Product Specification Sheet
IAP10-F	0309	MI IAP10-F/ IGP10-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IAP10-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IAP10-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IAP10-T	0309	MI IAP10-T/ IGP10-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)

Pressure Transmitters

Absolute/Gauge

Page 2 of 5

Product	Date	Doc. Num	Title or Description
IAP10-T	0110	PSS 2A-1C13 B	Product Specification Sheet
IAP10-V	0309	MI IAP10-V/ IGP10-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IAP10-V	0310	PSS 2A-1C13 D	Product Specification Sheet
IAP20	0705	DP 020-217	Dimensional Print Sanitary with Pulp and Paper Process Connections
IAP20	0403	DP 020-218	Dimensional Print Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IAP20	0403	DP 020-219	Dimensional Print Sanitary with Mini Tank Spud Seal
IAP20	0209	DP 020-447	Dimensional Print
IAP20	0609	MI 020-357	Functional Safety Manual
IAP20	0509	MI 020-358	Safety Information
IAP20	0509	MI 020-359	Universal Instruction Manual
IAP20	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IAP20	1209	PL 009-007	Parts List
IAP20	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IAP20-A	1007	MI IAP20-A/ IGP20-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IAP20-A	0409	PSS 2A-1C13 C	Product Specification Sheet
IAP20-D	1007	MI IAP20-D/ IGP20-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IAP20-D	0209	PSS 2A-1C13 A	Product Specification Sheet
IAP20-F	1007	MI IAP20-F/ IGP20-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communications)
IAP20-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IAP20-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IAP20-T	0708	MI IAP20-T/ IGP20-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IAP20-T	0110	PSS 2A-1C13 B	Product Specification Sheet
IAP20-V	1007	MI IAP20-V/ IGP20-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IAP20-V	0310	PSS 2A-1C13 D	Product Specification Sheet
IGP-F	0605	MI 014-900	Fieldbus Overview
IGP10	0599	DP 020-211	Dimensional Print Sanitary Gauge Pressure/Level 1 1/2-inch Tri-Clamp
IGP10	0599	DP 020-212	Dimensional Print Sanitary Gauge or Absolute Level 2-inch Tri-Clamp
IGP10	0599	DP 020-213	Dimensional Print Sanitary Gauge Pressure/Level 3-inch Tri-Clamp
IGP10	0599	DP 020-214	Dimensional Print Sanitary Gauge Pressure/Level Mini Tank Spud
IGP10	0599	DP 020-216	Dimensional Print Sanitary Gauge Pressure/Level Extended Mini Tank Spud

Pressure Transmitters

Absolute/Gauge

Page 3 of 5

Product	Date	Doc. Num	Title or Description
IGP10	0705	DP 020-217	Dimensional Print Sanitary with Pulp and Paper Process Connections
IGP10	0403	DP 020-218	Dimensional Print Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IGP10	0403	DP 020-219	Dimensional Print Sanitary with Mini Tank Spud Seal
IGP10	0208	DP 020-344	Dimensional Print High Gauge
IGP10	0209	DP 020-447	Dimensional Print
IGP10	0609	MI 020-357	Functional Safety Manual
IGP10	0509	MI 020-358	Safety Information
IGP10	0509	MI 020-359	Universal Instruction Manual
IGP10	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP10	1209	PL 009-006	Parts List
IGP10	1209	PL 009-010	Parts List - High Gauge
IGP10	1209	PSS 2A-1C13 F	Product Specification Sheet - for High Gauge
IGP10	1209	PSS 2A-1C13 K	Product Specification Sheet - Sanitary Process Connections
IGP10	1209	PSS 2A-1C13 L	Product Specification Sheet - Process Connections for Pulp and Paper
IGP10	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IGP10-A	0309	MI IAP10-A/ IGP10-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IGP10-A	0409	PSS 2A-1C13 C	Product Specification Sheet
IGP10-D	0309	MI IAP10-D/ IGP10-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP10-D	0209	PSS 2A-1C13 A	Product Specification Sheet
IGP10-F	0309	MI IAP10-F/ IGP10-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP10-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IGP10-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP10-T	0309	MI IAP10-T/ IGP10-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP10-T	0110	PSS 2A-1C13 B	Product Specification Sheet
IGP10-V	0309	MI IAP10-V/ IGP10-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IGP10-V	0310	PSS 2A-1C13 D	Product Specification Sheet
IGP20	0599	DP 020-211	Dimensional Print Sanitary Gauge Pressure/Level 1 1/2-inch Tri-Clamp
IGP20	0599	DP 020-212	Dimensional Print Sanitary Gauge or Absolute Pressure/Level 2-inch Tri-Clamp
IGP20	0599	DP 020-213	Dimensional Print Sanitary Gauge Pressure/Level 3-inch Tri-Clamp
IGP20	0599	DP 020-214	Dimensional Print Sanitary Gauge Pressure/Level Mini Tank Spud
IGP20	0599	DP 020-216	Dimensional Print Sanitary Gauge Pressure/Level Extended Mini Tank Spud

Pressure Transmitters

Absolute/Gauge

Page 4 of 5

Product	Date	Doc. Num	Title or Description
IGP20	0705	DP 020-217	Dimensional Print Sanitary with Pulp and Paper Process Connections
IGP20	0403	DP 020-218	Dimensional Print Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IGP20	0403	DP 020-219	Dimensional Print Sanitary with Mini Tank Spud Seal
IGP20	0209	DP 020-447	Dimensional Print
IGP20	0609	MI 020-357	Functional Safety Manual
IGP20	0509	MI 020-358	Safety Information
IGP20	0509	MI 020-359	Universal Instruction Manual
IGP20	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP20	1209	PL 009-007	Parts List
IGP20	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IGP20-A	1007	MI IAP20-A/ IGP20-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IGP20-A	0409	PSS 2A-1C13 C	Product Specification Sheet
IGP20-D	1007	MI IAP20-D/ IGP20-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP20-D	0209	PSS 2A-1C13 A	Product Specification Sheet
IGP20-F	1007	MI IAP20-F/ IGP20-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP20-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IGP20-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP20-T	0708	MI IAP20-T/ IGP20-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP20-T	0110	PSS 2A-1C13 B	Product Specification Sheet
IGP20-V	1007	MI IAP20-V/ IGP20-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IGP20-V	0310	PSS 2A-1C13 D	Product Specification Sheet
IGP25	0209	DP 020-447	Dimensional Print
IGP25	0509	MI 020-358	Safety Information
IGP25	0509	MI 020-359	Universal Instruction Manual
IGP25	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP25	0110	PL 009-011	Parts List
IGP25	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IGP25-D	0410	MI IGP25-D/ IGP50-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP25-D	1209	PSS 2A-1C13 G	Product Specification Sheet
IGP25-D	1209	PSS 2A-1C13 M	Product Specification Sheet - with Sanitary Process Connections
IGP25-D	1209	PSS 2A-1C13 N	Product Specification Sheet - with Pulp and Paper Process Connections

Pressure Transmitters Absolute/Gauge

Page 5 of 5

Product	Date	Doc. Num	Title or Description
IGP25-F	0410	MI IGP25-F/ IGP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP25-F	1209	PSS 2A-1C13 G	Product Specification Sheet
IGP25-F	1209	PSS 2A-1C13 M	Product Specification Sheet - with Sanitary Process Connections
IGP25-F	1209	PSS 2A-1C13 N	Product Specification Sheet - with Pulp and Paper Process Connections
IGP25-T	0410	MI IGP25-T/ IGP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP25-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP25-T	1209	PSS 2A-1C13 G	Product Specification Sheet
IGP25-T	1209	PSS 2A-1C13 M	Product Specification Sheet - with Sanitary Process Connections
IGP25-T	1209	PSS 2A-1C13 N	Product Specification Sheet - with Pulp and Paper Process Connections
IGP50	0209	DP 020-447	Dimensional Print
IGP50	0509	MI 020-358	Safety Information
IGP50	0509	MI 020-359	Universal Instruction Manual
IGP50	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP50	0110	PL 009-012	Parts List
IGP50	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IGP50-D	0410	MI IGP25-D/ IGP50-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP50-D	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP50-D	1209	PSS 2A-1C13 H	Product Specification Sheet
IGP50-F	0410	MI IGP25-F/ IGP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP50-F	1209	PSS 2A-1C13 H	Product Specification Sheet
IGP50-T	0410	MI IGP25-T/ IGP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP50-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP50-T	1209	PSS 2A-1C13 H	Product Specification Sheet

Pressure Transmitters

Pressure Seals

Product	Date	Doc. Num	Title or Description
PSFAD	1101	DP 020-346	Dimensional Print
PSFAD	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFAD	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSFAR	1101	DP 020-345	Dimensional Print
PSFAR	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFAR	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSFES	1101	DP 020-343	Dimensional Print
PSFES	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFES	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSFLT	1101	DP 020-342	Dimensional Print
PSFLT	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFLT	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSFPS	1101	DP 020-343	Dimensional Print
PSFPS	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFPS	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSISD	1101	DP 020-350	Dimensional Print
PSISD	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSISD	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSISR	1101	DP 020-349	Dimensional Print
PSISR	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSISR	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSSCR	1101	DP 020-351	Dimensional Print
PSSCR	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSSCR	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSSCT	0403	DP 020-355	Dimensional Print
PSSCT	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSSCT	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSSSR	0705	DP 020-353	Dimensional Print
PSSSR	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSSSR	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSSST	0705	DP 020-354	Dimensional Print
PSSST	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSSST	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSTAD	1101	DP 020-348	Dimensional Print
PSTAD	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSTAD	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSTAR	1101	DP 020-347	Dimensional Print
PSTAR	0307	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSTAR	0209	PSS 2A-1Z11 A	Product Specification Sheet

May 2010

Pressure Transmitters Pneumatic-to-Current Converters

Product	Date	Doc. Num	Title or Description
IPI10-A	1299	DP 020-414	Dimensional Print
IPI10-A	0100	MI 020-414	Installation, Calibration, Configuration, and Maintenance
IPI10-A	0100	PL 009-144	Parts List - Pneumatic-to-Current Converter
IPI10-A	0100	PSS 2A-2A4 A	IPI10 Series Pneumatic-to-Current Converter
IPI10-I	1299	DP 020-414	Dimensional Print
IPI10-I	0100	MI 020-414	Installation, Calibration, Configuration, and Maintenance
IPI10-I	0100	PL 009-144	Parts List - Pneumatic-to-Current Converter
IPI10-I	0100	PSS 2A-2A4 A	IPI10 Series Pneumatic-to-Current Converter

Pressure Transmitters

Multivariable

Product	Date	Doc. Num	Title or Description
IMV25	0605	DP 020-432	Dimensional Print
IMV25	0806	MI 020-358	Safety Information
IMV25	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IMV25-D	0408	MI 020-432	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA FoxCom)
IMV25-D	0408	PL 009-019	Parts List
IMV25-D	0408	PSS 2A-1C15 B	Product Specification Sheet
IMV25-M	0308	MI 020-384	Installation, Calibration, Configuration, and Maintenance (Modbus Communications and PCMM Field Device Configurator)
IMV25-M	0408	PL 009-019	Parts List
IMV25-M	1009	PSS 2A-1C15 D	Product Specification Sheet
IMV25-T	0308	MI 020-382	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA HART)
IMV25-T	0408	PL 009-019	Parts List
IMV25-T	0408	PSS 2A-1C15 B	Product Specification Sheet
IMV30	0605	DP 020-432	Dimensional Print
IMV30	0806	MI 020-358	Safety Information
IMV30	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IMV30-D	0408	MI 020-432	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA FoxCom)
IMV30-D	0907	PL 009-018	Parts List
IMV30-D	0709	PSS 2A-1C15 A	Product Specification Sheet
IMV30-T	0308	MI 020-382	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA HART)
IMV30-T	0907	PL 009-018	Parts List
IMV30-T	0709	PSS 2A-1C15 A	Product Specification Sheet
IMV31	0605	DP 020-432	Dimensional Print
IMV31	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IMV31-T	0809	MI 020-383	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA HART)
IMV31-T	0809	PL 009-020	Parts List
IMV31-T	0809	PSS 2A-1C15 C	Product Specification Sheet

Pressure Transmitters

Other

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0988	MI 020-328	Bubble Tube Installation for Measurement
	0799	MI 020-360	Wiring Guidelines for Foundation Fieldbus Transmitters
	0809	MI 022-138	1-, 2-, 3-, and 5-Valve Manifolds For Use With I/A Series Pressure Transmitter Family
	0501	PSS 3-2A1 A	Product Specification Sheet - Pressure and Receiver Elements
	1299	PSS 3-2C1 A	Product Specification Sheet - Pressure Seals
	1186	TI 37-75b	Technical Information - Material Selection Guide
	0109	TI 037-097	Technical Information - Process Sealing of Transmitters for use in Class I, Zone 0, 1, and 2 Hazardous Locations
13DEMP	0103	PL 006-180	Parts List - Transmitter with Matched Extended Pressure Seals
13DMP	0103	PL 006-180	Parts List - Transmitter with Matched Pressure Seals
13F	0209	PL 006-178	Parts List - Liquid Level or Density Styles C and D
13FE	0209	PL 006-178	Parts List - Liquid Level or Density Styles E and F
D0170MB thru MJ	0598	MI 020-412	Mounting Hardware Kits to Replace 823DP, 843DP and 863DP with IDP10
HHT	0197	MI 020-400	Pocket Guide with I/A Series Pressure Transmitters
MB3	0809	DP 022-148	Dimensional Print - 3-Valve Manifolds
MB3	0809	PL 006-152	Parts List - 3-Valve Manifold
MB3	0809	PSS 2B-1Z2 A	Product Specification Sheet - 3-Valve Manifolds
MB5G	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
MB5G	0809	PL 006-152	Parts List - 5-Valve Manifold
MB5G	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
MB5P	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
MB5P	0809	PL 006-152	Parts List - 5-Valve Manifold
MB5P	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
MH	1002	PL 002-101	Parts List - Pressure Gauges
M4A	0809	DP 022-148	Dimensional Print - 3-Valve Manifold
M4A	0809	PL 006-152	Parts List - 3-Valve Manifold
M4A	0809	PSS 2B-1Z2 A	Product Specification Sheet - 3-Valve Manifolds
M4AP	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
M4AP	0809	PL 006-152	Parts List - 2-Valve Manifold
M4AP	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds

Pressure Transmitters

Other

Page 2 of 2

Product	Date	Doc. Num	Title or Description
M4T	0809	DP 022-148	Dimensional Print - 3-Valve Manifold
M4T	0809	PL 006-152	Parts List - 3-Valve Manifold
M4T	0809	PSS 2B-1Z2 A	Product Specification Sheet - 3-Valve Manifolds
M4TP	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
M4TP	0809	PL 006-152	Parts List - 2-Valve Manifold
M4TP	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds
M6T	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
M6T	0809	PL 006-152	Parts List - 5-Valve Manifold
M6T	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
M6TA	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
M6TA	0809	PL 006-152	Parts List - 5-Valve Manifold
M6TA	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
M9	0208	DP 022-146	Dimensional Print - 1-Valve Manifold (Block and Bleed Valve)
M9	0809	PL 006-152	Parts List - 1-Valve Manifold (Block and Bleed Valve)
M9	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds
M24A	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
M24A	0809	PL 006-152	Parts List - 5-Valve Manifold
M24A	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
M24T	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
M24T	0609	PL 006-152	Parts List - 5-Valve Manifold
M24T	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
M25	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
M25	0809	PL 006-152	Parts List - 2-Valve Manifold
M25	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds
PTM	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
PTM	0809	PL 006-152	Parts List - 2-Valve Manifold
PTM	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds
PT7	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
PT7	0809	PL 006-152	Parts List - 2-Valve Manifold
PT7	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds

Product	Date	Doc. Num	Title or Description
	0801	B0193XX	Field Device Integration Checklist
HHT50	0108	MI 020-500	Configurator for use with Intelligent Field Devices
HHT50	1008	PL009-154	Parts List - use with Intelligent Field Devices
HHT50	0209	PSS 2A-1Z3 L	Product Specification Sheet - use with Intelligent Field Devices
PC20	1102	MI 020-495	Intelligent Field Device Configurator
PC20	1102	PL 009-156	Parts List
PC20	1102	PSS 2A-1Z3 E	Product Specification Sheet
PC50	0108	MI 020-501	Field Device Tool - Installation and Parts List
PC50	0809	MI 020-504	Field Device Tool - Operation Using FoxCom Communication Protocol
PC50	0208	MI 020-505	Field Device Tool - Operation Using HART Communication Protocol
PC50	0410	MI 020-520	Field Device Tool with Advanced DTM Library - Operation Using HART Communication Protocol
PC50	0209	PSS 2A-1Z3 G	Product Specification Sheet
PCMM	0308	MI 020-384	Installation, Calibration, Configuration, and Maintenance (Used with IMV25-M Modbus Communications)
PCMM	1104	PL 009-158	Parts List - used with IMV225-M
PCMM	1004	PSS 2A-1Z3 H	Product Specification Sheet- used with IMV25-M
PCMV	1104	MI 020-496	Intelligent Field Device Configurator for IMV25 and IMV30 Multivariable Transmitters
PCMV	0809	MI 020-497	Intelligent Field Device Configurator for IMV31 Multivariable Transmitters
PCMV	0904	PL 009-157	Parts List - used with IMV25, IMV30 and IMV31
PCMV	1108	PSS 2A-1Z3 F	Product Specification Sheet - used with IMV25, IMV30 and IMV31

Product	Date	Doc. Num	Title or Description
12A	0606	PL 006-330	Parts List
12A	0201	PSS 2B-1B1 A	Product Specification Sheet
MT	0207	DP 016-130	Dimensional Print
MT	0909	MI 016-128	MINOX Thermocouples Style B
MT	0207	PL 008-108	Parts List
MT	0909	PSS 1-1B6 A	Product Specification Sheet
PR	0207	DP 016-131	Dimensional Print
PR	0909	MI 016-131	Platinum Resistance Temperature Detectors (RTD) Style C
PR	0207	PL 008-111	Parts List
PR	0909	PSS 1-1B1 A	Product Specification Sheet
RTT15	0108	DP 020-462	Dimensional Print
RTT15	0607	MI 020-449	Intrinsic Safety Connection Diagrams
RTT15-F	0707	MI 020-462	Temperature Transmitter with FOUNDATION Fieldbus Protocol
RTT15-F	0908	PL 008-662	Parts List
RTT15-F	0709	PSS 2A-1F5 A	Product Specification Sheet
RTT15-P	0707	MI 020-462	Temperature Transmitter with PROFIBUS Protocol
RTT15-P	0908	PL 008-662	Parts List
RTT15-P	0709	PSS 2A-1F5 A	Product Specification Sheet
RTT15-T	0108	MI 020-463	Temperature Transmitter with HART Protocol
RTT15-T	0908	PL 008-662	Parts List
RTT15-T	0709	PSS 2A-1F5 A	Product Specification Sheet
RTT20	0108	DP 020-460	Dimensional Print
RTT20	0408	MI 020-453	Installation, Calibration, Configuration, and Maintenance
RTT20	0399	MI 020-454	Intrinsic Safety
RTT20	1096	MI 020-460	Operation, Configuration, and Calibration using HART M275 Configurator
RTT20	0596	MI 020-461	Configuration Menu Flowchart for 1-Line LCD Indicator
RTT20	0398	MI 020-469	Operation, Calibration, and Configuration Using HHT
RTT20	0509	PL 008-659	Parts List
RTT20	0408	PSS 2A-1F4 A	Product Specification Sheet
RTT20	0701	PSS 2A-1Z9 F	Product Specification Sheet Options
RTT25-F	0108	DP 020-461	Dimensional Print
RTT25-F	0605	MI 014-900	Fieldbus Overview
RTT25-F	0207	MI 020-488	Installation, Calibration, Local/Remote Configuration and Maintenance
RTT25-F	0310	PL 008-661	Parts List
RTT25-F	0210	PSS 2A-1F4 C	Product Specification Sheet
RTT25-F	0701	PSS 2A-1Z9 F	Product Specification Sheet
RTT30	0110	DP 020-530	Dimensional Print
RTT30	0310	MI 020-530	Temperature Transmitter with HART Protocol
RTT30	0310	MI 020-531	Temperature Transmitter Safety Information
RTT30	0110	MI RTT30	FM and CSA Safety Drawings
RTT30-A	0310	PSS 2A-1F6 A	Product Specification Sheet - HART Communications
RTT30-F	0410	PSS 2A-1F6 B	Product Specification Sheet - FOUNDATION Fieldbus Communications

May 2010

Temperature Thermowells

Product	Date	Doc. Num	Title or Description
TF	0307	DP 002-110	Dimensional Print - Flanged Thermowells
TF	1008	PSS 3-3D1 A	Product Specification Sheet - Flanged Thermowells
TS	0307	DP 002-111	Dimensional Print - Sanitary Thermowells
TS	1008	PSS 3-3D1 A	Product Specification Sheet - Sanitary Thermowells
TT	0307	DP 002-112	Dimensional Print - Threaded Thermowells
TT	1008	PSS 3-3D1 A	Product Specification Sheet - Threaded Thermowells
TW	0307	DP 002-113	Dimensional Print - Weld-In Thermowells
TW	1008	PSS 3-3D1 A	Product Specification Sheet - Weld-In Thermowells

Product	Date	Doc. Num	Title or Description
83	0409	B0800AB	Ensuring Premium Performance with Foxboro Intelligent Vortex Flowmeters
83	0908	MI 019-191	Amplifier Replacement for Conventional and Intelligent Vortex Flowmeters
83	0109	MI 019-179	Flow Safety Information
83	0403	MI 019-188	Conversion from Analog, FoxCom, or HART to FOUNDATION Fieldbus - Kit Numbers K0147VN and K0148VN
83	0205	MI 019-198	Addition or Replacement of Digital Display/Configurator Kits K0147EK, K0147HT , and K0147HU
83	0410	MI 019-209	Sensor Replacement Kits
83.-D	1000	MI 019-175	Intrinsic Safety Connection Diagrams
83.-F	0605	MI 014-900	Fieldbus Overview
83.-T	1000	MI 019-175	Intrinsic Safety Connection Diagrams
83F	0309	DP 019-150	Dimensional Print for Single Measurement Configuration
83F	0309	DP 019-151	Dimensional Print for Dual Measurement Configuration
83F	0607	MI 019-145	Universal Instruction Manual - Installation and Startup
83F	0297	MI 019-197	Convert Integral to Remote
83F-A	0596	MI 019-152	European Installations
83F-A	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
83F-A	0608	PL 008-708	Parts List
83F-A	0608	PSS 1-8A1 D	Product Specification Sheet
83F-D	0496	MI 019-153	European Installations
83F-D	0507	MI 019-194	Installation, Configuration, Troubleshooting, and Maintenance
83F-D	0608	PL 008-708	Parts List
83F-D	0608	PSS 1-8A1 E	Product Specification Sheet
83F-F	0907	MI 019-193	Flowmeters with FOUNDATION Fieldbus
83F-F	0608	PL 008-708	Parts List
83F-F	0608	PSS 1-8A1 F	Product Specification Sheet
83F-T	0397	MI 019-154	European Installations
83F-T	0507	MI 019-199	Installation, Configuration, Troubleshooting, and Maintenance
83F-T	0608	PL 008-708	Parts List
83F-T	0608	PSS 1-8A1 E	Product Specification Sheet
83S	0197	DP 019-154	Dimensional Print Sanitary
83S	0607	MI 019-145	Universal Instruction Manual - Installation and Startup
83S-A	0507	MI 019-173	Sanitary Installation, Troubleshooting, and Maintenance
83S-A	0297	PL 008-713	Parts List
83S-A	0409	PSS 1-8A2 E	Product Specification Sheet
83S-D	0507	MI 019-195	Sanitary Installation, Configuration, Troubleshooting, and Maintenance
83S-D	0205	MI 019-198	Addition of Digital Display and Configuration
83S-D	0297	PL 008-713	Parts List
83S-D	0409	PSS 1-8A2 D	Product Specification Sheet

Product	Date	Doc. Num	Title or Description
83S-T	0507	MI 019-174	Sanitary Installation, Troubleshooting, and Maintenance
83S-T	0297	PL 008-713	Parts List
83S-T	0409	PSS 1-8A2 D	Product Specification Sheet
83W	0702	DP 019-152	Dimensional Print Wafer Body
83W	0607	MI 019-145	Universal Instruction Manual - Installation and Startup
83W	0297	MI 019-197	Convert Integral to Remote
83W-A	0596	MI 019-152	European Installations
83W-A	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
83W-A	0107	PL 008-708	Installation, Troubleshooting, and Maintenance
83W-A	0700	PL 008-709	Parts List
83W-A	0608	PSS 1-8A1 D	Product Specification Sheet
83W-D	0496	MI 019-153	European Installations
83W-D	0507	MI 019-194	Installation, Configuration, Troubleshooting, and Maintenance
83W-D	0205	MI 019-198	Addition of Digital Display and Configuration
83W-D	0700	PL 008-709	Parts List
83W-D	0608	PSS 1-8A1 E	Product Specification Sheet
83W-F	0907	MI 019-193	Flowmeters with FOUNDATION Fieldbus
83W-F	0700	PL 008-709	Parts List
83W-F	0608	PSS 1-8A1 F	Product Specification Sheet
83W-T	0397	MI 019-154	European Installations
83W-T	0507	MI 019-199	Installation, Configuration, Troubleshooting, and Maintenance
83W-T	0700	PL 008-709	Parts List
83W-T	0608	PSS 1-8A1 E	Product Specification Sheet
84	0310	B0800AJ	Ensuring Premium Performance with Foxboro Intelligent Vortex Flowmeters
84	0410	MI 019-146	Universal Instruction Manual - Installation and Startup
84	1107	MI 019-177	FM and CSA Certification Connection Diagrams
84	0109	MI 019-179	Flow Safety Information
84	0410	MI 019-209	Sensor Replacement Kits
84F	0309	DP 019-120	Dimensional Print for Single Measurement Configuration
84F	0309	DP 019-121	Dimensional Print for Dual Measurement Configuration
84F	1209	PSS 1-8A3 A	Product Specification Sheet
84F-L	0410	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84F-L	0410	PL 008-714	Parts List - Low Power with Pulse Output
84F-L	0110	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, Pulse Output, with HART
84F-M	0410	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84F-M	0410	PL 008-714	Parts List - Low Power without Pulse Output
84F-M	0110	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, with HART
84F-T	0410	MI 019-202	with HART - Installation, Operation, and Maintenance
84F-T	0410	PL 008-714	Parts List - with Pulse Output
84F-U	0410	MI 019-202	with HART - Installation, Operation, and Maintenance
84F-U	0410	PL 008-714	Parts List - without Pulse Output

Product	Date	Doc. Num	Title or Description
84S	1006	DP 019-123	Dimensional Print Sanitary
84S	0409	PSS 1-8A5 A	Product Specification Sheet
84S-L	0410	MI 019-214	Low Power with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-L	0410	PL 008-717	Parts List - Low Power with Pulse Output
84S-L	0110	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, Pulse Output, with HART
84S-M	0410	MI 019-214	Low Power with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-M	0410	PL 008-717	Parts List - Low Power without Pulse Output
84S-M	0110	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, with HART
84S-T	0410	MI 019-205	with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-T	0410	PL 008-717	Parts List - with Pulse Output
84S-U	0410	MI 019-205	with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-U	0410	PL 008-717	Parts List - without Pulse Output
84W	1006	DP 019-122	Dimensional Print Wafer Body
84W	1209	PSS 1-8A3 A	Product Specification Sheet
84W-L	0410	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84W-L	0410	PL 008-714	Parts List - Low Power with Pulse Output
84W-L	0110	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, Pulse Output, with HART
84W-M	0410	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84W-M	0410	PL 008-714	Parts List - Low Power without Pulse Output
84W-M	0110	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, with HART
84W-T	0410	MI 019-202	with HART - Installation, Operation, and Maintenance
84W-T	0410	PL 008-714	Parts List - with Pulse Output
84W-U	0410	MI 019-202	with HART - Installation, Operation, and Maintenance
84W-U	0410	PL 008-714	Parts List - without Pulse Output
E83	0908	MI 019-191	Amplifier Replacement for Conventional and Intelligent Vortex Flowmeters
E83F	0398	MI 019-166	Sensor/Amplifier Replacement
E83FA	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
E83FA	0297	MI 019-196	Convert to 83F-D, 83S-D, or 83W-D Style A
E83L	0398	MI 019-166	Sensor/Amplifier Replacement
E83SA	0297	MI 019-196	Convert to 83F-D, 83S-D, or 83W-D Style A
E83W	0398	MI 019-166	Sensor/Amplifier Replacement
E83WA	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
E83WA	0297	MI 019-196	Convert to 83F-D, 83S-D, or 83W-D Style A

May 2010

Other Totalizer and Flow Computer

Product	Date	Doc. Num	Title or Description
75LBA	1193	DP 019-543	Dimensional Print
75LBA	0298	MI 019-589	Pulse Input Liquid Batch Totalizer
75LBA	0398	MI 019-590	Analog Input Liquid Batch Totalizer
75LBA	1193	PL 008-727	Parts List
75LBA	1093	PSS 1-9C1 A	Product Specification Sheet
75MCA	0794	DP 019-542	Dimensional Print
75MCA	0398	MI 019-591	Pulse Input Liquid Mass Computer
75MCA	0498	MI 019-592	Analog Input Liquid Mass Computer
75MCA	0598	MI 019-594	Pulse Input Gas/Steam Mass Computer
75MCA	0598	MI 019-595	Analog Input Gas/Steam Mass Computer
75MCA	0794	PL 008-728	Parts List
75MCA	0397	PSS 1-9D1 A	Product Specification Sheet
75RTA	0794	DP 019-542	Dimensional Print
75RTA	0298	MI 019-587	Pulse Input Ratemeter Totalizer
75RTA	0298	MI 019-588	Analog Input Ratemeter Totalizer
75RTA	0393	PSS 1-9B1 A	Product Specification Sheet

May 2010

Other Positioners and I/P Converters

Product	Date	Doc. Num	Title or Description
E69F	0506	DP 018-430	Dimensional Print
E69F	0605	MI 018-429	Current-to-Pneumatic Converter - Safety Information
E69F	0605	MI 018-430	Current-to-Pneumatic Converter - Field Mounted
E69F	0906	PL 008-645	Parts List
E69F	0906	PSS 2B-2A3 B	Product Specification Sheet
E69P	0506	DP 018-440	Dimensional Print
E69P	0605	MI 018-429	Current-to-Pneumatic Valve Positioner - Safety Information
E69P	0185	MI 018-440	Current-to-Pneumatic Valve Positioner
E69P	0802	PL 008-647	Parts List
E69P	0506	PSS 4-10A2 A	Product Specification Sheet
E69R	0802	PL 008-646	Parts List
E69R	0407	PSS 2B-2A2 A	Product Specification Sheet
P91PA	0504	PL 005-365	Parts List - Poweractor
P91T	0706	DP 014-132	Dimensional Print
P91T	0802	MI 014-132	Type CP Pneumatic Position Transmitter
P91T	0802	PL 006-320	Parts List
P91T	0104	PSS 2B-1B1 B	Product Specification Sheet
P91V	0802	DP 012-340	Dimensional Print
P91V	0802	MI 012-340	Type C Vernier VALVACTOR - Yoke Mounted
P91V	0802	PL 005-320	Parts List

Other Miscellaneous

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0408	DP 000-001	Dimensional Print Manual 190 Table of Contents
	0408	DP 000-002	Dimensional print Manual 190 Index by Model
	0408	MI 000-001	Master Book 100 Table of Contents
	0408	MI 000-002	Master Book 100 Index by Model
	0902	MI 014-101	Sulfur Detection Using Lead Acetate Test Paper
	0408	PL 000-001	Master Book 150 Table of Contents
	0408	PL 000-002	Master Book 150 Index by Model
	0903	PL 001-110	Chart Drives - Parts List
	0809	PSS 0-0A0 A	Product Specification Manual 010 Table of Contents
	0809	PSS 0-0A0 B	Product Specification Manual 010 Index by Model
	1008	TI 037-094	Quality Assurance Certificates for Non-Nuclear Parts and Products
B0110AS	0506	PL 005-420	Parts Lists - Air Filter Set
B0110AT	0506	PL 005-420	Parts Lists - Air Filter Set
B0110ZA	0506	PL 005-420	Parts Lists - Air Filter Set
B0123HE	0506	PL 005-420	Parts Lists - Adjustable Pressure Regulator with Filter
B0123HF	0506	PL 005-420	Parts Lists - Adjustable Pressure Regulator without Filter
B0197BA	0506	PL 005-420	Parts Lists - Air Filter Assembly
B1278HE	0506	DP 011-159	Dimensional Print - Adjustable Pressure Regulator
B1278HE	0506	PL 005-420	Parts Lists - Adjustable Pressure Regulator
CO	1107	DP 022-335	Dimensional Print - Compact Orifice with d/p Cell Transmitters
CO	1003	MI 022-335	Compact Orifice with d/p Cell Transmitters
CO	1003	PL 006-172	Parts List - Compact Orifice with d/p Cell Transmitters
CO	1003	PSS 3-5A1 E	Product Specification Sheet - Compact Orifice with d/p Cell Transmitters
IFOA	0707	MI 022-333	Integral Flow Orifice Assembly
IFOA	0607	PL 006-174	Parts List - Integral Flow Orifice Assembly
IFOA	0609	PSS 3-5A1 B	Integral Flow Orifice Assembly used with d/p Cell Transmitter
MAC	0802	PL 005-356	Air Cylinders - Parts List
PF100AX	1003	MI 018-180	75 V dc Multiloop Power Supply
P0300CQ	1003	MI 018-180	75 V dc Multiloop Power Supply
14A	0110	PL 003-525	Pneumatic Flow Integrator - Parts List
17BS	1205	PL 006-318	Side Mounted Buoyancy Transmitter - Parts List
17BT	1205	PL 006-318	Top Mounted Buoyancy Transmitter - Parts List
556	0410	MI 017-284	Pneumatic Analog Computer - Maintenance and Servicing
556	1105	PL 006-345	Pneumatic Analog Computer - Parts List
557	0108	PL 006-346	Pneumatic Square Root Extractor - Parts List

May 2010

Other Miscellaneous

Page 2 of 2

Product	Date	Doc. Num	Title or Description
2761	0908	PL 008-102	Mechanical DEWCEL - Parts List
2761	0908	PSS 1-5A1 A	Mechanical DEWCEL - Product Specification Sheet
2781	0908	DP 008-103	Electrical DEWCEL Element - Dimensional Print
2781	0908	MI 003-318	Dew Point Measurement with DEWCEL Element - Electrical Temperature Measurement
2781	0908	PL 008-102	Electrical DEWCEL, Basic Sensor - Parts List
2781	0908	PSS 1-5A1 A	Electrical DWECCEL - Product Specification Sheet