

Controllers, Indicators, and Recorders

Controllers

Page 1 of 2

Product	Date	Doc. Num	Title or Description
37	0108	PL 003-320	Parts List - Diaphragm Meter With Intermediate Linkage
37	0403	PSS 3-4A2 A	Product Specification Sheet - Diaphragm Measuring Element
40	0702	PL 001-105	Parts List - Box Pens, Pen-Arms, Indexes for Instruments
40	0702	PL 001-345	Parts List - Indicating Scale and Light Assemblies for Instruments
40M	0702	PL 001-105	Parts List - Box Pens, Pen-Arms, Indexes for Instruments
40M	0702	PL 001-345	Parts List - Indicating Scale and Light Assemblies for Instruments
40M	0410	PL 004-111	Parts List - On-Off or Narrow Band Proportional Types
40M	0410	PL 004-116	Parts List - On-Off or Narrow Band Proportional Types
40M	0410	PL 004-121	Parts List - Dual or Duplex, On-Off or Narrow Band Types
40M	0410	PL 004-126	Parts List - Dual or Duplex Proportional Types
40M	0402	PSS 3-1A1 A	Product Specification Sheet
40P	0702	PL 001-105	Parts List - Box Pens, Pen-Arms, Indexes for Instruments
40P	0702	PL 001-345	Parts List - Indicating Scale and Light Assemblies for Instruments
40P	0410	PL 004-111	Parts List - On-Off or Narrow Band Proportional Types
40P	0410	PL 004-116	Parts List - On-Off or Narrow Band Proportional Types
40P	0410	PL 004-121	Parts List - Dual or Duplex, On-Off or Narrow Band Types
40P	0410	PL 004-126	Parts List - Dual or Duplex Proportional Types
40P	0403	PSS 3-1A2 A	Product Specification Sheet - Pressure Recorders, Indicators, and Recording or Indicating Controllers
40P	0201	PSS 3-1A2 B	Product Specification Sheet - Temperature Recorders, Indicators, and Recording or Indicating Controllers
40P	0403	PSS 3-1A2 C	Product Specification Sheet - Flow Recorders, Indicators, and Controllers
43AP	0306	DP 011-476	Dimensional Print
43AP	0180	MI 011-476	Installation and Operation
43AP	0486	MI 011-477	Servicing
43AP	0486	MI 011-481	Maintenance and Alignment
43AP	0209	PL 004-484	Parts List
43AP	1210	PSS 3-1B3 A	Product Specification Sheet- Pneumatic Indicating Controllers
43AP	0101	PSS 3-1B3 B	Product Specification Sheet - Controllers for Electronic Inputs
43APG	0609	PL 004-494	Parts List
130	0603	PL 004-560	Parts List - Automatic Control Section for Controllers
130M	0806	DP 017-450	Dimensional Print
130M	0578	MI 017-450	Installation and Maintenance
130M	0179	PL 004-550	Parts List
130M	0495	PSS 2B-4H1 A	Product Specification Sheet
138	0101	PSS 2B-4H1 M	Product Specification Sheet
716C	1196	DP 018-575	Dimensional Print
716C	0297	MI 018-575	1/6 DIN Temperature
716C	0597	MI 018-579	1/16 DIN and 1/8 DIN Temperature Serial Communications Guide
716C	1196	PSS 2C-1B5 A	Product Specification Sheet

Controllers, Indicators, and Recorders

Controllers

Page 2 of 2

Product	Date	Doc. Num	Title or Description
718P	1196	DP 018-574	Dimensional Print
718P	0297	MI 018-574	1/8 DIN Temperature with Series Interface
718P	0597	MI 018-578	1/8 DIN Process Serial Communications Guide
718P	1196	PSS 2C-1B4 A	Product Specification Sheet
718TC	1196	DP 018-572	Dimensional Print
718TC	0297	MI 018-573	1/8 DIN Temperature with mA Output
718TC	0597	MI 018-579	1/16 DIN and 1/8 DIN Temperature Serial Communications Guide
718TC	1196	PSS 2C-1B3 A	Product Specification Sheet
740C	0905	MI 018-871	Digital Circular Chart Recorder and Recording Controller - Installation, Operation, Configuration, and Maintenance
740C	1005	PL 009-166	Parts List
740C	1005	PSS 2C-1A7 A	Product Specification Sheet
762	0398	MI 018-888	Serial Communications Guide
762	0895	TI 039-200	Technical Information
762C	0696	PSS 2C-1A1 D	Product Specification Sheet
762CNA	0906	DP 018-836	Dimensional Print
762CNA	0298	MI 018-885	SINGLE STATION MICRO
762CNA	0499	PL 009-136	Parts List
762CSA	0298	MI 018-889	Shelf Mounted
762CSA	1210	PL 009-139	Parts List

April 2011

Controllers, Indicators, and Recorders Indicators

Product	Date	Doc. Num	Title or Description
45P	1210	PSS 2B-1H1 E	Product Specification Sheet
65FS	1006	MI 018-272	Field Mounted
65FS	0210	PL 008-559	Parts List
65FS	0210	PSS 2A-3B1 C	Product Specification Sheet
65P	0101	PSS 2A-3B1 A	Product Specification Sheet
710D	1196	DP 018-571	Dimensional Print
710D	0297	MI 018-571	1/8 DIN Digital
710D	0597	MI 018-576	Digital Serial Communications Guide
710D	1196	PSS 2C-1B2 A	Product Specification Sheet

Controllers, Indicators, and Recorders Recorders

Product	Date	Doc. Num	Title or Description
40	0705	MI 001-130	Instrument Mounting and Connections Model 40 Recorders - Installation
40M	0705	MI 001-145	Mullins Chart Changers for Recorder - Installation and Operation (AS Reference MCC)
40M	0410	PL 001-301	Parts List - Circular Chart Recorder
40P	0705	MI 001-145	Mullins Chart Changers for Recorder - Installation and Operation (AS Reference MCC)
40P	0410	PL 001-301	Parts List - Circular Chart Recorder
120	0603	PL 006-413	Parts List - Style D
120	0509	PL 006-414	Parts List - Style E
120	1004	PL 006-416	Parts List - Chart Drives for 120 Series
120	0101	PSS 2B-3E1 A	Product Specification Sheet
740R	0905	MI 018-871	Digital Circular Chart Recorder and Recording Controller - Installation, Operation, Configuration, and Maintenance
740R	1005	PL 009-166	Parts List
740R	1005	PSS 2C-1A8 A	Product Specification Sheet
752RNA	0402	PSS 2C-1A16 A	Product Specification Sheet
763MNA	0901	PL 009-178	Parts List
763MNA	0402	PSS 2C-1A15 A	Product Specification Sheet
763RNA	0901	PL 009-178	Parts List
763RNA	0402	PSS 2C-1A14 A	Product Specification Sheet
6100AF	1208	DP 018-910	Dimensional Print
6100AF	0809	MI 018-910	Paperless Graphic Recorders
6100AF	0110	PL 009-190	Parts List
6100AF	0110	PSS 2C-1C1 A	Product Specification Sheet - Paperless Graphic Recorder
6180AF	1208	DP 018-910	Dimensional Print
6180AF	0809	MI 018-910	Paperless Graphic Recorders
6180AF	0809	PL 009-190	Parts List
6180AF	0809	PSS 2C-1C1 A	Product Specification Sheet - Paperless Graphic Recorder
E20S	0701	PSS 2A-3A1 C	Product Specification Sheet

Electrochemical Analyzers

Page 1 of 2

Product	Date	Doc. Num	Title or Description
BS810NX	1104	MI 611-226	Remote Communications Program for 875 Analyzers
BS811BV	0509	MI 611-207	Conversion Kit to Add HART Capability to 875 Series Analyzers
BS811FN	0206	MI 611-228	General Purpose Firmware Upgrade Kit for 875 Analyzers
BS811GC	1002	MI 611-189	Static Charge Control Upgrade for 875PH Analyzers
BS811GD	1002	MI 611-189	Static Charge Control Upgrade for 873PH-..P Analyzers
BS811GE	1002	MI 611-189	Static Charge Control Upgrade for 873PH-..W, X, Y, or Z Analyzers
873	1210	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
873A	1003	PSS 6-1C1 F	Product Specification Sheet
873ACC	0604	MI 611-192	Ace Series Analyzers for Contacting Conductivity Measurement
873AEC	0604	MI 611-193	Ace Series Analyzers for Electrodeless Conductivity Measurement
873APH	0604	MI 611-191	Ace Series Analyzers for pH Measurements
873ARS	0604	MI 611-194	Ace Series Analyzers for Resistivity Measurements
873CC	0608	DP 611-162	Dimensional Print
873CC	0604	MI 611-166	Contact/Conductivity Measurement
873CC	1295	PL 611-016	Parts List
873CC	1003	PSS 6-1C1 E	Product Specification Sheet
873DO	0608	DP 611-149	Dimensional Print
873DO	0608	DP 611-162	Dimensional Print
873DO	0705	MI 611-169	Dissolved Oxygen Measurement
873DO	1295	PL 611-016	Parts List
873DO	1003	PSS 6-1C1 E	Product Specification Sheet
873DPX	0608	DP 611-162	Dimensional Print
873DPX	0604	MI 611-190	pH/ORP/ISE Measurement
873DPX	1295	PL 611-016	Parts List
873DPX	0594	PSS 6-1C1 B	Product Specification Sheet
873DPX	1003	PSS 6-1C1 E	Product Specification Sheet
873EC	0608	DP 611-162	Dimensional Print
873EC	0409	MI 611-167	Electrodeless Conductivity Measurement
873EC	0409	MI 611-220	System Calibration Examples
873EC	1295	PL 611-016	Parts List
873EC	1003	PSS 6-1C1 E	Product Specification Sheet
873PH	0608	DP 611-162	Dimensional Print
873PH	0604	MI 611-165	pH and ORP Measurement
873PH	1295	PL 611-016	Parts List
873PH	0594	PSS 6-1C1 B	Product Specification Sheet
873PH	1003	PSS 6-1C1 E	Product Specification Sheet
873RS	0608	DP 611-162	Dimensional Print
873RS	1005	MI 611-168	Resistivity Measurement
873RS	1295	PL 611-016	Parts List
873RS	1003	PSS 6-1C1 E	Product Specification Sheet

Electrochemical Analyzers

Page 2 of 2

Product	Date	Doc. Num	Title or Description
875	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
875	0509	MI 611-207	Conversion Kit BS811BV to Add HART Communication Capability
875	1210	MI 611-208	Safety Information
875	1104	MI 611-226	Remote Communications Program BS810NX
875	1004	MI 611-227	Operation, Configuration and Calibration Using a HART Communicator
875	0206	MI 611-228	General Purpose Firmware Upgrade Kit BS811FN
875	0508	MI 611-246	Remote Communications
875CR	0500	DP 611-164	Dimensional Print
875CR	0809	MI 611-222	Contacting Conductivity and Resistivity Measurements
875CR	0206	PL 611-158	Parts List - Style A
875CR	1006	PL 611-163	Parts List - Styles C-D
875CR	1206	PSS 6-3A1 B	Product Specification Sheet
875EC	0500	DP 611-164	Dimensional Print
875EC	0809	MI 611-224	Electrodeless Conductivity Measurement
875EC	0409	MI 611-220	System Calibration Examples
875EC	0206	PL 611-158	Parts List - Style A
875EC	1006	PL 611-163	Parts List - Styles C-D
875EC	0209	PSS 6-3N1 C	Product Specification Sheet
875PH	0500	DP 611-164	Dimensional Print
875PH	0809	MI 611-225	pH, ORP, or Ion Selective Electrode (ISE) Measurement - Style C
875PH	0206	PL 611-158	Parts List - Style A
875PH	1006	PL 611-163	Parts List - Styles B-C
875PH	1206	PSS 6-1A1 E	Product Specification Sheet

April 2011

Electrochemical Transmitters

Product	Date	Doc. Num	Title or Description
870IT	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
870IT	0595	MI 611-213	Conversion Kit Kit-C-BS806ZP to Add Rain Door Assembly
870IT	0408	MI 611-208	Safety Information
870ITCR	0398	DP 611-163	Dimensional Print
870ITCR	0310	MI 611-216	Contact Conductivity/Resistivity
870ITCR	1002	PL 611-153	Parts List - Style B
870ITCR	1002	PL 611-156	Parts List - Style A
870ITCR	0609	PSS 6-3C1 B	Product Specification Sheet
870ITEC	0398	DP 611-163	Dimensional Print
870ITEC	0409	MI 611-212	Electrodeless Conductivity Measurements
870ITEC	0409	MI 611-220	System Calibration Examples
870ITEC	1002	PL 611-153	Parts List - Style B
870ITEC	1002	PL 611-156	Parts List - Style A
870ITEC	0509	PSS 6-3N2 A	Product Specification Sheet
870ITPH	0398	DP 611-163	Dimensional Print
870ITPH	1005	MI 611-211	pH, ORP, and ION Selective Electrode Measurements
870ITPH	1002	PL 611-153	Parts List - Style B
870ITPH	1002	PL 611-156	Parts List - Style A
870ITPH	0509	PSS 6-1B1 B	Product Specification Sheet
876PH	0510	DP 611-260	Dimensional Print
876PH	0810	MI 611-262	Intelligent Transmitter for pH, ORP, and ISE Measurement
876PH	0510	PL 611-260	Parts List - Style A
876PH	0810	PSS 6-1A4 A	Product Specification Sheet

Electrochemical Sensors

pH and ORP Sensors Page 1 of 2

Product	Date	Doc. Num	Title or Description
BS810FA	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871PH Titanium
BS810FB	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871PH 316 ss
BS811HZ	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871A 316 ss
BS811JC	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871A Titanium
ORP10	1103	DP 611-171	Dimensional Print
ORP10	1103	DP 611-172	Dimensional Print - Insertion Assemblies for DolpHin
ORP10	1103	DP 611-173	Dimensional Print - Mounting Accessories for DolpHin
ORP10	0902	MI 611-204	Use of Universal Bushing with DolpHin Sensors (BS810XB and BS810XC)
ORP10	0510	MI 611-205	DolpHin - Installation, Troubleshooting, Maintenance, and Parts List
ORP10	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
ORP10	0408	MI 611-208	Safety Information
ORP10	0802	PSS 6-1C3 A	Product Specification Sheet
PH10	1103	DP 611-171	Dimensional Print
PH10	1103	DP 611-172	Dimensional Print - Insertion Assemblies for DolpHin
PH10	1103	DP 611-173	Dimensional Print - Mounting Accessories for DolpHin
PH10	0902	MI 611-204	Use of Universal Bushing with DolpHin Sensors (BS810XB and BS810XC)
PH10	0510	MI 611-205	DolpHin - Installation, Troubleshooting, Maintenance, and Parts List
PH10	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
PH10	0408	MI 611-208	Safety Information
PH10	0802	PSS 6-1C3 A	Product Specification Sheet
PH12	0311	DP 611-214	Dimensional Print
PH12	0311	MI 611-214	pH Sensors and Accessories - Installation, Troubleshooting, and Maintenance
PH12	0311	MI 611-215	pH Sensors- Quick Start
PH12	0311	PL 611-214	Parts List
PH12	0311	PSS 6-1C5 A	Product Specification Sheet
871	1208	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
871A	0608	DP 611-141	Dimensional Print ECS Flow Through Submersible
871A	0608	DP 611-144	Dimensional Print
871A	0608	DP 611-145	Dimensional Print
871A	0608	DP 611-157	Dimensional Print Ball Valve Assembly
871A	1108	MI 611-164	Installation
871A	0408	MI 611-208	Safety Information
871A	0410	PSS 6-1C2 B	Product Specification Sheet

April 2011

Electrochemical Sensors

pH and ORP Sensors Page 2 of 2

Product	Date	Doc. Num	Title or Description
871PH	0508	DP 611-113	Dimensional Print pH and ORP
871PH	0307	DP 611-121	Dimensional Print Mounting Assembly
871PH	0804	DP 611-122	Dimensional Print Ball Valve Assembly
871PH	0307	DP 611-123	Dimensional Print Optional Containment
871PH	0608	DP 611-140	Dimensional Print ECS Flow Through Spool
871PH	0608	DP 611-141	Dimensional Print ECS Flow Through Submersible
871PH	0493	MI 611-125	Electrode Cleaning System
871PH	0804	MI 611-136	Reference Junction Refill Kit for Sensors
871PH	0808	MI 611-148	Installation and Maintenance
871PH	0408	MI 611-208	Safety Information
871PH	0804	MI 611-188	Electrode Kit for Sensors
871PH	0110	PL 611-014	Parts List
871PH	0410	PSS 6-1C2 A	Product Specification Sheet

Electrochemical Sensors

Conductivity Page 1 of 2

Product	Date	Doc. Num	Title or Description
871CC	0207	DP 611-091	Dimensional Print Flow Chambers
871CC	0605	DP 611-092	Dimensional Print Flanges 316 ss
871CC	0605	DP 611-093	Dimensional Print Twist-Lock Bushing 316 ss
871CC	0605	DP 611-094	Dimensional Print Twist-Lock Bushing PVC
871CC	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
871CC	0605	DP 611-131	Dimensional Print 3/4 NPT Threaded Bushing (-A and -K)
871CC	0605	DP 611-132	Dimensional Print Universal Mounting (-B)
871CC	0605	DP 611-133	Dimensional Print Sanitary Flange Mounted (-C and -L)
871CC	0605	DP 611-134	Dimensional Print Insertion Type (-D and -M)
871CC	0605	DP 611-135	Dimensional Print Twist-Lock Mounted (-E)
871CC	0605	DP 611-136	Dimensional Print 3/4 NPT Threaded Bushing and 1/2 NPT Conduit (-F)
871CC	0605	DP 611-139	Dimensional Print DIP Type (-G)
871CC	0606	MI 611-151	Installation and Maintenance
871CC	0408	MI 611-208	Safety Information
871CC	0105	PSS 6-3C2 A	Product Specification Sheet
871CR	0998	DP 611-165	Dimensional Print Universal Bore Piece
871CR	0998	DP 611-166	Dimensional Print Bushing Mounted
871CR	0998	DP 611-167	Dimensional Print Universal Bore Piece w/Cable Connector or Conduit Fitting
871CR	0998	DP 611-168	Dimensional Print Tri-Clamp Fittings
871CR	0998	DP 611-169	Dimensional Print Insertion Sensors for use with Ball Valve Accessories
871CR	0506	DP 611-170	Dimensional Print Accessories
871CR	0408	MI 611-208	Safety Information
871CR	0606	MI 611-221	Sensors and Accessories
871CR	0708	PL 611-019	Parts List Sensors
871CR	0610	PSS 6-3C2 B	Product Specification Sheet
871EC	0306	DP 611-011	Dimensional Print
871EC	0605	DP 611-092	Dimensional Print Flanges 316 ss
871EC	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
871EC	0608	DP 611-142	Dimensional Print Ball Valve Assembly
871EC	0305	DP 611-155	Dimensional Print Ball Valve Assembly (871EC-SP, -HP, -PP, -PT, -NL, -TF)
871EC	0305	DP 611-180	Dimensional Print Ball Valve Assembly (871EC-RE, -LB, -BW, -UT)
871EC	0306	MI 611-150	Installation and Maintenance
871EC	0408	MI 611-208	Safety Information
871EC	0409	MI 611-220	System Calibration Examples
871EC	0410	PSS 6-3C4 A	Product Specification Sheet
871FT	0408	DP 611-150	Dimensional Print with ANSI Class
871FT	0105	DP 611-151	Dimensional Print with NPT
871FT	0210	DP 611-152	Dimensional Print with Sanitary
871FT	0301	DP 611-153	Dimensional Print with ANSI Class 300
871FT	0797	DP 611-158	Dimensional Print with Metric PN10
871FT	0608	DP 611-159	Dimensional Print with Metric PN16

Electrochemical Sensors

Conductivity Page 2 of 2

Product	Date	Doc. Num	Title or Description
871FT	0610	MI 611-202	Installation, Calibration, and Troubleshooting
871FT	0408	MI 611-208	Safety Information
871FT	0409	MI 611-220	System Calibration Examples
871FT	0310	PL 611-017	Parts List Inch Line Sizes
871FT	0301	PL 611-018	Parts List Millimetre Line Sizes
871FT	0510	PSS 6-3Q1 A	Product Specification Sheet
910	0605	DP 611-092	Dimensional Print Flanges 316 ss
910	0605	DP 611-093	Dimensional Print Twist-Lock Bushing 316 ss
910	0605	DP 611-094	Dimensional Print Twist-Lock Bushing PVC
910	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
910	0605	DP 611-124	Dimensional Print 3/4 NPT Threaded Bushing
910	0605	DP 611-125	Dimensional Print 3/4 NPT Threaded Bushing
910	0605	DP 611-126	Dimensional Print Sanitary Flange Mounted
910	0605	DP 611-127	Dimensional Print Insertion Type
910	0605	DP 611-128	Dimensional Print Twist Lock Mounting
910	0605	DP 611-129	Dimensional Print 3/4 NPT Threaded Bushing and 1/2 NPT Conduit
910	0605	DP 611-130	Dimensional Print DIP Type
920	0605	DP 611-092	Dimensional Print Flanges 316 ss
920	0605	DP 611-093	Dimensional Print Twist-Lock Bushing 316 ss
920	0605	DP 611-094	Dimensional Print Twist-Lock Bushing PVC
920	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
920	0605	DP 611-124	Dimensional Print 3/4 NPT Threaded Bushing
920	0605	DP 611-125	Dimensional Print 3/4 NPT Threaded Bushing
920	0605	DP 611-126	Dimensional Print Sanitary Flange Mounted
920	0605	DP 611-127	Dimensional Print Insertion Type
920	0605	DP 611-128	Dimensional Print Twist Lock Mounting
920	0605	DP 611-129	Dimensional Print 3/4 NPT Threaded Bushing and 1/2 NPT Conduit
920	0605	DP 611-130	Dimensional Print DIP Type
921	0605	DP 611-093	Dimensional Print Twist-Lock Bushing 316 ss
921	0605	DP 611-094	Dimensional Print Twist-Lock Bushing PVC
1210	0605	DP 611-092	Dimensional Print Flanges 316 ss
1210	0806	DP 611-105	Dimensional Print Universal Mounting Bushing
FT10	0207	DP 611-217	Dimensional Print
FT10	0408	MI 611-208	Safety Information
FT10	1007	MI 611-217	Flow-Through Conductivity Sensors - Installation, Calibration, Troubleshooting, and Maintenance
FT10	0409	MI 611-220	System Calibration Examples
FT10	0107	PL 611-141	Parts List
FT10	0209	PSS 6-3Q1 B	Product Specification Sheet

April 2011

Electrochemical Sensors

Other

Product	Date	Doc. Num	Title or Description
	0207	TI 612-005	Electrodeless Conductivity, Toroidal Magnets, and the Procedure of Degaussing
222	0804	DP 611-122	Dimensional Print Ball Valve Assembly
222	0804	DP 611-137	Dimensional Print pH and ORP
871DO	0608	DP 611-149	Dimensional Print
871DO	0705	MI 611-200	Sensors and Accessories
871DO-C	0705	PL 611-121	Parts Lists - Dissolved Oxygen Sensors
871DO-C	0209	PSS 6-9B1 A	Product Specification Sheet
0051052	0904	DP 611-160	Dimensional Print - Junction Box (7 Terminals)
BS807BZ	0904	DP 611-160	Dimensional Print - Junction Box (8 Terminals)
BS811MR	0410	DP 611-174	Dimensional Print - Remote Preamplifier Junction Box
BS811MR	0410	MI 611-229	Remote Preamplifier Junction Box
BS813XN	0410	DP 611-174	Dimensional Print - Junction Box
BS813XN	0410	MI 611-229	Junction Box
EP402	0205	MI 611-177	Small-Bore Flow-Through Assembly
EP459A	0807	DP 611-210	Dimensional Print - Fluoride Measuring System
EP459A	0210	MI 611-210	Fluoride Measuring System
EP459A	0707	PL 611-210	Parts List - Fluoride Measuring System

April 2011

Electrochemical Product Application Data

Product	Date	Doc. Num	Title or Description
875PH	0904	PAD D3620-008	Analyzers for Control and Monitoring in Chromate Waste Treatment
	0998	PAD D3620-012	Point of Use Water Purity Measurements in Semiconductor Industry Using Intelligent Transmitters and Sensors
	0198	PAD G2600-006	Black Liquor Spill Reclamation
	0198	PAD G2600-015	Alkali Concentration Measurement System
	0198	PAD G2600-017	Bleaching
	0198	PAD G2600-018	Brownstock Washing
	0198	PAD G2600-019	Causticizing Control
	0198	PAD G2600-020	Steam Condensate Reclamation
	0198	PAD G2600-021	Dissolving Tank Density Control
	0198	PAD G2600-022	Paper Machine - Wet End pH Control
	0198	PAD G2600-023	Waste Water Treatment
	0198	PAD G2600-024	White Liquor Strength
	0298	PAD P4100-020	Intelligent Analytical Transmitters in Power Plant Applications
	0499	PAD P4100-021	Steam Condensate Leak Detection
	0499	PAD P4100-022	Reverse Osmosis Measurements
	0499	PAD P4100-023	pH Measurement in Wet Scrubbers
	0499	PAD P4100-024	pH Measurement in High Purity Boiler Water
	0499	PAD P4100-025	Demineralizer Regeneration Concentration Control
	0499	PAD P4100-026	Demineralization Bed Monitoring
	0499	PAD P4100-027	Cooling Tower Control
	0499	PAD P4100-028	Condensate Return
	0499	PAD P4100-029	Condensate Analysis
	0499	PAD P4100-030	Waste Water Treatment

April 2011

Foxboro Eckardt Electronic Transmitters

Product	Date	Doc. Num	Title or Description
104..	0696	PSS EML0900A-(en)	Product Specification Sheet Accessories for Buoyancy Transmitter
144LD	0503	MI EML0610A-(en)	Buoyancy Transmitter with Torque Tube
144LD	1008	MI EML0610E-(en)	Buoyancy Transmitter with Torque Tube and Displacer for Level, Interface and Density - All Versions
144LD	1107	MI EML0610F-(en)	Buoyancy Transmitter with Torque Tube and Displacer for Level, Interface and Density with Communication FOUNDATION Fieldbus
144LD	0708	PSS EML0610A-(en)	Product Specification Sheet
144LVD	0605	MI EML1610E-(en)	Buoyancy Transmitter for Liquid Level, Interface and Density
144LVD	0908	PSS EML1610A-(en)	Product Specification Sheet
167LP	1108	PSS EML0110A-(en)	Product Specification Sheet
204..	0109	PSS EML0901A-(en)	Product Specification Sheet Accessories for Buoyancy Transmitter
244LD	0210	MI EML0710E-(en)	Buoyancy Transmitter with Torque Tube and Displacer for Level, Interface and Density - All Versions
244LD	0908	PSS EML0710A-(en)	Product Specification Sheet
244LVP	0210	MI EML1710A-(en)	Buoyancy Transmitter for Liquid Level, Interface and Density
244LVP	0309	PSS EML1710A-(en)	Product Specification Sheet

April 2011

Foxboro Eckardt Positioners

Product	Date	Doc. Num	Title or Description
SRD960	0707	MI EVE0105B-(en)	Universal Positioner with HART Hand-Held Terminal
SRD960	0109	MI EVE0109A-(en)	Universal Positioner
SRD960	0210	PSS EVE0109A-(en)	Product Specification Sheet
SRD991	0707	MI EVE0105B-(en)	Intelligent Positioner with HART Hand-Held Terminal
SRD991	0409	MI EVE0105E(en)	Intelligent Positioner - All Versions
SRD991	1209	PSS EVE0105E-(en)	Product Specification Sheet
SRI986	0707	MI EVE0102A-(en)	Product Specification Sheet
SRI986	0409	PSS EVE0102A-(en)	Product Specification Sheet
SRI990	1007	MI EVE0107A-(en)	Analog Positioner
SRI990	0210	PSS EVE0107A-(en)	Product Specification Sheet
SRP981	0499	MI EVE0101A-(en)	Product Specification Sheet
SRP981	0499	PSS EVE0101A-(en)	Product Specification Sheet

Magnetic Flow Transmitters

Page 1 of 2

Product	Date	Doc. Num	Title or Description
47	0908	MI 021-322	Magnetic Flow Transmitters - Installation, Commissioning, and Service
47	0908	MI 021-326	Flowmeter Remote Mounting Kit, Installation Kit A5E01268346
47	0507	PSS 1-6G1 A	Product Specification Sheet
48	0908	MI 021-322	Magnetic Flow Transmitters - Installation, Commissioning, and Service
48	0908	MI 021-326	Flowmeter Remote Mounting Kit, Installation Kit A5E01268346
48	0604	MI 021-329	Supplemental Installation Instructions for Transmitter used in PMO, HTST Flowmeter Applications
48	0507	PSS 1-6G1 A	Product Specification Sheet
IMT25	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters
IMT25	0501	DP 021-365	Dimensional Print
IMT25	1208	MI 021-387	Installation with 8000A, 2800, 8300, 9100A, 9200A, and 9300A
IMT25	0810	MI 021-390	Model IMT25 - Operation, Configuration, and Calibration
IMT25	0405	MI 021-391	System Maintenance with 8000A, 2800, 8300, 9100A, 9200A, and 9300A
IMT25	0698	MI 021-397	Operation, Configuration, and Calibration With HART Communicator
IMT25	0705	PL 008-745	Parts List
IMT25	0309	PSS 1-6F5 A	Product Specification Sheet - FoxCom and HART
IMT25-...F	0605	MI 014-900	Fieldbus Overview
IMT25-...F	0405	MI 021-399	Operation, Configuration, and Calibration from a Fieldbus Host
IMT25-...F	0309	PSS 1-6F5 B	Product Specification Sheet - FOUNDATION Fieldbus
IMT25L	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters
IMT25L	0398	DP 021-366	Dimensional Print
IMT25L	1197	PL 008-746	Parts List
IMT25L	0309	PSS 1-6F6 A	Product Specification Sheet
IMT96	0299	DP 021-367	Dimensional Print
IMT96	0209	MI 021-402	With 2800 Series Flanged Flowtubes Installation
IMT96	0809	MI 021-403	Integral Keypad and Display, Local Operation, Configuration, and Calibration
IMT96	0309	MI 021-404	With 2800 Series Flanged Flowtubes System Maintenance
IMT96	0599	MI 021-412	Retrofitting 2800 Series with Flanged Flowtubes when Previously Connected to an E96
IMT96	0510	MI 021-415	With HART Communications - Operation, Configuration, and Calibration
IMT96	0109	PL 008-747	Parts List
IMT96	0109	PSS 1-6F8 A	Product Specification Sheet
MAG2	1208	TI 027-077	Technical Information Magnetic Flowmeter Application Guideline
MAG2IC	1208	DP 021-500	Dimensional Print
MAG2IC	0410	MI 021-500	Flowmeter with Integrally Mounted Transmitter - Operation, Configuration, and Calibration
MAG2IC	0210	PL 008-750	Parts List
MAG2IC	0610	PSS 1-6G3 A	Product Specification Sheet

April 2011

Magnetic Flow Transmitters

Page 2 of 2

Product	Date	Doc. Num	Title or Description
MAG2RS	1208	DP 021-501	Dimensional Print
MAG2RS	0410	MI 021-500	Remote Mounted Flowtube - Operation, Configuration, and Calibration
MAG2RS	0210	PL 008-750	Parts List
MAG2RS	0410	PSS 1-6G3 A	Product Specification Sheet
MAG2RT	1208	DP 021-500	Dimensional Print
MAG2RT	0410	MI 021-500	Remote Mounted Transmitter - Operation, Configuration, and Calibration
MAG2RT	0210	PL 008-750	Parts List
MAG2RT	0410	PSS 1-6G3 A	Product Specification Sheet

Magnetic Flow Flowtubes

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters - 8000A, 8300, and 9300A
2800	0708	DP 021-120	Dimensional Print
2800	0193	DP 021-137	Dimensional Print
2800	0909	MI 021-120	Flowtubes, Installation
2800	0309	MI 021-137	Installation
2800	1195	MI 021-138	Fault Location Guide
2800	0309	MI 021-141	Sanitary pftc Line
2800	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
2800	0610	PL 008-541	Parts List 15 to 300 mm (12/ to 12 in) Sizes
2800	0608	PL 008-544	Parts List 350 to 900 mm (14 to 36 in) Sizes
2800	1209	PSS 1-6B5 A	Product Specification Sheet
2800	0608	PSS 1-6B5 C	Product Specification Sheet
2800	1208	PSS 1-6B5 E	Product Specification Sheet
2891	0608	PL 008-543	Parts List 2.5 mm (1/10 in) Size
2893	0608	PL 008-543	Parts List 6 mm (1/4 in) Size
4700S	0908	MI 021-323	Sanitary Flowtube - Installation
4700S	0604	MI 021-329	Supplemental Installation Instructions for Flowtube used in PMO, HTST Flowmeter Applications
4700S	1208	MI 021-414	Flowmeter Submersible Mounting Kit FDK-085U0220
4700S	0410	PSS 1-6G2 A	Product Specification Sheet
8000A	1107	DP 021-358	Dimensional Print
8000A	0109	MI 019-179	Flow Safety Information
8000A	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
8000A	0909	MI 021-380	Compact Magnetic Flowtubes - Installation
8000A	0808	PL 008-740	Parts List
8000A	0808	PSS 1-6F2 A	Product Specification Sheet
8000A	0608	PSS 1-6F2 C	Product Specification Sheet
8300	0708	DP 021-360	Dimensional Print Flanged
8300	0708	DP 021-361	Dimensional Print pftc-Lined Sanitary
8300	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
8300	0810	MI 021-381	8300 Series Magnetic Flowtubes - Installation
8300	0808	PL 008-741	Parts List
8300	0608	PSS 1-6F2 B	Product Specification Sheet
8300	0608	PSS 1-6F2 C	Product Specification Sheet

April 2011

Magnetic Flow Flowtubes

Page 2 of 2

Product	Date	Doc. Num	Title or Description
9100A	0808	DP 021-368	Dimensional Print Flanged
9100A	1110	DP 021-369	Dimensional Print Flanged
9100A	0109	MI 019-179	Flow Safety Information
9100A	1110	MI 021-413	Flowtubes, Installation
9100A	1110	PL 008-748	Parts List
9100A	1110	PSS 1-6F9 A	Product Specification Sheet
9200A	0808	DP 021-368	Dimensional Print Flanged
9200A	1110	DP 021-369	Dimensional Print Flanged
9200A	0109	MI 019-179	Flow Safety Information
9200A	1110	MI 021-413	Flowtubes, Installation
9200A	1110	PL 008-748	Parts List
9200A	1110	PSS 1-6F10 A	Product Specification Sheet
9300A	0902	DP 021-364	Dimensional Print
9300A	0109	MI 019-179	Flow Safety Information
9300A	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
9300A	1208	MI 021-386	Flanged Magnetic Flowtubes, pfa-, pte-, or Polyurethane-Lined, Installation
9300A	0808	PL 008-742	Parts List
9300A	0808	PSS 1-6F4 A	Product Specification Sheet

April 2011

Magnetic Flow Other

Product	Date	Doc. Num	Title or Description
	0211	TI 27-71f	Technical Information Material Selection Guide
	0906	TI 027-072	Technical Information Electrical Conductivity of Process Liquids
IMTSIM	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters
IMTSIM	1009	MI 021-392	Magnetic Flowtube Simulator
IMTSIM	1109	PSS 1-6F7 A	Product Specification Sheet

April 2011

Mass Flow Transmitter

Product	Date	Doc. Num	Title or Description
	0300	TI 001-053	Tutorial Percent Solids Calculation
CFT50	0709	B0800AH-C	Digital Coriolis Mass Flowmeters Installation Guidelines and Quick Start - HART
CFT50	0210	B0800AL-B	Digital Coriolis Mass Flowmeters Installation Guidelines and Quick Start - Modbus
CFT50	0609	DP 019-375	Dimensional Print
CFT50	0510	MI 019-132	Digital Coriolis Transmitter with HART - Installation, Startup, Configuration, and Maintenance
CFT50	0409	MI 019-133	Safety Connection Diagrams (FM, CSA)
CFT50	0510	MI 019-134	Digital Coriolis Transmitter with Modbus - Installation, Startup, Configuration, and Maintenance
CFT50	0109	MI 019-179	Flow Safety Information
CFT50	0509	PL 008-704	Parts List
CFT50	0410	PSS 1-2B7 A	Product Specification Sheet

April 2011

Mass Flow Flowtubes

Product	Date	Doc. Num	Title or Description
CFS10	0802	DP 019-182	Dimensional Print 6-50 mm (1/4 to 2 inch)
CFS10	0998	DP 019-366	Dimensional Print 3 mm (1/8 inch)
CFS10	0506	MI 019-120	Installation, Startup, Troubleshooting and Maintenance
CFS10	0109	MI 019-179	Flow Safety Information
CFS10	0608	PL 008-702	Parts List - Style A
CFS10	0506	PL 008-733	Parts List - Style B
CFS10	0710	PSS 1-2B1 A	Product Specification Sheet
CFS20	0802	DP 019-183	Dimensional Print
CFS20	0506	MI 019-120	Installation, Startup, Troubleshooting and Maintenance
CFS20	0109	MI 019-179	Flow Safety Information
CFS20	0608	PL 008-703	Parts List - Style A
CFS20	0506	PL 008-735	Parts List - Style B
CFS20	0710	PSS 1-2B1 A	Product Specification Sheet

Product	Date	Doc. Num	Title or Description
	0309	MSDS 010	Recorders - Type 1800 Aqueous Recorder Ink
	0111	MSDS 011	Recorders - Non-Bleed Aqueous Recorder Ink Fiber Tip Cartridges
	0808	MSDS 021	Controllers - Nitrogen - N2 Liquefied Nitrogen N2 (Cryogenic)
	0311	MSDS 022	Controllers - Argon - Ar Liquefied Argon - Ar (Cryogenic)
	1110	MSDS 023	Controllers - Helium - He Liquefied Helium - He (Cryogenic)
0003093	1209	MSDS 049	Echem Sensors - Reference Electrode Solution - 4M Potassium Chloride Solution Plus Glycol
0016776	0111	MSDS 046	Controllers - Mercury
0016777	0111	MSDS 046	Controllers - Mercury
0017033	0111	MSDS 046	Controllers - Mercury
0046719	0309	MSDS 019	Controllers - Toluene
0046721	0810	MSDS 018	Controllers - Ethyl Ether (Stabilized with ethyl alcohol)
0046722	0311	MSDS 014	Controllers - Ethyl Alcohol
0048130	0311	MSDS 092	Pressure Transmitters - DC111 Valve Lubricant and Sealant
0048192	1209	MSDS 076	Temperature - Dewcel Solution - 5% Lithium Chloride Solution - 1 Ounce Bottle
0048860	1110	MSDS 099	Controllers - 4205 Prism Instant Adhesive Thermal Reistant Gel
1355061	1209	MSDS 051	Echem Sensors - Antimony pH Electrode Disk
1600585	0309	MSDS 140	Echem Sensors - Nyogel 761
A072203	0311	MSDS 032	Pressure Transmitters - DC704 Diffusion Pump Fluid Silicone
AS600AM	1209	MSDS 050	Echem Sensors - Glass pH Electrode Buffer Solution
B0134LM	0309	MSDS 031	Pressure Transmitters - DC200 Fluid 2 CST and 5 CST
B0139SL	1008	MSDS 029	Pressure Transmitters - FC-770 Fluorinert Electronic Liquid
B0158LY	1209	MSDS 049	Echem Sensors - Reference Electrode Solution - 4M Potassium Chloride Solution Plus Glycol
B0200EB	1209	MSDS 119	Echem Sensors - Dissolved Oxygen Electrolyte Solution 0.5M KCL
BS814AQ	0810	MSDS 136	Echem Sensors - Internal Filling Solution
BS814AP	0810	MSDS 139	Echem Sensors - Reference Electrode Solution - 1M Potassium Chloride Solution Plus Glycol
BS814AK	0810	MSDS 146	Reference Cavity Solution - Aqueous Electrolyte Solution with Propylene Glycol
C1000VY	0311	MSDS 103	Pressure Transmitters - DC200 Fluid 10 CST
D0114YC	0808	MSDS 034	Pressure Transmitters - DC200 Fluid, 500 CST - Silicone
D0116MP	0309	MSDS 043	Controllers - Ethylene Glycol
D0123MX	0111	MSDS 044	Controllers - Triethanolamine
D0129ZT	0111	MSDS 108	Controllers - High Intensity Nylon Wick Aqueous Recorder Ink
D0129ZU	0309	MSDS 024	Controllers - Nylon Wick 63 Aqueous Recorder Ink
D0129ZV	0309	MSDS 024	Controllers - Nylon Wick 63 Aqueous Recorder Ink
D0129ZW	0309	MSDS 024	Controllers - Nylon Wick 63 Aqueous Recorder Ink
F0109EH	1010	MSDS 120	Controllers - Moebius Oil Syntalube

Product	Date	Doc. Num	Title or Description
H0103AY	1209	MSDS 076	Temperature - Dewcel Solution - 5% Lithium Chloride Solution - 1 Pint Bottle
Q0104KE	0309	MSDS 053	Echem Sensors - 4 Molar Potassium Chloride Saturated with Silver Chloride
L0121CN	0111	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
L0121CS	0111	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
L0121CX	0111	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
L0121DC	0111	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
N1205BR	0407	MSDS 143	Pressure Transmitters - DC200 FLuid, Foodgrade, 350 CST - Silicone
N1206TZ	0309	MSDS 142	Pressure Seals - Neobee M-20
T0103RK	1110	MSDS 013	Controllers - sec-BUTYLBENZENE
T0103KR	0808	MSDS 015	Controllers - Propane
T0103KT	0309	MSDS 017	Controllers - Methyl Chloride
T0103PX	0808	MSDS 020	Controllers - Acetone
X0114AF	0309	MSDS 127	Pressure Transmitters - Key Abso-Lute (Oxygen Sealing Compound)
X0118CC	0309	MSDS 088	Pressure Transmitters - Lubriplate Aero
X0180AM	0908	MSDS 125	Pressure Transmitters - FC-43 Fluorinert Brand Electronic Liquid
X0180DE	0309	MSDS 126	Pressure Transmitters - DC200 Fluid 5 CST
X0180GS	0908	MSDS 144	Pressure Transmitters - F-900 Torque Seal (Red) Sealing Compount
X0180HB	0309	MSDS 137	Echem Analyzers - DC838 Silicone Adhesive/Sealant (Kit-AG100WH)
X0180HC	0309	MSDS 138	Echem Analyzers - Multiplurpose Alcohol Wipes (Kit-AG100WH)
X0180HK	0808	MSDS 141	Magnetic Flow Flowtubes - DC3-4207 Dielectric Tough Gel Part A and B
B1270KE	1110	MSDS 079	LOCTITE 592 PST PIPE SEALANT
B6301TF	1110	MSDS 081	LOCTITE - Moly Paste
K0180TA	1110	MSDS 083	430 Super Bonder Instant Adhesive
S0106ML	1110	MSDS 086	LOCTITE 222MS Threadlocker
BS814CN	1210	MSDS 086	Sodium Reconditioning Solution
G0109JA	0111	MSDS 027	Foxboro 1500 Type Aqueous Recorder Ink
G0109JB	0111	MSDS 027	Foxboro 1500 Type Aqueous Recorder Ink
D0123MX	0111	MSDS 044	Triethanolamine
1600100	0111	MSDS 058	Hydrion Buffer pH 4.00
1600101	0111	MSDS 059	Hydrion Buffer pH 7.00
1600102	0111	MSDS 060	Hydrion Buffer pH 10.00
B0119NZ	0111	MSDS 078	Parker O-Lube
X0117BY	0111	MSDS 117	Catalyst for Epoxy Resin
X0171NQ	0311	MSDS 030	Dow Chemical Company - Syltherm 800# Base Heat Transfer Fluid

Pressure Transmitters d/p Cell

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0998	B0800AE	Ensuring Premium Performance with Foxboro Intelligent Level Transmitters
	0210	B0800AG	Pressure Transmitters - Getting Started
11DM	0304	PL 006-265	Parts List Styles C and D
13A	0499	MI 022-310	d/p Cell Installation and Operation
13A	0789	MI 022-345	Maintenance
13A	1005	PL 006-175	Parts List
13A	0110	PSS 2B-1C1 A	Product Specification Sheet
13H	0306	PL 006-177	Parts List
13HA	0110	PSS 2B-1C1 A	Product Specification Sheet
15A	0304	PL 006-176	Parts List Styles B-E
15A	0110	PSS 2B-1C1 A	Product Specification Sheet
CO	1107	DP 022-335	Dimensional Print
CO	1003	MI 022-335	Compact Orifice with d/p Cell Transmitters
CO	1003	PL 006-172	Parts List - Compact Orifice with d/p Cell Transmitters
CO	1007	PSS 3-5A1 E	Product Specification Sheet - Compact Orifice with d/p Cell Transmitters
IDP.-F	0605	MI 014-900	Fieldbus Overview
IDP10	0605	DP 020-446	Dimensional Print
IDP10	0609	MI 020-357	Functional Safety Manual
IDP10	0509	MI 020-358	Safety Information
IDP10	0810	MI 020-359	Universal Instruction Manual
IDP10	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IDP10	0510	PL 009-005	Parts List
IDP10	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IDP10-A	0510	MI IDP10-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA Output Signal)
IDP10-A	0310	PSS 2A-1C14 C	Product Specification Sheet
IDP10-D	0510	MI IDP10-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IDP10-D	0311	PSS 2A-1C14 A	Product Specification Sheet
IDP10-F	0510	MI IDP10-F	Installation, Calibration, Configuration and Maintenance (FOUNDATION Fieldbus Communication)
IDP10-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IDP10-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IDP10-T	0510	MI IDP10-T	Installation, Calibration, Configuration, and Maintenance (HART Communications)
IDP10-T	0310	PSS 2A-1C14 B	Product Specification Sheet
IDP10-V	0510	MI IDP10-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IDP10-V	0310	PSS 2A-1C13 D	Product Specification Sheet

Pressure Transmitters d/p Cell

Page 2 of 2

Product	Date	Doc. Num	Title or Description
IDP25	0605	DP 020-446	Dimensional Print
IDP25	0509	MI 020-358	Safety Information
IDP25	0810	MI 020-359	Universal Instruction Manual
IDP25	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IDP25	0510	PL 009-013	Parts List
IDP25	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IDP25-D	0410	MI IDP25-D/ IDP50-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IDP25-D	1209	PSS 2A-1C14 K	Product Specification Sheet
IDP25-F	0410	MI IDP25-F/ IDP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IDP25-F	1209	PSS 2A-1C14 K	Product Specification Sheet
IDP25-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IDP25-T	0410	MI IDP25-T/ IDP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IDP25-T	1209	PSS 2A-1C14 K	Product Specification Sheet
IDP50	0605	DP 020-446	Dimensional Print
IDP50	0509	MI 020-358	Safety Information
IDP50	0810	MI 020-359	Universal Instruction Manual
IDP50	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IDP50	0510	PL 009-014	Parts List
IDP50	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IDP50-D	0410	MI IDP25-D/ IDP50-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communications)
IDP50-D	1209	PSS 2A-1C14 L	Product Specification Sheet
IDP50-F	0410	MI IDP25-F/ IDP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IDP50-F	1209	PSS 2A-1C14 L	Product Specification Sheet
IDP50-T	0806	MI 020-366	I/A Series Pressure Transmitters with HART M275 Configurator
IDP50-T	0410	MI IDP25-T/ IDP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IDP50-T	1209	PSS 2A-1C14 L	Product Specification Sheet

Pressure Transmitters Absolute/Gauge

Page 1 of 5

Product	Date	Doc. Num	Title or Description
	0998	B0800AE	Ensuring Premium Performance with Foxboro Intelligent Level Transmitters
	0210	B0800AG	Pressure Transmitters - Getting Started
11A	0701	PSS 2B-1A1 A	Product Specification Sheet
11AH	0304	PL 006-273	Parts List Styles C and D
11AL	0304	PL 006-272	Parts List Styles C and D
11AM	0304	PL 006-271	Parts List Styles D and E
11GH	0304	PL 006-267	Parts List Styles D and E
11GH	0510	PSS 2B-1A3 A	Product Specification Sheet
11GM	0499	MI 004-311	Removable Sealed Pressure
11GM	0499	MI 022-415	Pressure Transmitter Style C-D
11GM	0304	PL 006-266	Parts List
11GM	0510	PSS 2B-1A3 A	Product Specification Sheet
15F	0103	PL 006-179	Parts List
IAP.-F	0605	MI 014-900	Fieldbus Overview
IAP10	0599	DP 020-212	Dimensional Print Sanitary Gauge or Absolute Level 2-inch Tri-Clamp
IAP10	0705	DP 020-217	Dimensional Print Sanitary with Pulp and Paper Process Connections
IAP10	0403	DP 020-218	Dimensional Print Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IAP10	0403	DP 020-219	Dimensional Print Sanitary with Mini Tank Spud Seal
IAP10	0209	DP 020-447	Dimensional Print
IAP10	0609	MI 020-357	Functional Safety Manual
IAP10	0509	MI 020-358	Safety Information
IAP10	0810	MI 020-359	Universal Instruction Manual
IAP10	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IAP10	0510	PL 009-006	Parts List
IAP10	1209	PSS 2A-1C13 K	Product Specification Sheet - Sanitary Process Connections
IAP10	1209	PSS 2A-1C13 L	Product Specification Sheet - Process Connections for Pulp and Paper
IAP10	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IAP10-A	0510	MI IAP10-A/ IGP10-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IAP10-A	0409	PSS 2A-1C13 C	Product Specification Sheet
IAP10-D	0510	MI IAP10-D/ IGP10-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IAP10-D	0209	PSS 2A-1C13 A	Product Specification Sheet
IAP10-F	0510	MI IAP10-F/ IGP10-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IAP10-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IAP10-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IAP10-T	0510	MI IAP10-T/ IGP10-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)

Pressure Transmitters

Absolute/Gauge

Page 2 of 5

Product	Date	Doc. Num	Title or Description
IAP10-T	0110	PSS 2A-1C13 B	Product Specification Sheet
IAP10-V	0510	MI IAP10-V/ IGP10-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IAP10-V	0310	PSS 2A-1C13 D	Product Specification Sheet
IAP20	0705	DP 020-217	Dimensional Print Sanitary with Pulp and Paper Process Connections
IAP20	0403	DP 020-218	Dimensional Print Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IAP20	0403	DP 020-219	Dimensional Print Sanitary with Mini Tank Spud Seal
IAP20	0209	DP 020-447	Dimensional Print
IAP20	0609	MI 020-357	Functional Safety Manual
IAP20	0509	MI 020-358	Safety Information
IAP20	0810	MI 020-359	Universal Instruction Manual
IAP20	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IAP20	0510	PL 009-007	Parts List
IAP20	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IAP20-A	0510	MI IAP20-A/ IGP20-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IAP20-A	0409	PSS 2A-1C13 C	Product Specification Sheet
IAP20-D	0510	MI IAP20-D/ IGP20-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IAP20-D	0209	PSS 2A-1C13 A	Product Specification Sheet
IAP20-F	0510	MI IAP20-F/ IGP20-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communications)
IAP20-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IAP20-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IAP20-T	0510	MI IAP20-T/ IGP20-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IAP20-T	0110	PSS 2A-1C13 B	Product Specification Sheet
IAP20-V	0510	MI IAP20-V/ IGP20-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IAP20-V	0310	PSS 2A-1C13 D	Product Specification Sheet
IDP15D	0211	MI 020-600	I/A Advanced Pressure Transmitter
IDP15D	0211	MI 020-540	I/A Advanced Pressure Transmitter Safety Information
IDP15D	0311	PSS 2A-1C17 A	Product Specification Sheet
IDP15D	0211	DP 020-600	Dimensional Print
IDP31D	0211	MI 020-600	I/A Advanced Pressure Transmitter
IDP315D	0211	MI 020-540	I/A Advanced Pressure Transmitter Safety Information
IDP31D	0311	PSS 2A-1C17 A	Product Specification Sheet
IDP31D	0211	DP 020-600	Dimensional Print
IDP32D	0211	MI 020-600	I/A Advanced Pressure Transmitter
IDP32D	0211	MI 020-540	I/A Advanced Pressure Transmitter Safety Information
IDP32D	0311	PSS 2A-1C17 A	Product Specification Sheet
IDP32D	0211	DP 020-600	Dimensional Print
IGP-F	0605	MI 014-900	Fieldbus Overview
IGP10	0599	DP 020-211	Dimensional Print Sanitary Gauge Pressure/Level 1 1/2-inch Tri-Clamp
IGP10	0599	DP 020-212	Dimensional Print Sanitary Gauge or Absolute Level 2-inch Tri-Clamp

Pressure Transmitters

Absolute/Gauge

Page 3 of 5

Product	Date	Doc. Num	Title or Description
IGP10	0599	DP 020-213	Dimensional Print Sanitary Gauge Pressure/Level 3-inch Tri-Clamp
IGP10	0599	DP 020-214	Dimensional Print Sanitary Gauge Pressure/Level Mini Tank Spud
IGP10	0599	DP 020-216	Dimensional Print Sanitary Gauge Pressure/Level Extended Mini Tank Spud
IGP10	0705	DP 020-217	Dimensional Print Sanitary with Pulp and Paper Process Connections
IGP10	0403	DP 020-218	Dimensional Print Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IGP10	0403	DP 020-219	Dimensional Print Sanitary with Mini Tank Spud Seal
IGP10	0208	DP 020-344	Dimensional Print High Gauge
IGP10	0209	DP 020-447	Dimensional Print
IGP10	0609	MI 020-357	Functional Safety Manual
IGP10	0509	MI 020-358	Safety Information
IGP10	0810	MI 020-359	Universal Instruction Manual
IGP10	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP10	0510	PL 009-006	Parts List
IGP10	1209	PL 009-010	Parts List - High Gauge
IGP10	1209	PSS 2A-1C13 F	Product Specification Sheet - for High Gauge
IGP10	1209	PSS 2A-1C13 K	Product Specification Sheet - Sanitary Process Connections
IGP10	1209	PSS 2A-1C13 L	Product Specification Sheet - Process Connections for Pulp and Paper
IGP10	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IGP10-A	0510	MI IAP10-A/ IGP10-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IGP10-A	0409	PSS 2A-1C13 C	Product Specification Sheet
IGP10-D	0510	MI IAP10-D/ IGP10-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP10-D	0209	PSS 2A-1C13 A	Product Specification Sheet
IGP10-F	0510	MI IAP10-F/ IGP10-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP10-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IGP10-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP10-T	0510	MI IAP10-T/ IGP10-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP10-T	0110	PSS 2A-1C13 B	Product Specification Sheet
IGP10-V	0510	MI IAP10-V/ IGP10-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IGP10-V	0310	PSS 2A-1C13 D	Product Specification Sheet
IGP20	0599	DP 020-211	Dimensional Print Sanitary Gauge Pressure/Level 1 1/2-inch Tri-Clamp
IGP20	0599	DP 020-212	Dimensional Print Sanitary Gauge or Absolute Pressure/Level 2-inch Tri-Clamp
IGP20	0599	DP 020-213	Dimensional Print Sanitary Gauge Pressure/Level 3-inch Tri-Clamp
IGP20	0599	DP 020-214	Dimensional Print Sanitary Gauge Pressure/Level Mini Tank Spud
IGP20	0599	DP 020-216	Dimensional Print Sanitary Gauge Pressure/Level Extended Mini Tank Spud

Pressure Transmitters Absolute/Gauge

Product	Date	Doc. Num	Title or Description
IGP20	0705	DP 020-217	Dimensional Print Sanitary with Pulp and Paper Process Connections
IGP20	0403	DP 020-218	Dimensional Print Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IGP20	0403	DP 020-219	Dimensional Print Sanitary with Mini Tank Spud Seal
IGP20	0209	DP 020-447	Dimensional Print
IGP20	0609	MI 020-357	Functional Safety Manual
IGP20	0509	MI 020-358	Safety Information
IGP20	0810	MI 020-359	Universal Instruction Manual
IGP20	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP20	0510	PL 009-007	Parts List
IGP20	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IGP20-A	0510	MI IAP20-A/ IGP20-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IGP20-A	0409	PSS 2A-1C13 C	Product Specification Sheet
IGP20-D	0510	MI IAP20-D/ IGP20-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP20-D	0209	PSS 2A-1C13 A	Product Specification Sheet
IGP20-F	0510	MI IAP20-F/ IGP20-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP20-F	0310	PSS 2A-1C13 E	Product Specification Sheet
IGP20-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP20-T	0510	MI IAP20-T/ IGP20-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP20-T	0110	PSS 2A-1C13 B	Product Specification Sheet
IGP20-V	0510	MI IAP20-V/ IGP20-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IGP20-V	0310	PSS 2A-1C13 D	Product Specification Sheet
IGP25	0209	DP 020-447	Dimensional Print
IGP25	0509	MI 020-358	Safety Information
IGP25	0810	MI 020-359	Universal Instruction Manual
IGP25	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP25	0510	PL 009-011	Parts List
IGP25	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IGP25-D	0410	MI IGP25-D/ IGP50-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP25-D	1209	PSS 2A-1C13 G	Product Specification Sheet
IGP25-D	1209	PSS 2A-1C13 M	Product Specification Sheet - with Sanitary Process Connections
IGP25-D	1209	PSS 2A-1C13 N	Product Specification Sheet - with Pulp and Paper Process Connections

Pressure Transmitters

Absolute/Gauge

Page 5 of 5

Product	Date	Doc. Num	Title or Description
IGP25-F	0410	MI IGP25-F/ IGP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP25-F	1209	PSS 2A-1C13 G	Product Specification Sheet
IGP25-F	1209	PSS 2A-1C13 M	Product Specification Sheet - with Sanitary Process Connections
IGP25-F	1209	PSS 2A-1C13 N	Product Specification Sheet - with Pulp and Paper Process Connections
IGP25-T	0410	MI IGP25-T/ IGP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP25-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP25-T	1209	PSS 2A-1C13 G	Product Specification Sheet
IGP25-T	1209	PSS 2A-1C13 M	Product Specification Sheet - with Sanitary Process Connections
IGP25-T	1209	PSS 2A-1C13 N	Product Specification Sheet - with Pulp and Paper Process Connections
IGP50	0209	DP 020-447	Dimensional Print
IGP50	0509	MI 020-358	Safety Information
IGP50	0810	MI 020-359	Universal Instruction Manual
IGP50	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP50	0510	PL 009-012	Parts List
IGP50	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IGP50-D	0410	MI IGP25-D/ IGP50-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP50-D	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP50-D	1209	PSS 2A-1C13 H	Product Specification Sheet
IGP50-F	0410	MI IGP25-F/ IGP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP50-F	1209	PSS 2A-1C13 H	Product Specification Sheet
IGP50-T	0410	MI IGP25-T/ IGP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP50-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP50-T	1209	PSS 2A-1C13 H	Product Specification Sheet
IGP60G	0211	MI 020-600	I/A Advanced Pressure Transmitter
IGP60G	0211	MI 020-540	I/A Advanced Pressure Transmitter Safety Information
IGP60G	0211	PSS 2A-1C18 A	Product Specification Sheet
IGP60G	0211	DP 020-600	Dimensional Print

Pressure Transmitters

Pressure Seals

Product	Date	Doc. Num	Title or Description
PSFAD	1101	DP 020-346	Dimensional Print
PSFAD	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFAD	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSFAR	1101	DP 020-345	Dimensional Print
PSFAR	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFAR	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSFES	1101	DP 020-343	Dimensional Print
PSFES	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFES	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSFLT	1101	DP 020-342	Dimensional Print
PSFLT	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFLT	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSFPS	1101	DP 020-343	Dimensional Print
PSFPS	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSFPS	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSISD	1101	DP 020-350	Dimensional Print
PSISD	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSISD	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSISR	1101	DP 020-349	Dimensional Print
PSISR	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSISR	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSSCR	1101	DP 020-351	Dimensional Print
PSSCR	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSSCR	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSSCT	0403	DP 020-355	Dimensional Print
PSSCT	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSSCT	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSSSR	0705	DP 020-353	Dimensional Print
PSSSR	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSSSR	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSSST	0705	DP 020-354	Dimensional Print
PSSST	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSSST	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSTAD	1101	DP 020-348	Dimensional Print
PSTAD	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSTAD	0209	PSS 2A-1Z11 A	Product Specification Sheet
PSTAR	1101	DP 020-347	Dimensional Print
PSTAR	0810	MI 020-369	Pressure Seals for Use With I/A Series Pressure Transmitters
PSTAR	0209	PSS 2A-1Z11 A	Product Specification Sheet

April 2011

Pressure Transmitters Pneumatic-to-Current Converters

Product	Date	Doc. Num	Title or Description
IPI10-A	1299	DP 020-414	Dimensional Print
IPI10-A	0510	MI 020-414	Installation, Calibration, Configuration, and Maintenance
IPI10-A	0510	PL 009-144	Parts List - Pneumatic-to-Current Converter
IPI10-A	0100	PSS 2A-2A4 A	IPI10 Series Pneumatic-to-Current Converter

April 2011

Pressure Transmitters Multivariable

Product	Date	Doc. Num	Title or Description
IMV25	0605	DP 020-432	Dimensional Print
IMV25	0806	MI 020-358	Safety Information
IMV25	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IMV25-D	0510	MI 020-432	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA FoxCom)
IMV25-D	0510	PL 009-019	Parts List
IMV25-D	0408	PSS 2A-1C15 B	Product Specification Sheet
IMV25-M	0510	MI 020-384	Installation, Calibration, Configuration, and Maintenance (Modbus Communications and PCMM Field Device Configurator)
IMV25-M	0510	PL 009-019	Parts List
IMV25-M	1009	PSS 2A-1C15 D	Product Specification Sheet
IMV25-T	0510	MI 020-382	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA HART)
IMV25-T	0510	PL 009-019	Parts List
IMV25-T	0408	PSS 2A-1C15 B	Product Specification Sheet
IMV30	0605	DP 020-432	Dimensional Print
IMV30	0806	MI 020-358	Safety Information
IMV30	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IMV30-D	0510	MI 020-432	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA FoxCom)
IMV30-D	0510	PL 009-018	Parts List
IMV30-D	0709	PSS 2A-1C15 A	Product Specification Sheet
IMV30-T	0510	MI 020-382	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA HART)
IMV30-T	0510	PL 009-018	Parts List
IMV30-T	0709	PSS 2A-1C15 A	Product Specification Sheet
IMV31	0605	DP 020-432	Dimensional Print
IMV31	0609	PSS 2A-1Z9 E	Product Specification Sheet Options
IMV31-T	0510	MI 020-383	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA HART)
IMV31-T	0510	PL 009-020	Parts List
IMV31-T	0809	PSS 2A-1C15 C	Product Specification Sheet

Pressure Transmitters

Other

Product	Date	Doc. Num	Title or Description
	0988	MI 020-328	Bubble Tube Installation for Measurement
	0799	MI 020-360	Wiring Guidelines for Foundation Fieldbus Transmitters
	0809	MI 022-138	1-, 2-, 3-, and 5-Valve Manifolds For Use With I/A Series Pressure Transmitter Family
	1210	PSS 3-2A1 A	Product Specification Sheet - Pressure and Receiver Elements
	1299	PSS 3-2C1 A	Product Specification Sheet - Pressure Seals
	1186	TI 37-75b	Technical Information - Material Selection Guide
	0109	TI 037-097	Technical Information - Process Sealing of Transmitters for use in Class I, Zone 0, 1, and 2 Hazardous Locations
13DEMP	0103	PL 006-180	Parts List - Transmitter with Matched Extended Pressure Seals
13DMP	0103	PL 006-180	Parts List - Transmitter with Matched Pressure Seals
13F	0209	PL 006-178	Parts List - Liquid Level or Density Styles C and D
13FE	0209	PL 006-178	Parts List - Liquid Level or Density Styles E and F
D0170MB thru MJ	0598	MI 020-412	Mounting Hardware Kits to Replace 823DP, 843DP and 863DP with IDP10
HHT	0197	MI 020-400	Pocket Guide with I/A Series Pressure Transmitters
MB3	0809	DP 022-148	Dimensional Print - 3-Valve Manifolds
MB3	0809	PL 006-152	Parts List - 3-Valve Manifold
MB3	0809	PSS 2B-1Z2 A	Product Specification Sheet - 3-Valve Manifolds
MB5G	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
MB5G	0809	PL 006-152	Parts List - 5-Valve Manifold
MB5G	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
MB5P	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
MB5P	0809	PL 006-152	Parts List - 5-Valve Manifold
MB5P	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
MH	1002	PL 002-101	Parts List - Pressure Gauges
M4A	0809	DP 022-148	Dimensional Print - 3-Valve Manifold
M4A	0809	PL 006-152	Parts List - 3-Valve Manifold
M4A	0809	PSS 2B-1Z2 A	Product Specification Sheet - 3-Valve Manifolds
M4AP	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
M4AP	0809	PL 006-152	Parts List - 2-Valve Manifold
M4AP	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds

Pressure Transmitters

Other

Product	Date	Doc. Num	Title or Description
M4T	0809	DP 022-148	Dimensional Print - 3-Valve Manifold
M4T	0809	PL 006-152	Parts List - 3-Valve Manifold
M4T	0809	PSS 2B-1Z2 A	Product Specification Sheet - 3-Valve Manifolds
M4TP	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
M4TP	0809	PL 006-152	Parts List - 2-Valve Manifold
M4TP	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds
M6T	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
M6T	0809	PL 006-152	Parts List - 5-Valve Manifold
M6T	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
M6TA	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
M6TA	0809	PL 006-152	Parts List - 5-Valve Manifold
M6TA	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
M9	0208	DP 022-146	Dimensional Print - 1-Valve Manifold (Block and Bleed Valve)
M9	0809	PL 006-152	Parts List - 1-Valve Manifold (Block and Bleed Valve)
M9	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds
M24A	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
M24A	0809	PL 006-152	Parts List - 5-Valve Manifold
M24A	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
M24T	0809	DP 022-149	Dimensional Print - 5-Valve Manifold
M24T	0609	PL 006-152	Parts List - 5-Valve Manifold
M24T	0809	PSS 2B-1Z2 A	Product Specification Sheet - 5-Valve Manifolds
M25	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
M25	0809	PL 006-152	Parts List - 2-Valve Manifold
M25	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds
PTM	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
PTM	0809	PL 006-152	Parts List - 2-Valve Manifold
PTM	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds
PT7	0809	DP 022-147	Dimensional Print - 2-Valve Manifold
PT7	0809	PL 006-152	Parts List - 2-Valve Manifold
PT7	0809	PSS 2B-1Z2 A	Product Specification Sheet - 2-Valve Manifolds

Product	Date	Doc. Num	Title or Description
	0801	B0193XX	Field Device Integration Checklist
HHT50	0108	MI 020-500	Configurator for use with Intelligent Field Devices
HHT50	1008	PL009-154	Parts List - use with Intelligent Field Devices
HHT50	0209	PSS 2A-1Z3 L	Product Specification Sheet - use with Intelligent Field Devices
PC20	1010	MI 020-495	Intelligent Field Device Configurator
PC20	1102	PL 009-156	Parts List
PC20	1102	PSS 2A-1Z3 E	Product Specification Sheet
PC50	0108	MI 020-501	Field Device Tool - Installation and Parts List
PC50	0809	MI 020-504	Field Device Tool - Operation Using FoxCom Communication Protocol
PC50	0208	MI 020-505	Field Device Tool - Operation Using HART Communication Protocol
PC50	1210	MI 020-520	Field Device Tool with Advanced DTM Library - Operation Using HART Communication Protocol
PC50	0209	PSS 2A-1Z3 G	Product Specification Sheet
PCMM	0510	MI 020-384	Installation, Calibration, Configuration, and Maintenance (Used with IMV25-M Modbus Communications)
PCMM	1104	PL 009-158	Parts List - used with IMV225-M
PCMM	1004	PSS 2A-1Z3 H	Product Specification Sheet- used with IMV25-M
PCMV	1104	MI 020-496	Intelligent Field Device Configurator for IMV25 and IMV30 Multivariable Transmitters
PCMV	0809	MI 020-497	Intelligent Field Device Configurator for IMV31 Multivariable Transmitters
PCMV	0904	PL 009-157	Parts List - used with IMV25, IMV30 and IMV31
PCMV	1108	PSS 2A-1Z3 F	Product Specification Sheet - used with IMV25, IMV30 and IMV31

Product	Date	Doc. Num	Title or Description
12A	0606	PL 006-330	Parts List
12A	0201	PSS 2B-1B1 A	Product Specification Sheet
MT	0207	DP 016-130	Dimensional Print
MT	0909	MI 016-128	MINOX Thermocouples Style B
MT	0207	PL 008-108	Parts List
MT	0909	PSS 1-1B6 A	Product Specification Sheet
PR	0207	DP 016-131	Dimensional Print
PR	0909	MI 016-131	Platinum Resistance Temperature Detectors (RTD) Style C
PR	0207	PL 008-111	Parts List
PR	0909	PSS 1-1B1 A	Product Specification Sheet
RTT15	0108	DP 020-462	Dimensional Print
RTT15	0607	MI 020-449	Intrinsic Safety Connection Diagrams
RTT15-F	0707	MI 020-462	Temperature Transmitter with FOUNDATION Fieldbus Protocol
RTT15-F	0908	PL 008-662	Parts List
RTT15-F	0709	PSS 2A-1F5 A	Product Specification Sheet
RTT15-P	0707	MI 020-462	Temperature Transmitter with PROFIBUS Protocol
RTT15-P	0908	PL 008-662	Parts List
RTT15-P	0709	PSS 2A-1F5 A	Product Specification Sheet
RTT15-T	0108	MI 020-463	Temperature Transmitter with HART Protocol
RTT15-T	0908	PL 008-662	Parts List
RTT15-T	0709	PSS 2A-1F5 A	Product Specification Sheet
RTT20	0108	DP 020-460	Dimensional Print
RTT20	0408	MI 020-453	Installation, Calibration, Configuration, and Maintenance
RTT20	0399	MI 020-454	Intrinsic Safety
RTT20	1096	MI 020-460	Operation, Configuration, and Calibration using HART M275 Configurator
RTT20	0596	MI 020-461	Configuration Menu Flowchart for 1-Line LCD Indicator
RTT20	0398	MI 020-469	Operation, Calibration, and Configuration Using HHT
RTT20	0509	PL 008-659	Parts List
RTT20	0408	PSS 2A-1F4 A	Product Specification Sheet
RTT20	0701	PSS 2A-1Z9 F	Product Specification Sheet Options
RTT25-F	0108	DP 020-461	Dimensional Print
RTT25-F	0605	MI 014-900	Fieldbus Overview
RTT25-F	0207	MI 020-488	Installation, Calibration, Local/Remote Configuration and Maintenance
RTT25-F	0310	PL 008-661	Parts List
RTT25-F	0210	PSS 2A-1F4 C	Product Specification Sheet
RTT25-F	0701	PSS 2A-1Z9 F	Product Specification Sheet
RTT30	0110	DP 020-530	Dimensional Print
RTT30	0310	MI 020-530	Temperature Transmitter with HART Protocol
RTT30	1210	MI 020-531	Temperature Transmitter Safety Information
RTT30	0110	MI RTT30	FM and CSA Safety Drawings
RTT30-A	1210	PSS 2A-1F6 A	Product Specification Sheet - HART Communications
RTT30-F	1210	PSS 2A-1F6 B	Product Specification Sheet - FOUNDATION Fieldbus Communications
RTT30	1210	MI 020-532	RTT30 I/A Series Temperature Transmitter

April 2011

Temperature Thermowells

Product	Date	Doc. Num	Title or Description
TF	0307	DP 002-110	Dimensional Print - Flanged Thermowells
TF	1008	PSS 3-3D1 A	Product Specification Sheet - Flanged Thermowells
TS	0307	DP 002-111	Dimensional Print - Sanitary Thermowells
TS	1008	PSS 3-3D1 A	Product Specification Sheet - Sanitary Thermowells
TT	0307	DP 002-112	Dimensional Print - Threaded Thermowells
TT	1008	PSS 3-3D1 A	Product Specification Sheet - Threaded Thermowells
TW	0307	DP 002-113	Dimensional Print - Weld-In Thermowells
TW	1008	PSS 3-3D1 A	Product Specification Sheet - Weld-In Thermowells

Product	Date	Doc. Num	Title or Description
83	0409	B0800AB	Ensuring Premium Performance with Foxboro Intelligent Vortex Flowmeters
83	0908	MI 019-191	Amplifier Replacement for Conventional and Intelligent Vortex Flowmeters
83	0109	MI 019-179	Flow Safety Information
83	0403	MI 019-188	Conversion from Analog, FoxCom, or HART to FOUNDATION Fieldbus - Kit Numbers K0147VN and K0148VN
83	0205	MI 019-198	Addition or Replacement of Digital Display/Configurator Kits K0147EK, K0147HT , and K0147HU
83	0410	MI 019-209	Sensor Replacement Kits
83.-D	1000	MI 019-175	Intrinsic Safety Connection Diagrams
83.-F	0605	MI 014-900	Fieldbus Overview
83.-T	1000	MI 019-175	Intrinsic Safety Connection Diagrams
83F	0309	DP 019-150	Dimensional Print for Single Measurement Configuration
83F	0309	DP 019-151	Dimensional Print for Dual Measurement Configuration
83F	0610	MI 019-145	Universal Instruction Manual - Installation and Startup
83F	0297	MI 019-197	Convert Integral to Remote
83F-A	0596	MI 019-152	European Installations
83F-A	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
83F-A	0608	PL 008-708	Parts List
83F-A	0608	PSS 1-8A1 D	Product Specification Sheet
83F-D	0496	MI 019-153	European Installations
83F-D	0507	MI 019-194	Installation, Configuration, Troubleshooting, and Maintenance
83F-D	0608	PL 008-708	Parts List
83F-D	0608	PSS 1-8A1 E	Product Specification Sheet
83F-F	0907	MI 019-193	Flowmeters with FOUNDATION Fieldbus
83F-F	0608	PL 008-708	Parts List
83F-F	0608	PSS 1-8A1 F	Product Specification Sheet
83F-T	0397	MI 019-154	European Installations
83F-T	0111	MI 019-199	Installation, Configuration, Troubleshooting, and Maintenance
83F-T	0608	PL 008-708	Parts List
83F-T	0608	PSS 1-8A1 E	Product Specification Sheet
83S	0197	DP 019-154	Dimensional Print Sanitary
83S	0610	MI 019-145	Universal Instruction Manual - Installation and Startup
83S-A	0507	MI 019-173	Sanitary Installation, Troubleshooting, and Maintenance
83S-A	0297	PL 008-713	Parts List
83S-A	0710	PSS 1-8A2 E	Product Specification Sheet
83S-D	0507	MI 019-195	Sanitary Installation, Configuration, Troubleshooting, and Maintenance
83S-D	0205	MI 019-198	Addition of Digital Display and Configuration
83S-D	0297	PL 008-713	Parts List
83S-D	0710	PSS 1-8A2 D	Product Specification Sheet

Product	Date	Doc. Num	Title or Description
83S-T	0507	MI 019-174	Sanitary Installation, Troubleshooting, and Maintenance
83S-T	0297	PL 008-713	Parts List
83S-T	0409	PSS 1-8A2 D	Product Specification Sheet
83W	0702	DP 019-152	Dimensional Print Wafer Body
83W	0610	MI 019-145	Universal Instruction Manual - Installation and Startup
83W	0297	MI 019-197	Convert Integral to Remote
83W-A	0596	MI 019-152	European Installations
83W-A	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
83W-A	0107	PL 008-708	Installation, Troubleshooting, and Maintenance
83W-A	0700	PL 008-709	Parts List
83W-A	0608	PSS 1-8A1 D	Product Specification Sheet
83W-D	0496	MI 019-153	European Installations
83W-D	0507	MI 019-194	Installation, Configuration, Troubleshooting, and Maintenance
83W-D	0205	MI 019-198	Addition of Digital Display and Configuration
83W-D	0700	PL 008-709	Parts List
83W-D	0608	PSS 1-8A1 E	Product Specification Sheet
83W-F	0907	MI 019-193	Flowmeters with FOUNDATION Fieldbus
83W-F	0700	PL 008-709	Parts List
83W-F	0608	PSS 1-8A1 F	Product Specification Sheet
83W-T	0397	MI 019-154	European Installations
83W-T	0111	MI 019-199	Installation, Configuration, Troubleshooting, and Maintenance
83W-T	0700	PL 008-709	Parts List
83W-T	0608	PSS 1-8A1 E	Product Specification Sheet
84	0310	B0800AJ	Ensuring Premium Performance with Foxboro Intelligent Vortex Flowmeters
84	0610	MI 019-146	Universal Instruction Manual - Installation and Startup
84	1210	MI 019-177	FM and CSA Certification Connection Diagrams
84	0109	MI 019-179	Flow Safety Information
84	0410	MI 019-209	Sensor Replacement Kits
84F	0309	DP 019-120	Dimensional Print for Single Measurement Configuration
84F	0309	DP 019-121	Dimensional Print for Dual Measurement Configuration
84F	1209	PSS 1-8A3 A	Product Specification Sheet
84F-L	0410	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84F-L	0410	PL 008-714	Parts List - Low Power with Pulse Output
84F-L	0710	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, Pulse Output, with HART
84F-M	0410	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84F-M	0410	PL 008-714	Parts List - Low Power without Pulse Output
84F-M	0710	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, with HART
84F-T	0410	MI 019-202	with HART - Installation, Operation, and Maintenance
84F-T	0410	PL 008-714	Parts List - with Pulse Output
84F-U	0410	MI 019-202	with HART - Installation, Operation, and Maintenance
84F-U	0410	PL 008-714	Parts List - without Pulse Output

Product	Date	Doc. Num	Title or Description
84S	1006	DP 019-123	Dimensional Print Sanitary
84S	0409	PSS 1-8A5 A	Product Specification Sheet
84S-L	0410	MI 019-214	Low Power with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-L	0410	PL 008-717	Parts List - Low Power with Pulse Output
84S-L	0710	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, Pulse Output, with HART
84S-M	0410	MI 019-214	Low Power with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-M	0410	PL 008-717	Parts List - Low Power without Pulse Output
84S-M	0710	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, with HART
84S-T	0410	MI 019-205	with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-T	0410	PL 008-717	Parts List - with Pulse Output
84S-U	0410	MI 019-205	with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-U	0410	PL 008-717	Parts List - without Pulse Output
84W	1006	DP 019-122	Dimensional Print Wafer Body
84W	1209	PSS 1-8A3 A	Product Specification Sheet
84W-L	0410	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84W-L	0410	PL 008-714	Parts List - Low Power with Pulse Output
84W-L	0710	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, Pulse Output, with HART
84W-M	0410	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84W-M	0410	PL 008-714	Parts List - Low Power without Pulse Output
84W-M	0710	PSS 1-8A6 A	Product Specification Sheet- LOW POWER, with HART
84W-T	0410	MI 019-202	with HART - Installation, Operation, and Maintenance
84W-T	0410	PL 008-714	Parts List - with Pulse Output
84W-U	0410	MI 019-202	with HART - Installation, Operation, and Maintenance
84W-U	0410	PL 008-714	Parts List - without Pulse Output
E83	0908	MI 019-191	Amplifier Replacement for Conventional and Intelligent Vortex Flowmeters
E83F	0398	MI 019-166	Sensor/Amplifier Replacement
E83FA	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
E83FA	0297	MI 019-196	Convert to 83F-D, 83S-D, or 83W-D Style A
E83L	0398	MI 019-166	Sensor/Amplifier Replacement
E83SA	0297	MI 019-196	Convert to 83F-D, 83S-D, or 83W-D Style A
E83W	0398	MI 019-166	Sensor/Amplifier Replacement
E83WA	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
E83WA	0297	MI 019-196	Convert to 83F-D, 83S-D, or 83W-D Style A

April 2011

Other Totalizer and Flow Computer

Product	Date	Doc. Num	Title or Description
75LBA	1193	DP 019-543	Dimensional Print
75LBA	0298	MI 019-589	Pulse Input Liquid Batch Totalizer
75LBA	0398	MI 019-590	Analog Input Liquid Batch Totalizer
75LBA	1193	PL 008-727	Parts List
75LBA	1093	PSS 1-9C1 A	Product Specification Sheet
75MCA	0794	DP 019-542	Dimensional Print
75MCA	0398	MI 019-591	Pulse Input Liquid Mass Computer
75MCA	0498	MI 019-592	Analog Input Liquid Mass Computer
75MCA	0598	MI 019-594	Pulse Input Gas/Steam Mass Computer
75MCA	0598	MI 019-595	Analog Input Gas/Steam Mass Computer
75MCA	0794	PL 008-728	Parts List
75MCA	0397	PSS 1-9D1 A	Product Specification Sheet
75RTA	0794	DP 019-542	Dimensional Print
75RTA	0298	MI 019-587	Pulse Input Ratemeter Totalizer
75RTA	0298	MI 019-588	Analog Input Ratemeter Totalizer
75RTA	0393	PSS 1-9B1 A	Product Specification Sheet

April 2011

Other Positioners and I/P Converters

Product	Date	Doc. Num	Title or Description
E69F	0506	DP 018-430	Dimensional Print
E69F	0610	MI 018-429	Current-to-Pneumatic Converter - Safety Information
E69F	0605	MI 018-430	Current-to-Pneumatic Converter - Field Mounted
E69F	0906	PL 008-645	Parts List
E69F	0906	PSS 2B-2A3 B	Product Specification Sheet
E69P	0506	DP 018-440	Dimensional Print
E69P	0610	MI 018-429	Current-to-Pneumatic Valve Positioner - Safety Information
E69P	0185	MI 018-440	Current-to-Pneumatic Valve Positioner
E69P	0802	PL 008-647	Parts List
E69P	0510	PSS 4-10A2 A	Product Specification Sheet
E69R	0802	PL 008-646	Parts List
E69R	0407	PSS 2B-2A2 A	Product Specification Sheet
P91PA	0504	PL 005-365	Parts List - Poweractor
P91T	0706	DP 014-132	Dimensional Print
P91T	0802	MI 014-132	Type CP Pneumatic Position Transmitter
P91T	0802	PL 006-320	Parts List
P91T	0104	PSS 2B-1B1 B	Product Specification Sheet
P91V	0802	DP 012-340	Dimensional Print
P91V	0802	MI 012-340	Type C Vernier VALVACTOR - Yoke Mounted
P91V	0802	PL 005-320	Parts List

Other Miscellaneous

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0902	MI 014-101	Sulfur Detection Using Lead Acetate Test Paper
	0408	PL 000-001	Master Book 150 Table of Contents
	0408	PL 000-002	Master Book 150 Index by Model
	0903	PL 001-110	Chart Drives - Parts List
	1008	TI 037-094	Quality Assurance Certificates for Non-Nuclear Parts and Products
B0110AS	0506	PL 005-420	Parts Lists - Air Filter Set
B0110AT	0506	PL 005-420	Parts Lists - Air Filter Set
B0110ZA	0506	PL 005-420	Parts Lists - Air Filter Set
B0123HE	0506	PL 005-420	Parts Lists - Adjustable Pressure Regulator with Filter
B0123HF	0506	PL 005-420	Parts Lists - Adjustable Pressure Regulator without Filter
B0197BA	0506	PL 005-420	Parts Lists - Air Filter Assembly
B1278HE	0506	DP 011-159	Dimensional Print - Adjustable Pressure Regulator
B1278HE	0506	PL 005-420	Parts Lists - Adjustable Pressure Regulator
CO	1107	DP 022-335	Dimensional Print - Compact Orifice with d/p Cell Transmitters
CO	1003	MI 022-335	Compact Orifice with d/p Cell Transmitters
CO	1003	PL 006-172	Parts List - Compact Orifice with d/p Cell Transmitters
CO	1003	PSS 3-5A1 E	Product Specification Sheet - Compact Orifice with d/p Cell Transmitters
IFOA	0707	MI 022-333	Integral Flow Orifice Assembly
IFOA	0607	PL 006-174	Parts List - Integral Flow Orifice Assembly
IFOA	0609	PSS 3-5A1 B	Integral Flow Orifice Assembly used with d/p Cell Transmitter
MAC	0802	PL 005-356	Air Cylinders - Parts List
PF100AX	1003	MI 018-180	75 V dc Multiloop Power Supply
P0300CQ	1003	MI 018-180	75 V dc Multiloop Power Supply
14A	0110	PL 003-525	Pneumatic Flow Integrator - Parts List
17BS	1205	PL 006-318	Side Mounted Buoyancy Transmitter - Parts List
17BT	1205	PL 006-318	Top Mounted Buoyancy Transmitter - Parts List
556	0410	MI 017-284	Pneumatic Analog Computer - Maintenance and Servicing
556	1105	PL 006-345	Pneumatic Analog Computer - Parts List
557	0108	PL 006-346	Pneumatic Square Root Extractor - Parts List

April 2011

Other Miscellaneous

Page 2 of 2

Product	Date	Doc. Num	Title or Description
2761	0908	PL 008-102	Mechanical DEWCEL - Parts List
2761	0908	PSS 1-5A1 A	Mechanical DEWCEL - Product Specification Sheet
2781	0908	DP 008-103	Electrical DEWCEL Element - Dimensional Print
2781	0908	MI 003-318	Dew Point Measurement with DEWCEL Element - Electrical Temperature Measurement
2781	0908	PL 008-102	Electrical DEWCEL, Basic Sensor - Parts List
2781	0908	PSS 1-5A1 A	Electrical DWECCEL - Product Specification Sheet