

Controllers, Indicators, and Recorders

Controllers

Page 1 of 2

Product	Date	Doc. Num	Title or Description
37	0108	PL 003-320	Parts List: Diaphragm Meter With Intermediate Linkage
37	0403	PSS 3-4A2 A	Product Specification Sheet: Diaphragm Measuring Element
40	0702	PL 001-105	Parts List: Box Pens, Pen-Arms, Indexes for Instruments
40	0702	PL 001-345	Parts List: Indicating Scale and Light Assemblies for Instruments
40C	0713	MI 011-490	Control Relays
40C	1012	PL 004-459	Control Relays
40D	1012	PL 004-459	Control Relays
40G	1012	PL 004-459	Control Relays
40K	1012	PL 004-459	Control Relays
40M	0702	PL 001-105	Parts List: Box Pens, Pen-Arms, Indexes for Instruments
40M	0702	PL 001-345	Parts List: Indicating Scale and Light Assemblies for Instruments
40M	0711	PL 004-111	Parts List: Recording Pneumatic Controllers, On-Off or Narrow Band Proportional Types
40M	0112	PL 004-112	Parts List: Indicating Pneumatic Controllers, On-Off or Narrow Band Proportional Types
40M	0410	PL 004-116	Parts List: Recording Pneumatic Controllers, Proportional Types
40M	0711	PL 004-121	Parts List: Dual or Duplex, On-Off or Narrow Band Types
40M	0410	PL 004-126	Parts List: Dual or Duplex Proportional Types
40M	0112	PL 004-140	Parts List: Right-Hand Proportional Types (except Narrow Band)
40M	0112	PL 004-142	Parts List: Left-Hand Proportional Types (except Narrow Band)
40M	0711	PSS 3-1A1 A	Product Specification Sheet
40P	0702	PL 001-105	Parts List: Box Pens, Pen-Arms, Indexes for Instruments
40P	0702	PL 001-345	Parts List: Indicating Scale and Light Assemblies for Instruments
40P	0711	PL 004-111	Parts List: Recording Pneumatic Controllers, On-Off or Narrow Band Proportional Types
40P	0112	PL 004-112	Parts List: Indicating Pneumatic Controllers, On-Off or Narrow Band Proportional Types
40P	0410	PL 004-116	Parts List: Recording Pneumatic Controllers, Proportional Types
40P	0711	PL 004-121	Parts List: Dual or Duplex, On-Off or Narrow Band Types
40P	0410	PL 004-126	Parts List: Dual or Duplex Proportional Types
40P	0112	PL 004-140	Parts List: Right-Hand Proportional Types (except Narrow Band)
40P	0112	PL 004-142	Parts List: Left-Hand Proportional Types (except Narrow Band)
40P	0711	PSS 3-1A2 A	Product Specification Sheet: Pressure Recorders, Indicators, and Recording or Indicating Controllers
40P	0201	PSS 3-1A2 B	Product Specification Sheet: Temperature Recorders, Indicators, and Recording or Indicating Controllers
40P	0403	PSS 3-1A2 C	Product Specification Sheet: Flow Recorders, Indicators, and Controllers
43AP	0306	DP 011-476	Dimensional Print
43AP	0180	MI 011-476	Installation and Operation
43AP	0486	MI 011-477	Servicing
43AP	0486	MI 011-481	Maintenance and Alignment
43AP	0414	PL 004-484	Parts List
43AP	1210	PSS 3-1B3 A	Product Specification Sheet: Pneumatic Indicating Controllers

Controllers, Indicators, and Recorders

Controllers

Page 2 of 2

Product	Date	Doc. Num	Title or Description
43AP	0101	PSS 3-1B3 B	Product Specification Sheet: Controllers for Electronic Inputs
43APG	0114	PL 004-494	Parts List
130	0713	PL 004-560	Parts List: Automatic Control Section for Controllers
130M	0806	DP 017-450	Dimensional Print
130M	0578	MI 017-450	Installation and Maintenance
130M	0179	PL 004-550	Parts List
130M	0495	PSS 2B-4H1 A	Product Specification Sheet
138	1112	PSS 2B-4H1 M	Product Specification Sheet
138SP	1012	PL 004-590	Field-Mounted Pneumatic Controller
138LP	1012	PL 004-595	Field-Mounted Pneumatic Controller
716C	1196	DP 018-575	Dimensional Print
716C	0297	MI 018-575	1/6 DIN Temperature
716C	0597	MI 018-579	1/16 DIN and 1/8 DIN Temperature Serial Communications Guide
716C	1196	PSS 2C-1B5 A	Product Specification Sheet
718P	1196	DP 018-574	Dimensional Print
718P	0297	MI 018-574	1/8 DIN Temperature with Series Interface
718P	0597	MI 018-578	1/8 DIN Process Serial Communications Guide
718P	1196	PSS 2C-1B4 A	Product Specification Sheet
718TC	1196	DP 018-572	Dimensional Print
718TC	0297	MI 018-573	1/8 DIN Temperature with mA Output
718TC	0597	MI 018-579	1/16 DIN and 1/8 DIN Temperature Serial Communications Guide
718TC	1196	PSS 2C-1B3 A	Product Specification Sheet
740C	0905	MI 018-871	Digital Circular Chart Recorder and Recording Controller - Installation, Operation, Configuration, and Maintenance
740C	1005	PL 009-166	Parts List
740C	1005	PSS 2C-1A7 A	Product Specification Sheet
762	0398	MI 018-888	Serial Communications Guide
762	0895	TI 039-200	Technical Information
762C	0696	PSS 2C-1A1 D	Product Specification Sheet
762CNA	0906	DP 018-836	Dimensional Print
762CNA	0298	MI 018-885	SINGLE STATION MICRO
762CNA	0499	PL 009-136	Parts List
762CSA	0298	MI 018-889	Shelf Mounted
762CSA	1210	PL 009-139	Parts List
P110A	1012	DP 005-232	P110A Pneumatic Diaphragm Actuator with Yoke

Controllers, Indicators, and Recorders

Indicators

Product	Date	Doc. Num	Title or Description
45P	1210	PSS 2B-1H1 E	Product Specification Sheet
65FS	1006	MI 018-272	Field Mounted
65FS	0210	PL 008-559	Parts List
65FS	0210	PSS 2A-3B1 C	Product Specification Sheet
65P	1213	PSS 2A-3B1 A	Product Specification Sheet
65P	1013	DP 018-275	Dimensional Print: 65PX-JY Panel Mounted Indicators
65P	1013	DP 018-279	Dimensional Print: 65PV-HY, 65PV-JY, and 65PV-VY Series (Vertical) Indicating Receiver - Milliammeter
710D	1196	DP 018-571	Dimensional Print
710D	0297	MI 018-571	1/8 DIN Digital
710D	0597	MI 018-576	Digital Serial Communications Guide
710D	1196	PSS 2C-1B2 A	Product Specification Sheet

Controllers, Indicators, and Recorders

Recorders

Product	Date	Doc. Num	Title or Description
40	0705	MI 001-130	Instrument Mounting and Connections Model 40 Recorders - Installation
40M	0705	MI 001-145	Mullins Chart Changers for Recorder - Installation and Operation (AS Reference MCC)
40M	0410	PL 001-301	Parts List: Circular Chart Recorder
40P	0705	MI 001-145	Mullins Chart Changers for Recorder - Installation and Operation (AS Reference MCC)
40P	0410	PL 001-301	Parts List: Circular Chart Recorder
120	0603	PL 006-413	Parts List: Style D
120	0509	PL 006-414	Parts List: Style E
120	1004	PL 006-416	Parts List: Chart Drives for 120 Series
120	1213	PSS 2B-3E1 A	Product Specification Sheet
740R	0905	MI 018-871	Digital Circular Chart Recorder and Recording Controller - Installation, Operation, Configuration, and Maintenance
740R	1005	PL 009-166	Parts List
740R	1005	PSS 2C-1A8 A	Product Specification Sheet
752RNA	0402	PSS 2C-1A16 A	Product Specification Sheet
763MNA	0901	PL 009-178	Parts List
763MNA	0402	PSS 2C-1A15 A	Product Specification Sheet
6100AF	1208	DP 018-910	Dimensional Print
6100AF	0809	MI 018-910	Paperless Graphic Recorders
6100AF	0110	PL 009-190	Parts List
6100AF	0513	PSS 2C-1C1 A	Product Specification Sheet: Paperless Graphic Recorder
6180AF	1208	DP 018-910	Dimensional Print
6180AF	0809	MI 018-910	Paperless Graphic Recorders
6180AF	0809	PL 009-190	Parts List
6180AF	0513	PSS 2C-1C1 A	Product Specification Sheet: Paperless Graphic Recorder
E20S	0701	PSS 2A-3A1 C	Product Specification Sheet

Electrochemical Analyzers

Page 1 of 2

Product	Date	Doc. Num	Title or Description
BS810NX	1104	MI 611-226	Remote Communications Program for 875 Analyzers
BS811BV	0509	MI 611-207	Conversion Kit to Add HART Capability to 875 Series Analyzers
BS811FN	0206	MI 611-228	General Purpose Firmware Upgrade Kit for 875 Analyzers
BS811GC	1002	MI 611-189	Static Charge Control Upgrade for 875PH Analyzers
BS811GD	1002	MI 611-189	Static Charge Control Upgrade for 873PH-.P Analyzers
BS811GE	1002	MI 611-189	Static Charge Control Upgrade for 873PH-*W, *X, *Y, or *Z Analyzers
873	0711	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
873A	1003	PSS 6-1C1 F	Product Specification Sheet
873ACC	0604	MI 611-192	Ace Series Analyzers for Contacting Conductivity Measurement
873AEC	0604	MI 611-193	Ace Series Analyzers for Electrodeless Conductivity Measurement
873APH	0604	MI 611-191	Ace Series Analyzers for pH Measurements
873ARS	0604	MI 611-194	Ace Series Analyzers for Resistivity Measurements
873CC	0608	DP 611-162	Dimensional Print
873CC	0604	MI 611-166	Contact/Conductivity Measurement
873CC	1295	PL 611-016	Parts List
873CC	1003	PSS 6-1C1 E	Product Specification Sheet
873DO	0608	DP 611-149	Dimensional Print
873DO	0608	DP 611-162	Dimensional Print
873DO	0705	MI 611-169	Dissolved Oxygen Measurement
873DO	1295	PL 611-016	Parts List
873DO	1003	PSS 6-1C1 E	Product Specification Sheet
873DPX	0608	DP 611-162	Dimensional Print
873DPX	0604	MI 611-190	pH/ORP/ISE Measurement
873DPX	1295	PL 611-016	Parts List
873DPX	0594	PSS 6-1C1 B	Product Specification Sheet: Remote Preamplifier
873DPX	1003	PSS 6-1C1 E	Product Specification Sheet: Electrochemical Analyzers
873EC	0608	DP 611-162	Dimensional Print
873EC	0409	MI 611-167	Electrodeless Conductivity Measurement
873EC	0409	MI 611-220	System Calibration Examples
873EC	1295	PL 611-016	Parts List
873EC	1003	PSS 6-1C1 E	Product Specification Sheet
873PH	0608	DP 611-162	Dimensional Print
873PH	0604	MI 611-165	pH and ORP Measurement
873PH	1295	PL 611-016	Parts List
873PH	0594	PSS 6-1C1 B	Product Specification Sheet: Remote Preamplifier
873PH	1003	PSS 6-1C1 E	Product Specification Sheet: Electrochemical Analyzers
873RS	0608	DP 611-162	Dimensional Print
873RS	1005	MI 611-168	Resistivity Measurement
873RS	1295	PL 611-016	Parts List
873RS	1003	PSS 6-1C1 E	Product Specification Sheet
875	0711	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
875	0509	MI 611-207	Conversion Kit BS811BV to Add HART Communication Capability

Electrochemical

Analyzers

Page 2 of 2

Product	Date	Doc. Num	Title or Description
875	0711	MI 611-208	Safety Information
875	1104	MI 611-226	Remote Communications Program BS810NX
875	1004	MI 611-227	Operation, Configuration and Calibration Using a HART Communicator
875	0206	MI 611-228	General Purpose Firmware Upgrade Kit BS811FN
875	0508	MI 611-246	Remote Communications
875CR	0500	DP 611-164	Dimensional Print
875CR	0809	MI 611-222	Contacting Conductivity and Resistivity Measurements
875CR	0206	PL 611-158	Parts List: Style A
875CR	1006	PL 611-163	Parts List: Styles C-D
875CR	1206	PSS 6-3A1 B	Product Specification Sheet
875EC	0500	DP 611-164	Dimensional Print
875EC	0809	MI 611-224	Electrodeless Conductivity Measurement
875EC	0409	MI 611-220	System Calibration Examples
875EC	0206	PL 611-158	Parts List: Style A
875EC	1006	PL 611-163	Parts List: Styles C-D
875EC	0209	PSS 6-3N1 C	Product Specification Sheet
875PH	0500	DP 611-164	Dimensional Print
875PH	0809	MI 611-225	pH, ORP, or Ion Selective Electrode (ISE) Measurement - Style C
875PH	0206	PL 611-158	Parts List: Style A
875PH	1006	PL 611-163	Parts List: Styles B-C
875PH	1206	PSS 6-1A1 E	Product Specification Sheet

Electrochemical Transmitters

Product	Date	Doc. Num	Title or Description
870IT	0711	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
870IT	0595	MI 611-213	Conversion Kit-C-BS806ZP to Add Rain Door Assembly
870IT	0711	MI 611-208	Safety Information
870ITEC	0398	DP 611-163	Dimensional Print
870ITEC	0409	MI 611-212	Electrodeless Conductivity Measurements
870ITEC	0409	MI 611-220	System Calibration Examples
870ITEC	1002	PL 611-153	Parts List: Style B
870ITEC	1002	PL 611-156	Parts List: Style A
870ITEC	0509	PSS 6-3N2 A	Product Specification Sheet
870ITPH	0398	DP 611-163	Dimensional Print
870ITPH	1005	MI 611-211	pH, ORP, and ION Selective Electrode Measurements
870ITPH	1002	PL 611-153	Parts List: Style B
870ITPH	1002	PL 611-156	Parts List: Style A
870ITPH	0509	PSS 6-1B1 B	Product Specification Sheet
876PH	0510	DP 611-260	Dimensional Print
876PH	0810	MI 611-262	Intelligent Transmitter for pH, ORP, and ISE Measurement
876PH	0711	PL 611-260	Parts List: Style A
876PH	0810	PSS 6-1A4 A	Product Specification Sheet
876EC	0510	DP 611-260	Dimensional Print
876EC	0811	PSS 6-3N3 A	Model 876EC Intelligent Transmitter for Electrodeless Conductivity
876EC	1012	MI 611-261	Model 876EC Intelligent Electrochemical Transmitter
876EC	0711	PL 611-260	Model 876PH, 876CR, 876EC Parts List: Style A
876CR	0510	DP 611-260	Dimensional Print
876CR	1111	PSS 6-3A2 A	Model Product Specification Sheet
876CR	1111	MI 611-260	Model 876CR Intelligent Electrochemical Transmitter for Contacting Conductivity and Resistivity Measurements
876CR	0711	PL 611-260	Model 876PH, 876CR, 876EC Parts List: Style A

Electrochemical

pH and ORP Sensors

Page 1 of 2

Product	Date	Doc. Num	Title or Description
BS810FA	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871PH Titanium
BS810FB	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871PH 316 ss
BS811HZ	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871A 316 ss
BS811JC	1202	MI 611-209	PH10/ORP10 BVI Adapter Kit Replace 871A Titanium
ORP10	1103	DP 611-171	Dimensional Print: DolpHin® Series pH and ORP Sensors
ORP10	0513	DP 611-172	Dimensional Print: Legacy Insertion Tube and Ball Valve Assemblies for DolpHin Series pH and ORP Sensors
ORP10	1103	DP 611-173	Dimensional Print: Mounting Accessories for DolpHin
ORP10	0513	DP 611-182	Dimensional Print: BVA Series Ball Valve Insertion Assemblies for DolpHin® Series pH and ORP Sensors
ORP10	0902	MI 611-204	Use of Universal Bushing with DolpHin Sensors (BS810XB and BS810XC)
ORP10	0114	MI 611-205	DolpHin - Installation, Troubleshooting, Maintenance, and Parts List
ORP10	0711	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
ORP10	0711	MI 611-208	Safety Information
ORP10	0513	PSS 6-1C3 A	Product Specification Sheet
PH10	1103	DP 611-171	Dimensional Print: DolpHin® Series pH and ORP Sensors
PH10	0513	DP 611-172	Dimensional Print: Legacy Insertion Tube and Ball Valve Assemblies for DolpHin® Series pH and ORP Sensors
PH10	1103	DP 611-173	Dimensional Print: Mounting Accessories for DolpHin
PH10	0513	DP 611-182	Dimensional Print: BVA Series Ball Valve Insertion Assemblies for DolpHin® Series pH and ORP Sensors
PH10	0902	MI 611-204	Use of Universal Bushing with DolpHin Sensors (BS810XB and BS810XC)
PH10	0114	MI 611-205	DolpHin - Installation, Troubleshooting, Maintenance, and Parts List
PH10	0711	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
PH10	0711	MI 611-208	Safety Information
PH10	0513	PSS 6-1C3 A	Product Specification Sheet
PH12	0912	DP 611-214	Dimensional Print
PH12	0912	MI 611-214	pH Sensors and Accessories - Installation, Troubleshooting, and Maintenance
PH12	0912	MI 611-215	pH Sensors - Quick Start
PH12	0912	PL 611-214	Parts List
PH12	0912	PSS 6-1C5 A	Product Specification Sheet
871	0711	MI 611-206	Intrinsic Safety Connector Diagrams and Nonincendive Circuits
871A	0608	DP 611-141	Dimensional Print: Electrode Cleaning System (ECS), Flow-Through and Submersible Assemblies
871A	0608	DP 611-144	Dimensional Print: 871A pH and ORP Sensors
871A	0608	DP 611-145	Dimensional Print: 871A (pH and ORP) and 871DO (Dissolved Oxygen) Sensor Accessories
871A	0608	DP 611-157	Dimensional Print: Ball Valve Assemblies, Part Numbers BS806AN and BS806EP
871A	1108	MI 611-164	Installation
871A	0711	MI 611-208	Safety Information
871A	0410	PSS 6-1C2 B	Product Specification Sheet

Electrochemical pH and ORP Sensors

Page 2 of 2

Product	Date	Doc. Num	Title or Description
871PH	0508	DP 611-113	Dimensional Print: pH and ORP
871PH	0307	DP 611-121	Dimensional Print: Mounting Assembly
871PH	0804	DP 611-122	Dimensional Print: Ball Valve Assembly
871PH	0307	DP 611-123	Dimensional Print: Optional Containment
871PH	0608	DP 611-140	Dimensional Print: ECS Flow Through Spool
871PH	0608	DP 611-141	Dimensional Print: ECS Flow Through Submersible
871PH	0493	MI 611-125	Electrode Cleaning System
871PH	0804	MI 611-136	Reference Junction Refill Kit for Sensors
871PH	0808	MI 611-148	Installation and Maintenance
871PH	0711	MI 611-208	Safety Information
871PH	0804	MI 611-188	Electrode Kit for Sensors
871PH	0110	PL 611-014	Parts List
871PH	0410	PSS 6-1C2 A	Product Specification Sheet

Electrochemical Conductivity Sensors

Page 1 of 2

Product	Date	Doc. Num	Title or Description
871CC	0207	DP 611-091	Dimensional Print: Flow Chambers
871CC	0605	DP 611-092	Dimensional Print: Flanges 316 ss
871CC	0605	DP 611-093	Dimensional Print: Twist-Lock Bushing 316 ss
871CC	0605	DP 611-094	Dimensional Print: Twist-Lock Bushing PVC
871CC	0806	DP 611-105	Dimensional Print: Universal Mounting Bushing
871CC	0605	DP 611-131	Dimensional Print: 3/4 NPT Threaded Bushing (-A and -K)
871CC	0605	DP 611-132	Dimensional Print: Universal Mounting (-B)
871CC	0605	DP 611-133	Dimensional Print: Sanitary Flange Mounted (-C and -L)
871CC	0605	DP 611-134	Dimensional Print: Insertion Type (-D and -M)
871CC	0605	DP 611-135	Dimensional Print: Twist-Lock Mounted (-E)
871CC	0605	DP 611-136	Dimensional Print: 3/4 NPT Threaded Bushing and 1/2 NPT Conduit (-F)
871CC	0605	DP 611-139	Dimensional Print: DIP Type (-G)
871CC	0314	MI 611-151	Contacting Conductivity/Resistivity Sensors and Accessories
871CC	0711	MI 611-208	Safety Information
871CC	0314	PSS 6-3C2 A	Product Specification Sheet
871CC	0207	DP 611-117	Dimensional Print: Gate-Valve Assembly (GVI-2)
871CC	0207	DP 611-120	Dimensional Print: Gate-Valve Assembly
871CR	0998	DP 611-165	Dimensional Print: Universal Bore Piece
871CR	0998	DP 611-166	Dimensional Print: Bushing Mounted
871CR	0998	DP 611-167	Dimensional Print: Universal Bore Piece with Cable Connector or Conduit Fitting
871CR	0998	DP 611-168	Dimensional Print: Tri-Clamp Fittings
871CR	0998	DP 611-169	Dimensional Print: Insertion Sensors for use with Ball Valve Accessories
871CR	0506	DP 611-170	Dimensional Print: Accessories
871CR	0711	MI 611-208	Safety Information
871CR	0606	MI 611-221	Sensors and Accessories
871CR	0708	PL 611-019	Parts List:Sensors
871CR	0610	PSS 6-3C2 B	Product Specification Sheet
871EC	0306	DP 611-011	Dimensional Print: 871EC Electrodeless Conductivity Sensors
871EC	0605	DP 611-092	Dimensional Print: Flanges 316 ss
871EC	0806	DP 611-105	Dimensional Print: Universal Mounting Bushing
871EC	0608	DP 611-142	Dimensional Print: Ball Valve Assembly
871EC	0305	DP 611-155	Dimensional Print: Ball Valve Assembly (871EC-SP, -HP, -PP, -PT, -NL, -TF)
871EC	0305	DP 611-180	Dimensional Print: Ball Valve Assembly (871EC-RE, -LB, -BW, -UT)
871EC	0306	MI 611-150	Installation and Maintenance
871EC	0711	MI 611-208	Safety Information
871EC	0409	MI 611-220	System Calibration Examples
871EC	0410	PSS 6-3C4 A	Product Specification Sheet
871FT	0408	DP 611-150	Dimensional Print: ANSI Class
871FT	0105	DP 611-151	Dimensional Print: NPT
871FT	0210	DP 611-152	Dimensional Print: Sanitary

Electrochemical Conductivity Sensors

Page 2 of 2

Product	Date	Doc. Num	Title or Description
871FT	0301	DP 611-153	Dimensional Print: ANSI Class 300
871FT	0797	DP 611-158	Dimensional Print: Metric PN10
871FT	0608	DP 611-159	Dimensional Print: Metric PN16
871FT	0610	MI 611-202	Installation, Calibration, and Troubleshooting
871FT	0711	MI 611-208	Safety Information
871FT	0409	MI 611-220	System Calibration Examples
871FT	0310	PL 611-017	Parts List: Inch Line Sizes
871FT	0301	PL 611-018	Parts List: Millimeter Line Sizes
871FT	0510	PSS 6-3Q1 A	Product Specification Sheet
910	0605	DP 611-092	Dimensional Print: Flanges 316 ss
910	0605	DP 611-093	Dimensional Print: Twist-Lock Bushing 316 ss
910	0605	DP 611-094	Dimensional Print: Twist-Lock Bushing PVC
910	0806	DP 611-105	Dimensional Print: Universal Mounting Bushing
910	0605	DP 611-124	Dimensional Print: 3/4 NPT Threaded Bushing
910	0605	DP 611-125	Dimensional Print: 3/4 NPT Threaded Bushing
910	0605	DP 611-126	Dimensional Print: Sanitary Flange Mounted
910	0605	DP 611-127	Dimensional Print: Insertion Type
910	0605	DP 611-128	Dimensional Print: Twist Lock Mounting
910	0605	DP 611-129	Dimensional Print: 3/4 NPT Threaded Bushing and 1/2 NPT Conduit
910	0605	DP 611-130	Dimensional Print: DIP Type
920	0605	DP 611-092	Dimensional Print: Flanges 316 ss
920	0605	DP 611-093	Dimensional Print: Twist-Lock Bushing 316 ss
920	0605	DP 611-094	Dimensional Print: Twist-Lock Bushing PVC
920	0806	DP 611-105	Dimensional Print: Universal Mounting Bushing
920	0605	DP 611-124	Dimensional Print: 3/4 NPT Threaded Bushing
920	0605	DP 611-125	Dimensional Print: 3/4 NPT Threaded Bushing
920	0605	DP 611-126	Dimensional Print: Sanitary Flange Mounted
920	0605	DP 611-127	Dimensional Print: Insertion Type
920	0605	DP 611-128	Dimensional Print: Twist Lock Mounting
920	0605	DP 611-129	Dimensional Print: 3/4 NPT Threaded Bushing and 1/2 NPT Conduit
920	0605	DP 611-130	Dimensional Print: DIP Type
921	0605	DP 611-093	Dimensional Print: Twist-Lock Bushing 316 ss
921	0605	DP 611-094	Dimensional Print: Twist-Lock Bushing PVC
1210	0605	DP 611-092	Dimensional Print: Flanges 316 ss
1210	0806	DP 611-105	Dimensional Print: Universal Mounting Bushing
FT10	0207	DP 611-217	Dimensional Print
FT10	0711	MI 611-208	Safety Information
FT10	1007	MI 611-217	Flow-Through Conductivity Sensors - Installation, Calibration, Troubleshooting, and Maintenance
FT10	0409	MI 611-220	System Calibration Examples
FT10	0107	PL 611-141	Parts List
FT10	0209	PSS 6-3Q1 B	Product Specification Sheet

Electrochemical Other Sensors

Product	Date	Doc. Num	Title or Description
	0207	TI 612-005	Electrodeless Conductivity, Toroidal Magnets, and the Procedure of Degaussing
222	0804	DP 611-122	Dimensional Print: Ball Valve Assembly
222	0804	DP 611-137	Dimensional Print: pH and ORP
871DO	0608	DP 611-149	Dimensional Print
871DO	0705	MI 611-200	Sensors and Accessories
871DO-C	0705	PL 611-121	Parts Lists - Dissolved Oxygen Sensors
871DO-C	0209	PSS 6-9B1 A	Product Specification Sheet
0051052	0904	DP 611-160	Dimensional Print: Junction Box (7 Terminals)
BS807BZ	0904	DP 611-160	Dimensional Print: Junction Box (8 Terminals)
BS811MR	0410	DP 611-174	Dimensional Print: Remote Preamplifier Junction Box
BS811MR	0410	MI 611-229	Remote Preamplifier Junction Box
BS813XN	0410	DP 611-174	Dimensional Print: Junction Box
BS813XN	0410	MI 611-229	Junction Box
EP402	0205	MI 611-177	Small-Bore Flow-Through Assembly
EP459A	0807	DP 611-210	Dimensional Print: Fluoride Measuring System
EP459A	0210	MI 611-210	Fluoride Measuring System
EP459A	0707	PL 611-210	Parts List: Fluoride Measuring System

Electrochemical

Product Application Data

Product	Date	Doc. Num	Title or Description
875PH	0904	PAD D3620-008	Analyzers for Control and Monitoring in Chromate Waste Treatment
	0998	PAD D3620-012	Point of Use Water Purity Measurements in Semiconductor Industry Using Intelligent Transmitters and Sensors
	0198	PAD G2600-006	Black Liquor Spill Reclamation
	0198	PAD G2600-015	Alkali Concentration Measurement System
	0198	PAD G2600-017	Bleaching
	0198	PAD G2600-018	Brownstock Washing
	0198	PAD G2600-019	Causticizing Control
	0198	PAD G2600-020	Steam Condensate Reclamation
	0198	PAD G2600-021	Dissolving Tank Density Control
	0198	PAD G2600-022	Paper Machine - Wet End pH Control
	0198	PAD G2600-023	Waste Water Treatment
	0198	PAD G2600-024	White Liquor Strength
	0298	PAD P4100-020	Intelligent Analytical Transmitters in Power Plant Applications
	0499	PAD P4100-021	Steam Condensate Leak Detection
	0499	PAD P4100-022	Reverse Osmosis Measurements
	0499	PAD P4100-023	pH Measurement in Wet Scrubbers
	0499	PAD P4100-024	pH Measurement in High Purity Boiler Water
	0499	PAD P4100-025	Demineralizer Regeneration Concentration Control
	0499	PAD P4100-026	Demineralization Bed Monitoring
	0499	PAD P4100-027	Cooling Tower Control
	0499	PAD P4100-028	Condensate Return
	0499	PAD P4100-029	Condensate Analysis
	0499	PAD P4100-030	Waste Water Treatment

May 2014

Foxboro Eckardt Electronic Transmitters

Product	Date	Doc. Num	Title or Description
104.	0696	PSS EML0900A-(en)	Product Specification Sheet Accessories for Buoyancy Transmitter
144LD	0503	MI EML0610A-(en)	Buoyancy Transmitter with Torque Tube
144LD	1008	MI EML0610E-(en)	Buoyancy Transmitter with Torque Tube and Displacer for Level, Interface and Density - All Versions
144LD	1107	MI EML0610F-(en)	Buoyancy Transmitter with Torque Tube and Displacer for Level, Interface and Density with Communication FOUNDATION Fieldbus
144LD	0708	PSS EML0610A-(en)	Product Specification Sheet
144LVD	0605	MI EML1610E-(en)	Buoyancy Transmitter for Liquid Level, Interface and Density
144LVD	0908	PSS EML1610A-(en)	Product Specification Sheet
167LP	1108	PSS EML0110A-(en)	Product Specification Sheet
204.	0109	PSS EML0901A-(en)	Product Specification Sheet Accessories for Buoyancy Transmitter
244LD	0210	MI EML0710E-(en)	Buoyancy Transmitter with Torque Tube and Displacer for Level, Interface and Density - All Versions
244LD	0908	PSS EML0710A-(en)	Product Specification Sheet
244LVP	0210	MI EML1710A-(en)	Buoyancy Transmitter for Liquid Level, Interface and Density
244LVP	0309	PSS EML1710A-(en)	Product Specification Sheet

Foxboro Eckardt Positioners

Product	Date	Doc. Num	Title or Description
SRD960	0707	MI EVE0105B-(en)	Universal Positioner with HART Hand-Held Terminal
SRD960	0109	MI EVE0109A-(en)	Universal Positioner
SRD960	0210	PSS EVE0109A-(en)	Product Specification Sheet
SRD991	0707	MI EVE0105B-(en)	Intelligent Positioner with HART Hand-Held Terminal
SRD991	0409	MI EVE0105E(en)	Intelligent Positioner - All Versions
SRD991	1209	PSS EVE0105E-(en)	Product Specification Sheet
SRI986	0707	MI EVE0102A-(en)	Product Specification Sheet
SRI986	0409	PSS EVE0102A-(en)	Product Specification Sheet
SRI990	1007	MI EVE0107A-(en)	Analog Positioner
SRI990	0210	PSS EVE0107A-(en)	Product Specification Sheet
SRP981	0499	MI EVE0101A-(en)	Product Specification Sheet
SRP981	0499	PSS EVE0101A-(en)	Product Specification Sheet

Magnetic Flow Transmitters

Page 1 of 2

Product	Date	Doc. Num	Title or Description
47	0908	MI 021-322	Magnetic Flow Transmitters - Installation, Commissioning, and Service
47	0908	MI 021-326	Flowmeter Remote Mounting Kit, Installation Kit A5E01268346
47	0507	PSS 1-6G1 A	Product Specification Sheet
48	0908	MI 021-322	Magnetic Flow Transmitters - Installation, Commissioning, and Service
48	0908	MI 021-326	Flowmeter Remote Mounting Kit, Installation Kit A5E01268346
48	0604	MI 021-329	Supplemental Installation Instructions for Transmitter used in PMO, HTST Flowmeter Applications
48	0507	PSS 1-6G1 A	Product Specification Sheet
IMT25	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters
IMT25	0501	DP 021-365	Dimensional Print
IMT25	1208	MI 021-387	Installation with 8000A, 2800, 8300, 9100A, 9200A, and 9300A
IMT25	0810	MI 021-390	Model IMT25 - Operation, Configuration, and Calibration
IMT25	0405	MI 021-391	System Maintenance with 8000A, 2800, 8300, 9100A, 9200A, and 9300A
IMT25	0698	MI 021-397	Operation, Configuration, and Calibration With HART Communicator
IMT25	0705	PL 008-745	Parts List
IMT25	0513	PSS 1-6F5 A	Product Specification Sheet: FoxCom and HART
IMT25-***F	0605	MI 014-900	Fieldbus Overview
IMT25-***F	0405	MI 021-399	Operation, Configuration, and Calibration from a Fieldbus Host
IMT25-***F	0309	PSS 1-6F5 B	Product Specification Sheet: FOUNDATION Fieldbus
IMT25L	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters
IMT96	0299	DP 021-367	Dimensional Print
IMT96	0209	MI 021-402	With 2800 Series Flanged Flowtubes Installation
IMT96	0809	MI 021-403	Integral Keypad and Display, Local Operation, Configuration, and Calibration
IMT96	0309	MI 021-404	With 2800 Series Flanged Flowtubes System Maintenance
IMT96	0599	MI 021-412	Retrofitting 2800 Series with Flanged Flowtubes when Previously Connected to an E96
IMT96	1212	MI 021-501	IMT96SIM Magnetic Flowtube Simulator for use With IMT96 MagEXPERT™ Magnetic Flow Transmitters
IMT96	0510	MI 021-415	With HART Communications - Operation, Configuration, and Calibration
IMT96	0109	PL 008-747	Parts List
IMT96	0109	PSS 1-6F8 A	Product Specification Sheet
MAG2	1208	TI 027-077	Technical Information Magnetic Flowmeter Application Guideline
MAG2IC	1208	DP 021-500	Dimensional Print
MAG2IC	0410	MI 021-500	Flowmeter with Integrally Mounted Transmitter - Operation, Configuration, and Calibration
MAG2IC	0610	PSS 1-6G3 A	Product Specification Sheet

Magnetic Flow

Transmitters

Page 2 of 2

Product	Date	Doc. Num	Title or Description
MAG2RS	1208	DP 021-501	Dimensional Print
MAG2RS	0410	MI 021-500	Remote Mounted Flowtube - Operation, Configuration, and Calibration
MAG2RS	0410	PSS 1-6G3 A	Product Specification Sheet
MAG2RT	1208	DP 021-500	Dimensional Print
MAG2RT	0410	MI 021-500	Remote Mounted Transmitter - Operation, Configuration, and Calibration
MAG2RT	0410	PSS 1-6G3 A	Product Specification Sheet

Magnetic Flow

Flowtubes

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters - 8000A, 8300, and 9300A
2800	0708	DP 021-120	Dimensional Print: 2800 Series Magnetic Flowtube Sizes 2.5 to 300 mm (1/10 to 12 in) With Lined Metal Metering Tube
2800	0193	DP 021-137	Dimensional Print: 2800 Series Flanged Magnetic Flowtubes, 350 through 900 mm (14 through 36 in) Flowtube Sizes, Style C
2800	0909	MI 021-120	Flowtubes, Installation
2800	0309	MI 021-137	Installation
2800	1195	MI 021-138	Fault Location Guide
2800	0309	MI 021-141	Sanitary ptfе Line
2800	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
2800	0610	PL 008-541	Parts List: 15 to 300 mm (1/2 to 12 in) Sizes
2800	0608	PL 008-544	Parts List: 350 to 900 mm (14 to 36 in) Sizes
2800	1209	PSS 1-6B5 A	Product Specification Sheet: ptfе, pfa, or Polyurethane Lined 1/10 through 12 in Sizes
2800	0608	PSS 1-6B5 C	Product Specification Sheet: Used with Model IMT96 MagEXPERT, E96, or IMT25, 15 to 80 mm (1/2 to 3 in) Flowtube Sizes, ptfе Lined
2800	1208	PSS 1-6B5 E	Product Specification Sheet: Used with Model IMT96 MagEXPERT, E96, or IMT25, 14 to 36 in Sizes; ptfе, Polyurethane, or Neoprene Lined
2891	0608	PL 008-543	Parts List: 2.5 mm (1/10 in) Size
2893	0608	PL 008-543	Parts List: 6 mm (1/4 in) Size
4700S	0908	MI 021-323	Sanitary Flowtube - Installation
4700S	0604	MI 021-329	Supplemental Installation Instructions for Flowtube used in PMO, HTST Flowmeter Applications
4700S	1208	MI 021-414	Flowmeter Submersible Mounting Kit FDK-085U0220
4700S	0410	PSS 1-6G2 A	Product Specification Sheet
8000A	1107	DP 021-358	Dimensional Print
8000A	1212	MI 019-179	Flow Safety Information
8000A	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
8000A	0909	MI 021-380	Compact Magnetic Flowtubes - Installation
8000A	0808	PL 008-740	Parts List
8000A	0808	PSS 1-6F2 A	Product Specification Sheet: Wafer Body, Ceramic- or pfa-Lined, 1.6 to 150 mm (1/16 to 6 in) Line Sizes
8000A	0711	PSS 1-6F2 C	Product Specification Sheet: Ceramic-Lined 15 to 80 mm (1/2 to 3 in) Sizes
8300	0708	DP 021-360	Dimensional Print: Flanged
8300	0708	DP 021-361	Dimensional Print: ptfе-Lined Sanitary
8300	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
8300	0810	MI 021-381	8300 Series Magnetic Flowtubes - Installation
8300	0808	PL 008-741	Parts List
8300	0608	PSS 1-6F2 B	Product Specification Sheet: ptfе, Polyurethane, or Neoprene Lined, 1/2 through 36 in Sizes
8300	0711	PSS 1-6F2 C	Product Specification Sheet: Ceramic-Lined 15 to 80 mm (1/2 to 3 in) Sizes

Magnetic Flow

Flowtubes

Page 2 of 2

Product	Date	Doc. Num	Title or Description
9100A	0808	DP 021-368	Dimensional Print: 9100A Flanged: 1 to 78 in (25 to 2000 mm) Sizes; Neoprene or EPDM Lining
9100A	1110	DP 021-369	Dimensional Print: 9100A Flanged: 1 to 78 in (25 to 2000 mm) Sizes; Ebonite Lining
9100A	1212	MI 019-179	Flow Safety Information
9100A	1110	MI 021-413	Flowtubes, Installation
9100A	1110	PL 008-748	Parts List
9100A	1110	PSS 1-6F9 A	Product Specification Sheet
9200A	0808	DP 021-368	Dimensional Print: 9200A Flanged: 8 to 48 in (200 to 1200 mm) Sizes; Neoprene, EPDM, Linatex, Ebonite, or ptfе Lining
9200A	1110	DP 021-369	Dimensional Print: 9200A Flanged: 1/2 to 78 in (15 to 2000 mm) Sizes; Neoprene, EPDM, Linatex, Ebonite, or ptfе Lining
9200A	1212	MI 019-179	Flow Safety Information
9200A	1110	MI 021-413	Flowtubes, Installation
9200A	1110	PL 008-748	Parts List
9200A	1110	PSS 1-6F10 A	Product Specification Sheet
9300A	0902	DP 021-364	Dimensional Print
9300A	1212	MI 019-179	Flow Safety Information
9300A	1103	MI 021-151	Sealing Kits D0128GY (Flanged End) and D0155VA (Wafer End)
9300A	1208	MI 021-386	Flanged Magnetic Flowtubes, pfa-, ptfе-, or Polyurethane-Lined, Installation
9300A	0808	PL 008-742	Parts List
9300A	0808	PSS 1-6F4 A	Product Specification Sheet

May 2014

Magnetic Flow Other

Product	Date	Doc. Num	Title or Description
	0211	TI 27-71f	Technical Information Material Selection Guide
	0906	TI 027-072	Technical Information Electrical Conductivity of Process Liquids
IMTSIM	0409	B0800AC	Ensuring Premium Performance with Foxboro I/A Series Pulsed dc Magnetic Flowmeters
IMTSIM	1009	MI 021-392	Magnetic Flowtube Simulator
IMTSIM	1109	PSS 1-6F7 A	Product Specification Sheet

May 2014

Mass Flow Transmitters

Product	Date	Doc. Num	Title or Description
	0300	TI 001-053	Tutorial Percent Solids Calculation
CFT50	0709	B0800AH-C	Digital Coriolis Mass Flowmeters Installation Guidelines and Quick Start - HART
CFT50	0210	B0800AL-B	Digital Coriolis Mass Flowmeters Installation Guidelines and Quick Start - Modbus
CFT50	0609	DP 019-375	Dimensional Print
CFT50	0510	MI 019-132	Digital Coriolis Transmitter with HART - Installation, Startup, Configuration, and Maintenance
CFT50	0409	MI 019-133	Safety Connection Diagrams (FM, CSA)
CFT50	0912	MI 019-134	Digital Coriolis Transmitter with Modbus - Installation, Startup, Configuration, and Maintenance
CFT50	1212	MI 019-179	Flow Safety Information
CFT50	0509	PL 008-704	Parts List
CFT50	0410	PSS 1-2B7 A	Product Specification Sheet
CFT51	0711	B0800AM	CFT51 Digital Coriolis Mass Flowmeters - Installation and Quick Start
CFT51	0611	DP 019-376	Dimensional Print
CFT51	0913	MI 019-140	I/A Series® Digital Coriolis Mass Flow Transmitter
CFT51	1112	MI 019-141	CFT51 - Safety Connection Diagrams (FM, CSA)
CFT51	1212	MI 019-179	Flow Safety Information
CFT51	0913	PL 008-752	Parts List
CFT51	0913	PSS 1-2B7 C	Product Specification Sheet

May 2014

Mass Flow Flowtubes

Product	Date	Doc. Num	Title or Description
CFS10	0802	DP 019-182	Dimensional Print: 6-50 mm (1/4 to 2 inch)
CFS10	0998	DP 019-366	Dimensional Print: 3 mm (1/8 inch)
CFS10	0913	MI 019-120	Installation, Startup, Troubleshooting and Maintenance
CFS10	1212	MI 019-179	Flow Safety Information
CFS10	0608	PL 008-702	Parts List: Style A
CFS10	0712	PL 008-733	Parts List: Style B
CFS10	0913	PSS 1-2B1 A	Product Specification Sheet
CFS20	0802	DP 019-183	Dimensional Print
CFS20	0913	MI 019-120	Installation, Startup, Troubleshooting and Maintenance
CFS20	1212	MI 019-179	Flow Safety Information
CFS20	0608	PL 008-703	Parts List: Style A
CFS20	0913	PL 008-735	Parts List: Style B
CFS20	0913	PSS 1-2B1 A	Product Specification Sheet

Pressure Transmitters

d/p Cell

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0998	B0800AE	Ensuring Premium Performance with Foxboro Intelligent Level Transmitters
	0210	B0800AG	Pressure Transmitters - Getting Started
11DM	0711	PL 006-265	Parts List: Styles C and D
13A	0499	MI 022-310	d/p Cell Installation and Operation
13A	0789	MI 022-345	Maintenance
13A	1005	PL 006-175	Parts List
13A	0911	PSS 2B-1C1 A	Product Specification Sheet
13H	0306	PL 006-177	Parts List
13HA	0911	PSS 2B-1C1 A	Product Specification Sheet
15A	0304	PL 006-176	Parts List: Styles B-E
15A	0911	PSS 2B-1C1 A	Product Specification Sheet
CO	1107	DP 022-335	Dimensional Print
CO	1003	MI 022-335	Compact Orifice with d/p Cell Transmitters
CO	1003	PL 006-172	Parts List: Compact Orifice with d/p Cell Transmitters
CO	1007	PSS 3-5A1 E	Product Specification Sheet: Compact Orifice with d/p Cell Transmitters
IDP**-F	0605	MI 014-900	Fieldbus Overview
IDP10	1212	DP 020-446	Dimensional Print
IDP10	0609	MI 020-357	Functional Safety Manual
IDP10	0509	MI 020-358	Safety Information
IDP10	0810	MI 020-359	Universal Instruction Manual
IDP10	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IDP10	0510	PL 009-005	Parts List
IDP10	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IDP10-A	0510	MI IDP10-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA Output Signal)
IDP10-A	1212	PSS 2A-1C14 C	Product Specification Sheet
IDP10-D	0510	MI IDP10-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IDP10-D	0311	PSS 2A-1C14 A	Product Specification Sheet
IDP10-F	1113	MI IDP10-F	Installation, Calibration, Configuration and Maintenance (FOUNDATION Fieldbus Communication)
IDP10-F	0113	PSS 2A-1C13 E	Product Specification Sheet
IDP10-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IDP10-T	0510	MI IDP10-T	Installation, Calibration, Configuration, and Maintenance (HART Communications)
IDP10-T	0414	PSS 2A-1C14 B	Product Specification Sheet
IDP10-V	0510	MI IDP10-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IDP10-V	0811	PSS 2A-1C13 D	Product Specification Sheet
IDP15D	0211	MI 020-600	Installation, Operation, Calibration, Configuration, and Maintenance
IDP15D	0211	MI 020-540	Safety Information
IDP15D	0311	PSS 2A-1C17 A	Product Specification Sheet

Pressure Transmitters

d/p Cell

Page 2 of 2

Product	Date	Doc. Num	Title or Description
IDP15D	0211	DP 020-600	Dimensional Print
IDP25	1212	DP 020-446	Dimensional Print
IDP25	0509	MI 020-358	Safety Information
IDP25	0810	MI 020-359	Universal Instruction Manual
IDP25	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IDP25	0510	PL 009-013	Parts List
IDP25	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IDP25-F	0410	MI IDP25-F/ IDP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IDP25-F	1209	PSS 2A-1C14 K	Product Specification Sheet
IDP25-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IDP25-T	0410	MI IDP25-T/ IDP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IDP25-T	1209	PSS 2A-1C14 K	Product Specification Sheet
IDP31D	0211	MI 020-600	Installation, Operation, Calibration, Configuration, and Maintenance
IDP31D	0211	MI 020-540	Safety Information
IDP31D	0311	PSS 2A-1C17 A	Product Specification Sheet
IDP31D	0211	DP 020-600	Dimensional Print
IDP32D	0211	MI 020-600	Installation, Operation, Calibration, Configuration, and Maintenance
IDP32D	0211	MI 020-540	Safety Information
IDP32D	0311	PSS 2A-1C17 A	Product Specification Sheet
IDP32D	0211	DP 020-600	Dimensional Print
IDP50	1212	DP 020-446	Dimensional Print
IDP50	0509	MI 020-358	Safety Information
IDP50	0810	MI 020-359	Universal Instruction Manual
IDP50	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IDP50	0510	PL 009-014	Parts List
IDP50	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IDP50-F	0410	MI IDP25-F/ IDP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IDP50-F	1212	PSS 2A-1C14 L	Product Specification Sheet
IDP50-T	0806	MI 020-366	I/A Series Pressure Transmitters with HART Configurator
IDP50-T	0410	MI IDP25-T/ IDP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IDP50-T	1212	PSS 2A-1C14 L	Product Specification Sheet

Pressure Transmitters

Absolute/Gauge

Page 1 of 5

Product	Date	Doc. Num	Title or Description
	0998	B0800AE	Ensuring Premium Performance with Foxboro Intelligent Level Transmitters
	0210	B0800AG	Pressure Transmitters - Getting Started
11A	0701	PSS 2B-1A1 A	Product Specification Sheet
11AH	0304	PL 006-273	Parts List: Styles C and D
11AL	0304	PL 006-272	Parts List: Styles C and D
11AM	0304	PL 006-271	Parts List: Styles D and E
11GH	0304	PL 006-267	Parts List: Styles D and E
11GH	0510	PSS 2B-1A3 A	Product Specification Sheet
11GM	0499	MI 004-311	Removable Sealed Pressure
11GM	0499	MI 022-415	Pressure Transmitter Style C-D
11GM	0304	PL 006-266	Parts List
11GM	0510	PSS 2B-1A3 A	Product Specification Sheet
15F	0103	PL 006-179	Parts List
IAP**-F	0605	MI 014-900	Fieldbus Overview
IAP10	0599	DP 020-212	Dimensional Print: Sanitary Gauge or Absolute Level 2-inch Tri-Clamp
IAP10	0705	DP 020-217	Dimensional Print: Sanitary with Pulp and Paper Process Connections
IAP10	0403	DP 020-218	Dimensional Print: Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IAP10	0403	DP 020-219	Dimensional Print: Sanitary with Mini Tank Spud Seal
IAP10	1212	DP 020-447	Dimensional Print: IAP10, IGP10, IAP20, IGP20, IGP25, IGP50
IAP10	0609	MI 020-357	Functional Safety Manual
IAP10	0509	MI 020-358	Safety Information
IAP10	0810	MI 020-359	Universal Instruction Manual
IAP10	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IAP10	0510	PL 009-006	Parts List
IAP10	0113	PSS 2A-1C13 K	Product Specification Sheet: Sanitary Process Connections
IAP10	0113	PSS 2A-1C13 L	Product Specification Sheet: Process Connections for Pulp and Paper
IAP10	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IAP10-A	0510	MI IAP10-A/ IGP10-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IAP10-A	0811	PSS 2A-1C13 C	Product Specification Sheet
IAP10-D	0510	MI IAP10-D/ IGP10-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IAP10-D	0811	PSS 2A-1C13 A	Product Specification Sheet
IAP10-F	1113	MI IAP10-F/ IGP10-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IAP10-F	0113	PSS 2A-1C13 E	Product Specification Sheet
IAP10S	0513	DP 020-463	I/A Series® Pressure S Series Transmitters
IAP10S	0513	PL 009-025	I/A Series® Pressure S Series Transmitters
IAP10S	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
IAP10S	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IAP10S	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters

Pressure Transmitters

Absolute/Gauge

Page 2 of 5

Product	Date	Doc. Num	Title or Description
IAP10S	0414	MI 020-541	I/A Series® Pressure S Series Transmitters FM/CSA Safety Information
IAP10S	0613	MI 020-542	I/A Series® Pressure S Series Transmitters ATEX/IECEX Safety Information
IAP10S	0114	PSS 2A-1C13 P	Pressure Transmitters with HART Communication Protocol
IAP10-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IAP10-T	0510	MI IAP10-T/ IGP10-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IAP10-T	0414	PSS 2A-1C13 B	Product Specification Sheet
IAP10-V	0510	MI IAP10-V/ IGP10-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IAP10-V	0811	PSS 2A-1C13 D	Product Specification Sheet
IAP20	0705	DP 020-217	Dimensional Print: Sanitary with Pulp and Paper Process Connections
IAP20	0403	DP 020-218	Dimensional Print: Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IAP20	0403	DP 020-219	Dimensional Print: Sanitary with Mini Tank Spud Seal
IAP20	1212	DP 020-447	Dimensional Print: IAP10, IGP10, IAP20, IGP20, IGP25, IGP50
IAP20	0609	MI 020-357	Functional Safety Manual
IAP20	0509	MI 020-358	Safety Information
IAP20	0810	MI 020-359	Universal Instruction Manual
IAP20	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IAP20	0510	PL 009-007	Parts List
IAP20	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IAP20-A	0510	MI IAP20-A/ IGP20-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IAP20-A	0811	PSS 2A-1C13 C	Product Specification Sheet
IAP20-D	0510	MI IAP20-D/ IGP20-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IAP20-D	0811	PSS 2A-1C13 A	Product Specification Sheet
IAP20-F	1113	MI IAP20-F/ IGP20-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communications)
IAP20-F	0113	PSS 2A-1C13 E	Product Specification Sheet
IAP20-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IAP20-T	0510	MI IAP20-T/ IGP20-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IAP20-T	0414	PSS 2A-1C13 B	Product Specification Sheet
IAP20-V	0510	MI IAP20-V/ IGP20-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IAP20-V	0811	PSS 2A-1C13 D	Product Specification Sheet
IGP**-F	0605	MI 014-900	Fieldbus Overview
IGP10	0599	DP 020-211	Dimensional Print: Sanitary Gauge Pressure/Level 1 1/2-inch Tri-Clamp
IGP10	0599	DP 020-212	Dimensional Print: Sanitary Gauge or Absolute Level 2-inch Tri-Clamp
IGP10	0599	DP 020-213	Dimensional Print: Sanitary Gauge Pressure/Level 3-inch Tri-Clamp
IGP10	0599	DP 020-214	Dimensional Print: Sanitary Gauge Pressure/Level Mini Tank Spud
IGP10	0599	DP 020-216	Dimensional Print: Sanitary Gauge Pressure/Level Extended Mini Tank Spud

Pressure Transmitters

Absolute/Gauge

Page 3 of 5

Product	Date	Doc. Num	Title or Description
IGP10	0705	DP 020-217	Dimensional Print: Sanitary with Pulp and Paper Process Connections
IGP10	0403	DP 020-218	Dimensional Print: Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IGP10	0403	DP 020-219	Dimensional Print: Sanitary with Mini Tank Spud Seal
IGP10	0208	DP 020-344	Dimensional Print: High Gauge
IGP10	1212	DP 020-447	Dimensional Print: IAP10, IGP10, IAP20, IGP20, IGP25, IGP50
IGP10	0609	MI 020-357	Functional Safety Manual
IGP10	0509	MI 020-358	Safety Information
IGP10	0810	MI 020-359	Universal Instruction Manual
IGP10	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP10	0510	PL 009-006	Parts List
IGP10	1209	PL 009-010	Parts List: High Gauge
IGP10	0113	PSS 2A-1C13 F	Product Specification Sheet: High Gauge
IGP10	0113	PSS 2A-1C13 K	Product Specification Sheet: Sanitary Process Connections
IGP10	0113	PSS 2A-1C13 L	Product Specification Sheet: Process Connections for Pulp and Paper
IGP10	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IGP10-A	0510	MI IAP10-A/ IGP10-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IGP10-A	0811	PSS 2A-1C13 C	Product Specification Sheet
IGP10-D	0510	MI IAP10-D/ IGP10-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP10-D	0811	PSS 2A-1C13 A	Product Specification Sheet
IGP10-F	1113	MI IAP10-F/ IGP10-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP10-F	0113	PSS 2A-1C13 E	Product Specification Sheet
IGP10S	0513	DP 020-463	I/A Series® Pressure S Series Transmitters
IGP10S	0513	PL 009-025	I/A Series® Pressure S Series Transmitters
IGP10S	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
IGP10S	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IGP10S	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
IGP10S	0414	MI 020-541	I/A Series® Pressure S Series Transmitters FM/CSA Safety Information
IGP10S	0613	MI 020-542	I/A Series® Pressure S Series Transmitters ATEX/IECEX Safety Information
IGP10S	0114	PSS 2A-1C13 P	Pressure Transmitters with HART Communication Protocol
IGP10-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP10-T	0510	MI IAP10-T/ IGP10-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP10-T	0414	PSS 2A-1C13 B	Product Specification Sheet
IGP10-V	0510	MI IAP10-V/ IGP10-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IGP10-V	0811	PSS 2A-1C13 D	Product Specification Sheet
IGP20	0599	DP 020-211	Dimensional Print: Sanitary Gauge Pressure/Level 1 1/2-inch Tri-Clamp

Pressure Transmitters

Absolute/Gauge

Page 4 of 5

Product	Date	Doc. Num	Title or Description
IGP20	0599	DP 020-212	Dimensional Print: Sanitary Gauge or Absolute Pressure/Level 2-inch Tri-Clamp
IGP20	0599	DP 020-213	Dimensional Print: Sanitary Gauge Pressure/Level 3-inch Tri-Clamp
IGP20	0599	DP 020-214	Dimensional Print: Sanitary Gauge Pressure/Level Mini Tank Spud
IGP20	0599	DP 020-216	Dimensional Print: Sanitary Gauge Pressure/Level Extended Mini Tank Spud
IGP20	0705	DP 020-217	Dimensional Print: Sanitary with Pulp and Paper Process Connections
IGP20	0403	DP 020-218	Dimensional Print: Sanitary with 1 1/2-, 2-, 3-inch Tri-Clamp
IGP20	0403	DP 020-219	Dimensional Print: Sanitary with Mini Tank Spud Seal
IGP20	1212	DP 020-447	Dimensional Print: IAP10, IGP10, IAP20, IGP20, IGP25, IGP50
IGP20	0609	MI 020-357	Functional Safety Manual
IGP20	0509	MI 020-358	Safety Information
IGP20	0810	MI 020-359	Universal Instruction Manual
IGP20	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP20	0510	PL 009-007	Parts List
IGP20	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IGP20-A	0510	MI IAP20-A/ IGP20-A	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA)
IGP20-A	0811	PSS 2A-1C13 C	Product Specification Sheet
IGP20-D	0510	MI IAP20-D/ IGP20-D	Installation, Calibration, Configuration, and Maintenance (FoxCom Communication)
IGP20-D	0811	PSS 2A-1C13 A	Product Specification Sheet
IGP20-F	1113	MI IAP20-F/ IGP20-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP20-F	0113	PSS 2A-1C13 E	Product Specification Sheet
IGP20-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP20-T	0510	MI IAP20-T/ IGP20-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP20-T	0414	PSS 2A-1C13 B	Product Specification Sheet
IGP20-V	0510	MI IAP20-V/ IGP20-V	Installation, Calibration, Configuration, and Maintenance (1 to 5 V dc Output Signal)
IGP20-V	0811	PSS 2A-1C13 D	Product Specification Sheet
IGP25	1212	DP 020-447	Dimensional Print: IAP10, IGP10, IAP20, IGP20, IGP25, IGP50
IGP25	0509	MI 020-358	Safety Information
IGP25	0810	MI 020-359	Universal Instruction Manual
IGP25	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP25	0510	PL 009-011	Parts List
IGP25	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IGP25-F	0410	MI IGP25-F/ IGP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP25-F	0113	PSS 2A-1C13 G	Product Specification Sheet
IGP25-F	0113	PSS 2A-1C13 M	Product Specification Sheet: Sanitary Process Connections
IGP25-F	0113	PSS 2A-1C13 N	Product Specification Sheet: Pulp and Paper Process Connections

Pressure Transmitters

Absolute/Gauge

Page 5 of 5

Product	Date	Doc. Num	Title or Description
IGP25-T	0410	MI IGP25-T/ IGP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP25-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP25-T	0113	PSS 2A-1C13 G	Product Specification Sheet
IGP25-T	0113	PSS 2A-1C13 M	Product Specification Sheet: Sanitary Process Connections
IGP25-T	0113	PSS 2A-1C13 N	Product Specification Sheet: Pulp and Paper Process Connections
IGP50	1212	DP 020-447	Dimensional Print: IAP10, IGP10, IAP20, IGP20, IGP25, IGP50
IGP50	0509	MI 020-358	Safety Information
IGP50	0810	MI 020-359	Universal Instruction Manual
IGP50	0805	MI 020-427	Pressure Transmitters Intrinsic Safety Diagrams and Nonincendive Circuits
IGP50	0510	PL 009-012	Parts List
IGP50	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IGP50-D	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP50-D	0113	PSS 2A-1C13 H	Product Specification Sheet
IGP50-F	0410	MI IGP25-F/ IGP50-F	Installation, Calibration, Configuration, and Maintenance (FOUNDATION Fieldbus Communication)
IGP50-F	0113	PSS 2A-1C13 H	Product Specification Sheet
IGP50-T	0410	MI IGP25-T/ IGP50-T	Installation, Calibration, Configuration, and Maintenance (HART Communication)
IGP50-T	0608	MI 020-366	I/A Series Pressure Transmitters with HART Communicator
IGP50-T	0113	PSS 2A-1C13 H	Product Specification Sheet
IGP60G	0211	MI 020-600	Installation, Operation, Calibration, Configuration, and Maintenance
IGP60G	0211	MI 020-540	Safety Information
IGP60G	0211	PSS 2A-1C18 A	Product Specification Sheet
IGP60G	0211	DP 020-600	Dimensional Print

Pressure Transmitters

Pressure Seals

Page 1 of 2

Product	Date	Doc. Num	Title or Description
PSFAD	1212	DP 020-346	Dimensional Print
PSFAD	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSFAD	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSFAR	1212	DP 020-345	Dimensional Print
PSFAR	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSFAR	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSFES	1212	DP 020-343	Dimensional Print
PSFES	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSFES	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSFFD	1212	DP 020-357	Dimensional Print
PSFFD	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSFFD	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSFFR	1212	DP 020-356	Dimensional Print
PSFFR	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSFFR	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSFLT	1212	DP 020-342	Dimensional Print
PSFLT	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSFLT	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSFPS	1212	DP 020-343	Dimensional Print
PSFPS	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSFPS	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSISD	1212	DP 020-350	Dimensional Print
PSISD	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSISD	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSISR	1212	DP 020-349	Dimensional Print
PSISR	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSISR	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSSCR	1101	DP 020-351	Dimensional Print
PSSCR	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSSCR	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSSCT	0403	DP 020-355	Dimensional Print
PSSCT	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSSCT	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSSSR	0705	DP 020-353	Dimensional Print
PSSSR	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSSSR	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSSST	0705	DP 020-354	Dimensional Print
PSSST	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSSST	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters

Pressure Transmitters

Pressure Seals

Page 2 of 2

Product	Date	Doc. Num	Title or Description
PSTAD	1212	DP 020-348	Dimensional Print
PSTAD	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSTAD	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters
PSTAR	1212	DP 020-347	Dimensional Print
PSTAR	0414	MI 020-369	Pressure Seals for Use with I/A Series Pressure Transmitters
PSTAR	0414	PSS 2A-1Z11 A	Pressure Seals for Use with I/A Series® Pressure Transmitters

May 2014

Pressure Transmitters Pneumatic-to-Current Converters

Product	Date	Doc. Num	Title or Description
IPI10-A	1299	DP 020-414	Dimensional Print
IPI10-A	0510	MI 020-414	Installation, Calibration, Configuration, and Maintenance
IPI10-A	0510	PL 009-144	Parts List: Pneumatic-to-Current Converter
IPI10-A	0100	PSS 2A-2A4 A	IPI10 Series Pneumatic-to-Current Converter

Pressure Transmitters

Multivariable

Product	Date	Doc. Num	Title or Description
IMV25	1212	DP 020-432	Dimensional Print
IMV25	0806	MI 020-358	Safety Information
IMV25	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IMV25-M	0510	MI 020-384	Installation, Calibration, Configuration, and Maintenance (Modbus Communications and PCMM Field Device Configurator)
IMV25-M	0510	PL 009-019	Parts List
IMV25-M	1212	PSS 2A-1C15 D	Product Specification Sheet
IMV25-T	0510	MI 020-382	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA HART)
IMV25-T	0510	PL 009-019	Parts List
IMV25-T	1212	PSS 2A-1C15 B	Product Specification Sheet
IMV30	1212	DP 020-432	Dimensional Print
IMV30	0806	MI 020-358	Safety Information
IMV30	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IMV30-T	0510	MI 020-382	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA HART)
IMV30-T	0510	PL 009-018	Parts List
IMV30-T	1212	PSS 2A-1C15 A	Product Specification Sheet
IMV31	1212	DP 020-432	Dimensional Print
IMV31	0513	PSS 2A-1Z9 E	I/A Series Electronic Pressure Transmitters Options and Accessories
IMV31	0513	TI 037-098	Using IMV31 for Boiler Drum Level Applications
IMV31-T	0510	MI 020-383	Installation, Calibration, Configuration, and Maintenance (4 to 20 mA HART)
IMV31-T	0510	PL 009-020	Parts List
IMV31-T	1212	PSS 2A-1C15 C	Product Specification Sheet

Pressure Transmitters

Other

Page 1 of 2

Product	Date	Doc. Num	Title or Description
	0913	MI 020-328	Bubble Tube Installation for Measurement
	0799	MI 020-360	Wiring Guidelines for Foundation Fieldbus Transmitters
	0809	MI 022-138	1-, 2-, 3-, and 5-Valve Manifolds For Use With I/A Series Pressure Transmitter Family
	1210	PSS 3-2A1 A	Product Specification Sheet: Pressure and Receiver Elements
	1299	PSS 3-2C1 A	Product Specification Sheet: Pressure Seals
	1186	TI 37-75b	Technical Information - Material Selection Guide
	0109	TI 037-097	Technical Information - Process Sealing of Transmitters for use in Class I, Zone 0, 1, and 2 Hazardous Locations
13DEMP	0103	PL 006-180	Parts List: Transmitter with Matched Extended Pressure Seals
13DMP	0103	PL 006-180	Parts List: Transmitter with Matched Pressure Seals
13F	0209	PL 006-178	Parts List: Liquid Level or Density Styles C and D
13FE	0209	PL 006-178	Parts List: Liquid Level or Density Styles E and F
D0170MB thru MJ	0598	MI 020-412	Mounting Hardware Kits to Replace 823DP, 843DP and 863DP with IDP10
HHT	0197	MI 020-400	Pocket Guide with I/A Series Pressure Transmitters
MB3	0809	DP 022-148	Dimensional Print: 3-Valve Manifolds
MB3	0809	PL 006-152	Parts List: 3-Valve Manifold
MB3	0809	PSS 2B-1Z2 A	Product Specification Sheet: 3-Valve Manifolds
MB5G	0809	DP 022-149	Dimensional Print: 5-Valve Manifold
MB5G	0809	PL 006-152	Parts List: 5-Valve Manifold
MB5G	0809	PSS 2B-1Z2 A	Product Specification Sheet: 5-Valve Manifolds
MB5P	0809	DP 022-149	Dimensional Print: 5-Valve Manifold
MB5P	0809	PL 006-152	Parts List: 5-Valve Manifold
MB5P	0809	PSS 2B-1Z2 A	Product Specification Sheet: 5-Valve Manifolds
MH	1002	PL 002-101	Parts List: Pressure Gauges
M4A	0809	DP 022-148	Dimensional Print: 3-Valve Manifold
M4A	0809	PL 006-152	Parts List: 3-Valve Manifold
M4A	0809	PSS 2B-1Z2 A	Product Specification Sheet: 3-Valve Manifolds
M4AP	0809	DP 022-147	Dimensional Print: 2-Valve Manifold
M4AP	0809	PL 006-152	Parts List: 2-Valve Manifold
M4AP	0809	PSS 2B-1Z2 A	Product Specification Sheet: 2-Valve Manifolds
M4T	0809	DP 022-148	Dimensional Print: 3-Valve Manifold
M4T	0809	PL 006-152	Parts List: 3-Valve Manifold
M4T	0809	PSS 2B-1Z2 A	Product Specification Sheet: 3-Valve Manifolds
M4TP	0809	DP 022-147	Dimensional Print: 2-Valve Manifold
M4TP	0809	PL 006-152	Parts List: 2-Valve Manifold
M4TP	0809	PSS 2B-1Z2 A	Product Specification Sheet: 2-Valve Manifolds
M6T	0809	DP 022-149	Dimensional Print: 5-Valve Manifold
M6T	0809	PL 006-152	Parts List: 5-Valve Manifold
M6T	0809	PSS 2B-1Z2 A	Product Specification Sheet: 5-Valve Manifolds

Pressure Transmitters

Other

Page 2 of 2

Product	Date	Doc. Num	Title or Description
M6TA	0809	DP 022-149	Dimensional Print: 5-Valve Manifold
M6TA	0809	PL 006-152	Parts List: 5-Valve Manifold
M6TA	0809	PSS 2B-1Z2 A	Product Specification Sheet: 5-Valve Manifolds
M9	0208	DP 022-146	Dimensional Print: 1-Valve Manifold (Block and Bleed Valve)
M9	0809	PL 006-152	Parts List: 1-Valve Manifold (Block and Bleed Valve)
M9	0809	PSS 2B-1Z2 A	Product Specification Sheet: 2-Valve Manifolds
M24A	0809	DP 022-149	Dimensional Print: 5-Valve Manifold
M24A	0809	PL 006-152	Parts List: 5-Valve Manifold
M24A	0809	PSS 2B-1Z2 A	Product Specification Sheet: 5-Valve Manifolds
M24T	0809	DP 022-149	Dimensional Print: 5-Valve Manifold
M24T	0609	PL 006-152	Parts List: 5-Valve Manifold
M24T	0809	PSS 2B-1Z2 A	Product Specification Sheet: 5-Valve Manifolds
M25	0809	DP 022-147	Dimensional Print: 2-Valve Manifold
M25	0809	PL 006-152	Parts List: 2-Valve Manifold
M25	0809	PSS 2B-1Z2 A	Product Specification Sheet: 2-Valve Manifolds
PTM	0809	DP 022-147	Dimensional Print: 2-Valve Manifold
PTM	0809	PL 006-152	Parts List: 2-Valve Manifold
PTM	0809	PSS 2B-1Z2 A	Product Specification Sheet: 2-Valve Manifolds
PT7	0809	DP 022-147	Dimensional Print: 2-Valve Manifold
PT7	0809	PL 006-152	Parts List: 2-Valve Manifold
PT7	0809	PSS 2B-1Z2 A	Product Specification Sheet: 2-Valve Manifolds

Product	Date	Doc. Num	Title or Description
	0801	B0193XX	Field Device Integration Checklist
HHT50	0108	MI 020-500	Configurator for use with Intelligent Field Devices
HHT50	1008	PL009-154	Parts List: use with Intelligent Field Devices
HHT50	0209	PSS 2A-1Z3 L	Product Specification Sheet: use with Intelligent Field Devices
PC20	1010	MI 020-495	Intelligent Field Device Configurator
PC20	1102	PL 009-156	Parts List
PC20	1102	PSS 2A-1Z3 E	Product Specification Sheet
PC50	0108	MI 020-501	Field Device Tool - Installation and Parts List
PC50	0809	MI 020-504	Field Device Tool - Operation Using FoxCom Communication Protocol
PC50	0208	MI 020-505	Field Device Tool - Operation Using HART Communication Protocol
PC50	0114	MI 020-520	Field Device Tool with Advanced DTM Library - Operation Using HART Communications Protocol
PC50	0209	PSS 2A-1Z3 G	Product Specification Sheet
	0512	MI 019-276	Advanced DTM Library - Operation Using MODBUS Communication Protocol
	1211	MI 019-275	Advanced DTM Library - Operation Using FOUNDATION Fieldbus Communications Protocol
PCMM	0510	MI 020-384	Installation, Calibration, Configuration, and Maintenance (Used with IMV25-M Modbus Communications)
PCMM	1104	PL 009-158	Parts List: used with IMV225-M
PCMM	1004	PSS 2A-1Z3 H	Product Specification Sheet: used with IMV25-M
PCMV	1104	MI 020-496	Intelligent Field Device Configurator for IMV25 and IMV30 Multivariable Transmitters
PCMV	0809	MI 020-497	Intelligent Field Device Configurator for IMV31 Multivariable Transmitters
PCMV	0904	PL 009-157	Parts List: used with IMV25, IMV30 and IMV31
PCMV	1108	PSS 2A-1Z3 F	Product Specification Sheet: used with IMV25, IMV30 and IMV31

Temperature

Product	Date	Doc. Num	Title or Description
12A	0606	PL 006-330	Parts List
12A	0201	PSS 2B-1B1 A	Product Specification Sheet
MT	0207	DP 016-130	Dimensional Print
MT	0909	MI 016-128	MINOX Thermocouples Style B
MT	1213	PL 008-108	Parts List
MT	1213	PSS 1-1B6 A	Product Specification Sheet
PR	0207	DP 016-131	Dimensional Print
PR	0909	MI 016-131	Platinum Resistance Temperature Detectors (RTD) Style C
PR	1213	PL 008-111	Parts List
PR	1213	PSS 1-1B1 A	Product Specification Sheet
RTT15	0108	DP 020-462	Dimensional Print
RTT15	0214	MI 020-449	Intrinsic Safety Connection Diagrams
RTT15-F	0707	MI 020-462	Temperature Transmitter with FOUNDATION Fieldbus Protocol
RTT15-F	0214	PL 008-662	Parts List
RTT15-F	0214	PSS 2A-1F5 A	Product Specification Sheet
RTT15-P	0707	MI 020-462	Temperature Transmitter with PROFIBUS Protocol
RTT15-P	0214	PL 008-662	Parts List
RTT15-P	0214	PSS 2A-1F5 A	Product Specification Sheet
RTT15-T	0214	MI 020-463	Temperature Transmitter with HART Protocol
RTT15-T	0214	PL 008-662	Parts List
RTT15-T	0214	PSS 2A-1F5 A	Product Specification Sheet
RTT20	0108	DP 020-460	Dimensional Print
RTT20	0408	MI 020-453	Installation, Calibration, Configuration, and Maintenance
RTT20	0399	MI 020-454	Intrinsic Safety
RTT20	1096	MI 020-460	Operation, Configuration, and Calibration using HART M275 Configurator
RTT20	0596	MI 020-461	Configuration Menu Flowchart for 1-Line LCD Indicator
RTT20	0398	MI 020-469	Operation, Calibration, and Configuration Using HHT
RTT20	0509	PL 008-659	Parts List
RTT20	0811	PSS 2A-1F4 A	Product Specification Sheet
RTT20	0701	PSS 2A-1Z9 F	I/A Series Electronic Pressure Transmitters Options and Accessories
RTT25-F	0108	DP 020-461	Dimensional Print
RTT25-F	0605	MI 014-900	Fieldbus Overview
RTT25-F	0207	MI 020-488	Installation, Calibration, Local/Remote Configuration and Maintenance
RTT25-F	0310	PL 008-661	Parts List
RTT25-F	1112	PSS 2A-1F4 C	Product Specification Sheet
RTT25-F	0701	PSS 2A-1Z9 F	I/A Series Electronic Pressure Transmitters Options and Accessories
RTT30	0110	DP 020-530	Dimensional Print
RTT30	0310	MI 020-530	Temperature Transmitter with HART Protocol
RTT30	1210	MI 020-531	Temperature Transmitter Safety Information
RTT30	0110	MI RTT30	FM and CSA Safety Drawings
RTT30-A	1210	PSS 2A-1F6 A	Product Specification Sheet: HART Communications
RTT30-F	1210	PSS 2A-1F6 B	Product Specification Sheet: FOUNDATION Fieldbus Communications
RTT30	1210	MI 020-532	RTT30 I/A Series Temperature Transmitter

Temperature

Page 2 of 2

Product	Date	Doc. Num	Title or Description
RTT80	0214	PSS 2A-1F8 A	Product Specification Sheet
RTT80	0214	PSS 2A-1F8 B	Product Specification Sheet
RTT80	0214	PL 008-680	Model RTT80 I/A Series® Temperature Transmitter
RTT80	0214	MI 020-580	FM/CSA Safety Information
RTT80	0214	MI 020-581	ATEX/IECEX Safety Information
RTT80	0214	MI 020-582	RTT80 with HART Protocol
RTT80	0214	MI 020-583	RTT80F with Foundation Fieldbus Protocol
RTT80	0513	DP 020-580	Dimensional Print
PRMTA	1112	PL 008-681	Parts List
PRMTA	1112	PSS 3-3E1 A	Product Specification Sheet

May 2014

Temperature Thermowells

Product	Date	Doc. Num	Title or Description
TF	0307	DP 002-110	Dimensional Print: Flanged Thermowells
TF	1008	PSS 3-3D1 A	Product Specification Sheet: Flanged Thermowells
TS	0307	DP 002-111	Dimensional Print: Sanitary Thermowells
TS	1008	PSS 3-3D1 A	Product Specification Sheet: Sanitary Thermowells
TT	0307	DP 002-112	Dimensional Print: Threaded Thermowells
TT	1008	PSS 3-3D1 A	Product Specification Sheet: Threaded Thermowells
TW	0307	DP 002-113	Dimensional Print: Weld-In Thermowells
TW	1008	PSS 3-3D1 A	Product Specification Sheet: Weld-In Thermowells

Product	Date	Doc. Num	Title or Description
83	0409	B0800AB	Ensuring Premium Performance with Foxboro Intelligent Vortex Flowmeters
83	0908	MI 019-191	Amplifier Replacement for Conventional and Intelligent Vortex Flowmeters
83	1212	MI 019-179	Flow Safety Information
83	0403	MI 019-188	Conversion from Analog, FoxCom, or HART to FOUNDATION Fieldbus - Kit Numbers K0147VN and K0148VN
83	0205	MI 019-198	Addition or Replacement of Digital Display/Configurator Kits K0147EK, K0147HT, and K0147HU
83	1111	MI 019-209	Sensor Replacement Kits
83.-D	1000	MI 019-175	Intrinsic Safety Connection Diagrams
83.-F	0605	MI 014-900	Fieldbus Overview
83.-T	1000	MI 019-175	Intrinsic Safety Connection Diagrams
83F	0309	DP 019-150	Dimensional Print: Single Measurement Configuration
83F	0309	DP 019-151	Dimensional Print: Dual Measurement Configuration
83F	0610	MI 019-145	Universal Instruction Manual - Installation and Startup
83F	0297	MI 019-197	Convert Integral to Remote
83F-A	0596	MI 019-152	European Installations
83F-A	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
83F-A	0608	PL 008-708	Parts List
83F-A	0608	PSS 1-8A1 D	Product Specification Sheet
83F-F	0907	MI 019-193	Flowmeters with FOUNDATION Fieldbus
83F-F	0608	PL 008-708	Parts List
83F-F	0608	PSS 1-8A1 F	Product Specification Sheet
83S	0197	DP 019-154	Dimensional Print: Sanitary
83S	0610	MI 019-145	Universal Instruction Manual - Installation and Startup
83S-A	0507	MI 019-173	Sanitary Installation, Troubleshooting, and Maintenance
83S-A	0297	PL 008-713	Parts List
83S-A	0710	PSS 1-8A2 E	Product Specification Sheet
83W	0702	DP 019-152	Dimensional Print: Wafer Body
83W	0610	MI 019-145	Universal Instruction Manual - Installation and Startup
83W	0297	MI 019-197	Convert Integral to Remote
83W-A	0596	MI 019-152	European Installations
83W-A	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
83W-A	0107	PL 008-708	Installation, Troubleshooting, and Maintenance
83W-A	0700	PL 008-709	Parts List
83W-A	0608	PSS 1-8A1 D	Product Specification Sheet
83W-D	0205	MI 019-198	Addition of Digital Display and Configuration
83W-D	0700	PL 008-709	Parts List
83W-F	0907	MI 019-193	Flowmeters with Foundation Fieldbus
83W-F	0700	PL 008-709	Parts List
83W-F	0608	PSS 1-8A1 F	Product Specification Sheet
83W-T	0700	PL 008-709	Parts List
84	1111	B0800AJ	Ensuring Premium Performance with Foxboro Intelligent Vortex Flowmeters
84	1111	MI 019-146	Universal Instruction Manual - Installation and Startup

Vortex

Page 2 of 3

Product	Date	Doc. Num	Title or Description
84	1210	MI 019-177	FM and CSA Certification Connection Diagrams
84	1212	MI 019-179	Flow Safety Information
84	1111	MI 019-209	Sensor Replacement Kits
84F	1111	DP 019-120	Dimensional Print: Single Measurement Configuration
84F	1111	DP 019-121	Dimensional Print: Dual Measurement Configuration
84F	0212	DP 019-125	Dimensional Print: Single Measurement Configuration
84F	0813	MI 019-221	Model 83 to 84 I/A Series® Intelligent Vortex Flowmeter Conversion Kit Installation Procedure
84F	0212	DP 019-126	Dimensional Print: Dual Measurement Configuration
84F	0413	PSS 1-8A3 A	Product Specification Sheet
84F	0413	PSS 1-8A7 A	Product Specification Sheet
84F	0813	TI 027-070	Model 83 to 84 I/A Series® Intelligent Vortex Flowmeter Conversion Kit Ordering Instructions
84F-L	0212	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84F-L	1111	PL 008-714	Parts List: Low Power with Pulse Output
84F-L	0613	PL 008-753	Parts List: (Style B) Flanged Body Flowmeters
84F-L	0413	PSS 1-8A6 A	Product Specification Sheet: LOW POWER, Pulse Output, with HART
84F-M	0212	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84F-M	1111	PL 008-714	Parts List: Low Power without Pulse Output
84F-M	0613	PL 008-753	Parts List: (Style B) Flanged Body Flowmeters
84F-M	0413	PSS 1-8A6 A	Product Specification Sheet: LOW POWER, with HART
84F-T	0212	MI 019-202	Intelligent Vortex Flowmeter with HART - Installation, Operation, and Maintenance
84F-T	1111	PL 008-714	Parts List: Pulse Output
84F-T	0613	PL 008-753	Parts List: (Style B) Flanged Body Flowmeters
84F-U	0212	MI 019-202	Intelligent Vortex Flowmeter with HART - Installation, Operation, and Maintenance
84F-U	1111	PL 008-714	Parts List: without Pulse Output
84F-U	0613	PL 008-753	Parts List: (Style B) Flanged Body Flowmeters
84S	1006	DP 019-123	Dimensional Print: Sanitary
84S	0413	PSS 1-8A5 A	Product Specification Sheet
84S-L	0410	MI 019-214	Low Power with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-L	0410	PL 008-717	Parts List: Low Power with Pulse Output
84S-L	0413	PSS 1-8A6 A	Product Specification Sheet: LOW POWER, Pulse Output, with HART
84S-M	0410	MI 019-214	Low Power with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-M	0410	PL 008-717	Parts List: Low Power without Pulse Output
84S-M	0413	PSS 1-8A6 A	Product Specification Sheet: LOW POWER, with HART
84S-T	0410	MI 019-205	with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-T	0410	PL 008-717	Parts List: Pulse Output
84S-U	0410	MI 019-205	with HART - Installation, Operation, Troubleshooting, and Maintenance
84S-U	0410	PL 008-717	Parts List: without Pulse Output

Vortex

Page 3 of 3

Product	Date	Doc. Num	Title or Description
84W-L	1111	PL 008-714	Parts List: Low Power with Pulse Output
84W	0813	MI 019-221	Model 83 to 84 I/A Series® Intelligent Vortex Flowmeter Conversion Kit Installation Procedure
84W	1006	DP 019-122	Dimensional Print: Wafer Body
84W	0413	PSS 1-8A3 A	Product Specification Sheet
84W	0813	TI 027-070	Model 83 to 84 I/A Series® Intelligent Vortex Flowmeter Conversion Kit Ordering Instructions
84W-L	0212	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84W-L	0413	PSS 1-8A6 A	Product Specification Sheet: LOW POWER, Pulse Output, with HART
84W-M	0212	MI 019-211	Low Power with HART - Installation, Operation, and Maintenance
84W-M	1111	PL 008-714	Parts List: Low Power without Pulse Output
84W-M	0413	PSS 1-8A6 A	Product Specification Sheet: LOW POWER, with HART
84W-T	0212	MI 019-202	with HART - Installation, Operation, and Maintenance
84W-T	1111	PL 008-714	Parts List: Pulse Output
84W-U	0212	MI 019-202	with HART - Installation, Operation, and Maintenance
84W-U	1111	PL 008-714	Parts List: without Pulse Output
E83	0908	MI 019-191	Amplifier Replacement for Conventional and Intelligent Vortex Flowmeters
E83F	0398	MI 019-166	Sensor/Amplifier Replacement
E83FA	0309	MI 019-189	Installation, Troubleshooting, and Maintenance
E83L	0398	MI 019-166	Sensor/Amplifier Replacement
E83W	0398	MI 019-166	Sensor/Amplifier Replacement
E83WA	0309	MI 019-189	Installation, Troubleshooting, and Maintenance

May 2014

Other Totalizer and Flow Computer

Product	Date	Doc. Num	Title or Description
75LBA	1193	DP 019-543	Dimensional Print
75LBA	0298	MI 019-589	Pulse Input Liquid Batch Totalizer
75LBA	0398	MI 019-590	Analog Input Liquid Batch Totalizer
75LBA	1193	PL 008-727	Parts List
75LBA	1093	PSS 1-9C1 A	Product Specification Sheet
75MCA	0794	DP 019-542	Dimensional Print
75MCA	0398	MI 019-591	Pulse Input Liquid Mass Computer
75MCA	0498	MI 019-592	Analog Input Liquid Mass Computer
75MCA	0598	MI 019-594	Pulse Input Gas/Steam Mass Computer
75MCA	0598	MI 019-595	Analog Input Gas/Steam Mass Computer
75MCA	0794	PL 008-728	Parts List
75MCA	0397	PSS 1-9D1 A	Product Specification Sheet
75RTA	0794	DP 019-542	Dimensional Print
75RTA	0298	MI 019-587	Pulse Input Ratemeter Totalizer
75RTA	0298	MI 019-588	Analog Input Ratemeter Totalizer
75RTA	0393	PSS 1-9B1 A	Product Specification Sheet

Other

Positioners and I/P Converters

Product	Date	Doc. Num	Title or Description
E69F	0506	DP 018-430	Dimensional Print
E69F	0610	MI 018-429	Current-to-Pneumatic Converter - Safety Information
E69F	0605	MI 018-430	Current-to-Pneumatic Converter - Field Mounted
E69F	0906	PL 008-645	Parts List
E69F	0906	PSS 2B-2A3 B	Product Specification Sheet
E69P	0506	DP 018-440	Dimensional Print
E69P	0610	MI 018-429	Current-to-Pneumatic Valve Positioner - Safety Information
E69P	0185	MI 018-440	Current-to-Pneumatic Valve Positioner
E69P	0711	PL 008-647	Parts List
E69P	0510	PSS 4-10A2 A	Product Specification Sheet
E69R	0802	PL 008-646	Parts List
E69R	0407	PSS 2B-2A2 A	Product Specification Sheet
P91PA	0711	PL 005-365	Parts List: Poweractor
P91T	0706	DP 014-132	Dimensional Print
P91T	0802	MI 014-132	Type CP Pneumatic Position Transmitter
P91T	0802	PL 006-320	Parts List
P91T	0104	PSS 2B-1B1 B	Product Specification Sheet
P91V	0802	DP 012-340	Dimensional Print
P91V	0802	MI 012-340	Type C Vernier VALVACTOR - Yoke Mounted
P91V	0802	PL 005-320	Parts List

Other

Miscellaneous

Product	Date	Doc. Num	Title or Description
	0902	MI 014-101	Sulfur Detection Using Lead Acetate Test Paper
	0408	PL 000-001	Master Book 150 Table of Contents
	0408	PL 000-002	Master Book 150 Index by Model
	0813	PL 001-110	Chart Drives - Parts List
	0913	TI 037-094	Quality Assurance Certificates for Non-Nuclear Parts and Products
B0110AS	0506	PL 005-420	Parts Lists - Air Filter Set
B0110AT	0506	PL 005-420	Parts Lists - Air Filter Set
B0110ZA	0506	PL 005-420	Parts Lists - Air Filter Set
B0123HE	0506	PL 005-420	Parts Lists - Adjustable Pressure Regulator with Filter
B0123HE	1013	MI 011-157	B0123HF and B0123HE Pressure Regulators and B1279UL Air Filter
B0123HF	0506	PL 005-420	Parts Lists - Adjustable Pressure Regulator without Filter
B0123HF	1013	MI 011-157	B0123HF and B0123HE Pressure Regulators and B1279UL Air Filter
B0197BA	0506	PL 005-420	Parts Lists - Air Filter Assembly
B1278HE	0506	DP 011-159	Dimensional Print: Adjustable Pressure Regulator
B1278HE	0506	PL 005-420	Parts Lists - Adjustable Pressure Regulator
B1279UL	1013	MI 011-157	B0123HF and B0123HE Pressure Regulators and B1279UL Air Filter
CO	1107	DP 022-335	Dimensional Print: Compact Orifice with d/p Cell Transmitters
CO	1003	MI 022-335	Compact Orifice with d/p Cell Transmitters
CO	1003	PL 006-172	Parts List: Compact Orifice with d/p Cell Transmitters
CO	1003	PSS 3-5A1 E	Product Specification Sheet: Compact Orifice with d/p Cell Transmitters
IFOA	0707	MI 022-333	Integral Flow Orifice Assembly
IFOA	0607	PL 006-174	Parts List: Integral Flow Orifice Assembly
IFOA	0609	PSS 3-5A1 B	Integral Flow Orifice Assembly used with d/p Cell Transmitter
MAC	0802	PL 005-356	Air Cylinders - Parts List
PF100AX	1003	MI 018-180	75 V dc Multiloop Power Supply
P0300CQ	1003	MI 018-180	75 V dc Multiloop Power Supply
14A	0110	PL 003-525	Pneumatic Flow Integrator - Parts List
17BS	1205	PL 006-318	Side Mounted Buoyancy Transmitter - Parts List
17BT	1205	PL 006-318	Top Mounted Buoyancy Transmitter - Parts List
556	0410	MI 017-284	Pneumatic Analog Computer - Maintenance and Servicing
556	0711	PL 006-345	Pneumatic Analog Computer - Parts List
557	0711	PL 006-346	Pneumatic Square Root Extractor - Parts List
2761	0908	PL 008-102	Mechanical DEWCEL - Parts List
2761	0908	PSS 1-5A1 A	Mechanical DEWCEL - Product Specification Sheet
2781	0908	DP 008-103	Electrical DEWCEL Element - Dimensional Print
2781	0908	MI 003-318	Dew Point Measurement with DEWCEL Element - Electrical Temperature Measurement
2781	0908	PL 008-102	Electrical DEWCEL, Basic Sensor - Parts List
2781	0908	PSS 1-5A1 A	Electrical DEWCEL - Product Specification Sheet

Material Safety Data Sheets

MSDS Index

Page 1 of 2

Product	Date	Doc. Num	Title or Description
1800 Ink	0413	MSDS 010	Recorders - Type 1800 Aqueous Recorder Ink
Fiber Tip Cartridges	0413	MSDS 011	Recorders - Non-Bleed Aqueous Recorder Ink Fiber Tip Cartridges
B0200CQ	0413	MSDS 021	Controllers - Nitrogen - N2 Liquefied Nitrogen N2 (Cryogenic)
B0201JB	0413	MSDS 022	Controllers - Argon - Ar Liquefied Argon - Ar (Cryogenic)
B0201JQ	0413	MSDS 023	Controllers - Helium - He Liquefied Helium - He (Cryogenic)
0003093S	0313	MSDS 049	Echem Sensors - Reference Electrode Solution - 4M Potassium Chloride Solution Plus Glycol
0016776	0111	MSDS 046	Controllers - Mercury
0016777	0111	MSDS 046	Controllers - Mercury
0017033	0111	MSDS 046	Controllers - Mercury
0046719	0413	MSDS 019	Controllers - Toluene
0046721	0413	MSDS 018	Controllers - Ethyl Ether (Stabilized with ethyl alcohol)
0046722	0311	MSDS 014	Controllers - Ethyl Alcohol
0048130	0311	MSDS 092	Pressure Transmitters - DC111 Valve Lubricant and Sealant
0048192	0313	MSDS 076	Temperature - Dewcel Solution - 5% Lithium Chloride Solution - 1 Ounce or 1 Pint Bottle
0048860	0413	MSDS 099	Controllers - 4205 Prism Instant Adhesive Thermal Resistant Gel
1355061	0313	MSDS 051	Echem Sensors - Antimony pH Electrode Disk
1600585	0413	MSDS 140	Echem Sensors - Nyogel 761
A072203	0311	MSDS 032	Pressure Transmitters - DC704 Diffusion Pump Fluid Silicone
AS600AM	0313	MSDS 050	Echem Sensors - Glass pH Electrode Buffer Solution
B0134JY	1012	MSDS 097	Pressure Transmitters - Blue/Yellow 3.5 Ea Bars Epoxy
B0134LM	0413	MSDS 031	Pressure Transmitters - DC200 Fluid 2 CST and 5 CST
B0139SL	0511	MSDS 029	Pressure Transmitters - FC-770 Fluorinert Electronic Liquid
B0158LY	0313	MSDS 049	Echem Sensors - Reference Electrode Solution - 4M Potassium Chloride Solution Plus Glycol
B0200EB	0313	MSDS 119	Echem Sensors - Dissolved Oxygen Electrolyte Solution 0.5M KCL
BS814AQ	0313	MSDS 136	Echem Sensors - Internal Filling Solution
BS814AF	0313	MSDS 139	Echem Sensors - Reference Electrode Solution - 4M Potassium Chloride Solution Plus Glycol
BS814AK	0313	MSDS 146	Reference Cavity Solution - Aqueous Electrolyte Solution with Glycerol
C1000VY	0311	MSDS 103	Pressure Transmitters - DC200 Fluid 10 CST
D0114YC	0511	MSDS 034	Pressure Transmitters - DC200 Fluid, 500 CST - Silicone
D0116MP	0413	MSDS 043	Controllers - Ethylene Glycol
D0123MX	0111	MSDS 044	Controllers - Triethanolamine
D0129ZT	0413	MSDS 108	Controllers - High Intensity Nylon Wick Aqueous Recorder Ink
D0129ZU	0413	MSDS 024	Controllers - Nylon Wick 63 Aqueous Recorder Ink
D0129ZV	0413	MSDS 024	Controllers - Nylon Wick 63 Aqueous Recorder Ink
D0129ZW	0413	MSDS 024	Controllers - Nylon Wick 63 Aqueous Recorder Ink
F0109EH	0413	MSDS 120	Controllers - Moebius Oil Syntalube
H0103AY	0313	MSDS 076	Temperature - Dewcel Solution - 5% Lithium Chloride Solution - 1 Ounce or 1 Pint Bottle

Material Safety Data Sheets

MSDS Index

Page 2 of 2

Product	Date	Doc. Num	Title or Description
L0121CN	0111	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
L0121CS	0111	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
L0121CX	0111	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
L0121DC	0111	MSDS 109	Controllers - Universal Marker Aqueous Recorder Ink
N1205BR	0511	MSDS 143	Pressure Transmitters - DC200 Fluid, Foodgrade, 350 CST - Silicone
N1206TZ	0413	MSDS 142	Pressure Seals - Neobee M-20
P0104RM	0413	MSDS 048	Dow Corning (R) 550 Fluid
Q0104KE	0413	MSDS 053	Echem Sensors - 4 Molar Potassium Chloride Saturated with Silver Chloride
S0106ML	0413	MSDS 086	Loctite 222MS Threadlocker
T0103RK	0413	MSDS 013	Controllers - sec-Butybenzene
T0103KR	0511	MSDS 015	Controllers - Propane
T0103KS	0413	MSDS 016	N-Butane
T0103KT	0309	MSDS 017	Controllers - Methyl Chloride
T0103PX	0511	MSDS 020	Controllers - Acetone
X0114AF	0413	MSDS 127	Pressure Transmitters - Key Abso-Lute (Oxygen Sealing Compound)
X0118CC	0413	MSDS 088	Pressure Transmitters - Lubriplate Aero
X0180AM	0511	MSDS 125	Pressure Transmitters - FC-43 Fluorinert Brand Electronic Liquid
X0180DE	0712	MSDS 126	Pressure Transmitters - PMX200 Silicon Fluid 5 CS
X0180GS	0712	MSDS 144	Pressure Transmitters - F-900 Torque Seal (Red) Sealing Compound
X0180HB	0309	MSDS 137	Echem Analyzers - DC838 Silicone Adhesive/Sealant (Kit-AG100WH)
X0180HC	0413	MSDS 138	Echem Analyzers - Multipurpose Alcohol Wipes (Kit-AG100WH)
X0180HK	0413	MSDS 141	Magnetic Flow Flowtubes - DC3-4207 Dielectric Tough Gel Part A and B

Technical Information Index

Product	Date	Doc. Num	Title or Description
762, 760, and 740 Controllers	0895	TI 039-200	EXACT Tuning with 762, 760, and 740 Series Controllers
Electrochemical Sensors	0207	TI 612-005	Electrodeless Conductivity, Toroidal Magnets, and the Procedure of Degaussing
MAG2 Magnetic Flowmeters	1208	TI 027-077	Technical Information Magnetic Flowmeter Application Guideline
Magnetic Flowmeters	0211	TI 27-71f	Technical Information Material Selection Guide
Magnetic Flowmeters	0906	TI 027-072	Technical Information Electrical Conductivity of Process Liquids
Mass Flowmeters	0300	TI 001-053	Tutorial Percent Solids Calculation
Vortex Flowmeters	0813	TI 027-070	Model 83 to 84 I/A Series® Intelligent Vortex Flowmeter Conversion Kit Ordering Instructions
Pressure Transmitters	1186	TI 37-75b	Technical Information - Material Selection Guide
Pressure Transmitters	0109	TI 037-097	Technical Information - Process Sealing of Transmitters for use in Class I, Zone 0, 1, and 2 Hazardous Locations
Other	0913	TI 037-094	Quality Assurance Certificates for Non-Nuclear Parts and Products